


中文

使用说明书

M69

TWS 蓝牙耳机

产品结构图



包装清单

耳机x2pcs
充电仓x1pcs
Type-C充电线 x1ps
说明书x1pcs
硅胶耳帽1对

产品操作介绍

功能	操作	指示灯	提示音
配对名	M69		
低电量报警	当耳机的电压低于3.3V, 会有提示, 直至耳机关机	红灯闪烁5次	叮咚
断开连接	超出有效连接范围, 或手动操作断开智能设备蓝牙连接	主耳红灯交互闪烁, 副耳灯熄灭	Disconnected /断开连接
自动配对	开机后自动配对, 在有有效范围内, 耳机会自动连上上次连接过的智能设备	灯熄灭	connected /连接成功
耳机充电	耳机放回充电仓内, 自动关机并开始充电, 耳机会灯常亮, 充满后灯熄灭		
将耳机放回充电仓	将耳机放回充电仓中, 主耳提示音, 显示当前电量, 耳机充电显示开始		
给充电仓充电	插上适配磁座充电仓充电, 充电仓显示屏显示当前电量		
给充电仓充满电	充满后显示屏显示电量为100		
备注:	当蓝牙耳机连接智能设备, 切换游戏模式时, 耳机的使用时长和连接距离会有缩短		

耳机参数

- 1.产品名称: M69

2.蓝牙耳机版本: Bluetooth 5.4

3.支持模式: AAC/SBC

4.蓝牙传输距离: 10m

5.载波频率: 2.402GHz~2.480GHz

6.频率范围: 20Hz~20KHz

7.喇叭尺寸: 46mm

8.喇叭灵敏度: 115±dB ±3dB

9.喇叭阻抗: 32Ω±15%
- 10.喇叭额定功率: 3mW

11.耳机电池容量: 3.7V/30mAh (聚合物电池)

12.充电仓电池容量: 3.7V/200mAh (聚合物电池)

13.充电接口: USB Type-C

14.耳机使用时间: >5小时

15.耳机单次充电时间: ≈1.5小时

16.充电仓充电时间: ≈1.5小时

17.充电仓给耳机充电次数: 2次

18.关机待机电时间: ≈160小时

简单故障排查

故障	原因	解决方法
不开机	耳机电量不足	对耳机进行充电
耳机不配对	耳机电量不足	对耳机进行充电
充电无提示	耳机没有放好	调整耳机放置的位置
自动关机	自动电量不足	对耳机进行充电
耳机有回音	音量太大或者环境太嘈杂	调低音量或更换环境
耳机有杂音	外界干扰严重或距离手机太远	更换地点或靠近手机
对方听不清	耳机佩戴不正确或音量太小	调整耳机佩戴或音量大小
信号断续	外界干扰严重或距离手机太远	选择无干扰的环境或靠近手机

产品中有害物质的名称及含量

部件名称	有害物质					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
主机	X	○	○	○	○	○
配件	X	○	○	○	○	○

本表依据SJ/T11364的规定编制。
0:表示该有害物质在该部件所有均质材料中含量均在GB/T 26572规定的限量要求以下。
X:表示该有害物质在该部件所有均质材料中含量超过GB/T 26572规定的限量要求。
注:本产品标有“X”的原因是, 现阶段没有可供选择的替代技术或部件。

安全指引

- 1.初次使用本产品前, 请先充满电再使用。

2.产品不是玩具, 12岁以下儿童须在成人监护下使用。

3.请使用通过正规厂家安全认证的5V/1A充电器, 避免支持高压的快充充电器对产品造成损坏。

4.请在安全的环境下充电, 在给充电仓充电时, 电量充满后请尽快将充电线拔出, 避免长时间充电对电池造成损坏。充电仓的充电方式为Type-C接口。

5.本产品内置不可拆卸的可重复充电电池, 重复对耳机进行充电和放电会随着时间推移而导致电池性能下降, 这对于所有可以重复充电电池来说均属于正常现象。

6.本产品带有锂电池, 如长时间未使用, 请至少一个月充电一次。

7.因个体差异原因, 如佩戴时感到皮肤不适, 请停止佩戴并咨询医生。

8.在蓝牙连接本产品使用时, 请将耳机声音调至合适音量大小, 以免长期在大音量状态下对听力造成损伤。

9.如果您在从事需要集中注意力的活动时使用本产品, 应注意您自身和他人安全, 例如驾车或骑自行车时, 在道路、施工区域、铁路上或徒步行走时。您应取下耳机或调整音量以确保可以听到周围的声音, 包括警报和警告信号。

10.请遵守所在地区或国家的相关规定。驾车时按照要求使用本产品。

11.本产品含有磁性材料, 使用或安放产品时, 请远离具有强磁场或强电场的电器, 如微波炉、电冰箱等。

12.建议在温度-0°C~+45°C的环境中本产品。当环境温度低于 +5°C时, 电池性能会受到限制。

13.有明文规定禁止使用无线设备的场所, 请勿使用本产品, 否则可能会干扰其它电子设备或导致其它危险。

14.靠近医疗及工业设备或飞机之前, 请咨询当地工作人员能否使用。

15.对本产品清洁和维护前, 请停止使用并断开, 并断开与其它设备的所有连接或线路。

16.请根据本地法令, 正确处理废弃电子产品, 不可将电子电气设备、部件、电池与其它生活垃圾一起丢弃。
- 1.请遵循本说明书的内容进行使用, 避免产品因错误操作损坏。

2.本产品请远离儿童、火源、热源、冷冻源、水源及化学品。

7.请勿长时间使用大音量收听, 以免对听力造成不良影响。

4.请勿将产品及附件放入任何液体或用水冲洗产品, 否则导致火灾或触电危险。

5.请勿将产品放置在太阳直射或者温度高的地方, 高温会缩短电子部件的使用寿命, 损坏电池, 使其某些塑料部件变形。

6.请勿将本产品放在尘土多、温度和湿度过高或过低的地方保存。

7.请勿将磁条卡(例如银行卡、公交卡等)长期接触本产品, 否则可能导致磁条卡被磁场损坏。

8.请勿在本产品上施加额外的压力, 或拆卸、挤压、震动本产品, 以防产品损坏。

9.请勿在靠近热源处使用本产品, 如散热器、热风调节器、炉灶或其他产生热量的仪器。


10.请勿堵塞本产品的开口处, 如充电口、指示灯、麦克风等。

11.请勿在暴雨天气下使用设备, 雷暴可能导致设备出现故障, 增大电击的风险。

12.请避免本产品及其配件潮湿或受潮, 且剧烈运动或出汗较多时使用本产品, 防止液体渗透到产品内部损坏本产品。

13.产品属于内置聚合物锂电池, 不可更换, 请勿丢弃或置以火中, 以免爆炸、起火等危险发生。

14.如因消费者违反上述警示而不恰当地使用造成的人身及财产损失将自行承担一切后果本公司将不承担任何法律责任。




英语

INSTRUCTION MANUAL

M69

TWS Bluetooth earphones

Product structure diagram



Packing list

Headphones x2pcs
Charging case x1pcs
Type-C charging cable x1ps
Instruction manual x1pcs
Silicone ear cap 1 pair

Introduction to product operation

function	operate	Light	Tone
Pair name	M69		
Boot	When the earbuds are in the charging compartment, take out the earbuds to automatically turn on/earbuds. When the machine is off, press and hold the function button for 3 seconds to turn it on	The blue light is on	Power on/开机
Shutdown	After the earbuds are placed in the charging case, they are turned off/when the earbuds are powered on, press and hold Function button for 5 seconds, power off	The red light flashes three times	Power off/关机
Pair the left and right earphones	The left and right earphones will automatically enter pairing mode after powering on	After the left and right ear- ears are successfully paired, the blue and red lights of the main ear will flash alternately, and the light of the secondary ear will be extinguished	Connected/Pairing successfully
Toggle the Chinese and English prompt tone	When the smart device is not connected, tap any left and right ear functions in a row Button 2 times to switch the language. The factory default is English		English/中文
Smart device connectivity	When the ears are successfully paired, it will automatically enter the state to be connected. At this time, open the Bluetooth list of the smart device to search and click "M69" to connect. After the earbuds are successfully connected to the smart device, the Bluetooth indicator will go off	The lights in the left and right ears are turned off	Connected /连接成功
Toggle Music/ Game mode	Connect the device to the state of the left and Right Earphone Touch Keys 4 times, mode switching, the factory default music mode	/	音乐/游戏模式, MUSIC/GAME MODE
Play/Pause	Double-click any left or right earphone touch button	/	/
Previous song	In music mode, tap the left earphone touch button three times	/	/
Next song	In music mode, tap the right earphone touch button three times	/	/
Increase the volume	Click the right earphone touch button	/	Maximum volume indicator (knock)
Reduce the volume	Click the left earphone touch button	/	/
Voice assistant	Connect the state, long press the left earphone touch button 2 seconds to release, you can wake up the voice assistant	/	Ding Dong

Answer an incoming call	Call status, double-click any left or right earphone touch button	/	Ringtone of your phone
Reject an incoming call	In the incoming call state, press the touch button of any headset for 2 seconds	/	/
Hang up	While on the phone, double-click the touch button on any headset	/	/
Low battery alarm	When the voltage of the earbuds is lower than 3.3V, there will be a prompt up to the ear Powered off every 5 seconds	The red light flashes every 5 seconds	Ding Dong
Disconnect	Outside the effective connection range, or manually disconnect the Bluetooth connection of the smart device	The red and blue lights of the main ear flashed alternately, and the secondary ear light went out	Disconnected /断开连接
Automatic reconnection	After powering on or disconnecting the earbuds will automatically reconnect to the last connected smart device within the effective distance	The lights go out	connected /连接成功
Charge the headphones	Put the earbuds back into the charging compartment, automatically power off and start charging, the red light of the earbuds will always be on, and the light will turn off when fully charged		
Place the earbuds back into the charging case	While the earbuds are charging, the display lights up to show the current power level, and the display screen turns off when the earbuds are fully charged		
Charging the charging case	Plug in the adapter to charge the charging case, and the charging case display shows the current power level		
Fully charge the charging case	When fully charged, the display shows a battery level of 100		

Note: When the Bluetooth headset is connected to a smart device and the game mode is switched, the usage time and connection distance of the headset will be shortened

Headset parameters

1. Product name: M69

2. Bluetooth version: Bluetooth 5.4

3. Support mode: AAC/SBC

4. Bluetooth transmission distance: 10m

5. Carrier frequency: 2.402GHz~2.480GHz

6. Frequency response range: 20Hz~20KHz

7. Horn size: 46mm

8. Horn sensitivity: 115dB ±3dB

9. Horn impedance: 32Ω±15%
10. Horn rated power: 3mW

11. Headphone battery capacity: 3.7V/30mAh (polymer battery)

12. Charging bin battery capacity: 3.7V/200mAh (polymer battery)

13. Charging interface: USB Type-C

14. Headset use time: >5 hours

15. Earphone single charging time: >=1.5 hours

16. Charging time: >=1.5 hours

17. Charge the headset: 2 times

18. Shutdown standby time: >=160 hours

Simple troubleshooting

fault	CAUSE	Resolution
Doesn't turn on	The headphones are low on battery	Charge the headphones
The headphones flash red	The headphones are low on battery	Charge the headphones
Charging is silent	The headphones were not put away	Adjust the position where the headphones are placed
Automatic power off	Automatic low battery	Charge the headphones
Disconnect	The volume is too loud or the environment is too noisy	Adjust the volume or change the environment
There is a murmur from the headphones	Serious external interference or too far away from the phone	Change the location or be close to your phone
The other party's voice is quiet	The headphones are worn incorrectly or the volume is too low	Adjust the headset wear or volume
The signal is intermittent	Serious external interference or too far away from the phone	Choose a distraction-free environment or be close to your phone

The name and content of the hazardous substance in the product

Part name	Hazardous substances					
	lead (Pb)	mercury (Hg)	cadmium (Cd)	Hexavalent chromium (Cr(VI))	Polybrominated biphenyls (PBB)	Polybrominated diphenylethers (PBDE)
host	X	○	○	○	○	○
fittings	X	○	○	○	○	○

This table is prepared in accordance with the provisions of SJ/T11364.
0: It means that the content of the hazardous substance in all homogeneous materials of the part is below the limit specified in GB/T 26572.
X: It means that the content of the hazardous substance in at least one of the homogeneous materials of the part exceeds the limit requirements specified in GB/T 26572.
Note: The reason why this product is marked with an "X" is that there are no alternative technologies or components to choose from at this stage.

Safety guidelines

1. Before using this product for the first time, please fully charge it before using it.

2. The product is not a toy, and children under the age of 12 must be used under the supervision of an adult.

3. Please use a 5V/1A charger that has passed the safety certification of a regular manufacturer to avoid damage to the product caused by a fast charging charger that supports high voltage.

4. Please charge in a safe environment, when charging the charging case, please pull out the charging cable as soon as possible after the power is fully charged to avoid damage to the battery caused by long-term charging. The charging method of the charging case is the same as that of the rechargeable batteries.

5. This product has a built-in non-removable rechargeable battery, and repeated charging and discharging of the battery will lead to a decrease in battery performance over time, which is normal for all rechargeable batteries.

6. This product comes with a healthy battery. If it has not been used for a long time, please charge it at least once a month.

7. If you feel skin discomfort when wearing it due to individual differences, please stop wearing it and consult a doctor.

8. When using this product with Bluetooth connection, please adjust the sound of the earphones to an appropriate volume to avoid hearing damage caused by long-term loud volume.

9. If you use this product while engaging in activities that require concentration, you should pay attention to your own safety and the safety of others, such as when driving or cycling on roads, construction sites, railways, or walking. You should remove your headphones or adjust the volume to ensure that you can hear the sounds around you, including alarms and warning signals.

10. Please follow the relevant regulations of your region or country and use this product as required when driving.

11. This product contains magnetic materials, please keep away from electrical appliances with strong magnetic or electric fields, such as microwave ovens, refrigerators, etc., when using or placing the product.

12. It is recommended to use this product in an environment with a temperature of -0°C-45°C. When the ambient temperature is below +5°C, battery performance is limited.

13. Do not use this product in places where it is expressly prohibited to use wireless equipment, otherwise it will interfere with other electronic equipment or cause other dangers.

14. Before approaching medical or industrial equipment or boarding a plane, please ask the local staff if they can use it.

15. Before cleaning and maintaining this product, stop using this product, turn off all applications, and disconnect all connections or other equipment.

16. Please dispose of waste electronic products properly in accordance with local laws and regulations, and do not dispose of electrical and electronic equipment, parts, batteries and other household waste.
1. Please follow the content of this manual to avoid damage to the product due to incorrect operation.

2. Keep this product away from children, fire, heat, refrigeration, water and chemicals.

3. Do not listen at a loud volume for a long time to avoid adverse effects on hearing.

4. Do not immerse the product and accessories in any liquid or rinse the product with water, otherwise it will cause fire or electric shock hazard.

5. Do not place the product in the sun or in a place with high temperature. High temperatures can shorten the life of electronic components, damage batteries, and deform certain plastic parts.

6. Do not store this product in a place with a lot of dust, too high or too low temperature and humidity.

7. Do not apply greater pressure to this product, or disassemble, beat, or shake this product to prevent damage to the product

8. Do not use this product near heat sources, such as radiators, hot air regulators, stoves, or other instruments that generate heat

9. Do not block the openings of this product, such as charging ports, indicator lights, microphones, etc.

11. Do not use the device in rainstormy weather, thunderstorms may cause the device to malfunction and increase the risk of electric shock.

12. Please avoid using this product when this product and its accessories are exposed to rain or moisture, and when you exercise vigorously or sweat a lot, to prevent liquid from penetrating into the product and damaging this product.

13. The product belongs to the built-in polymer battery, which cannot be replaced, please do not discard or put it in the fire to avoid explosion, fire and other dangers.

14. If the consumer violates the above warning and inappropriate use, the personal and property damage will be borne by the company, and the company will not incur any legal responsibility.



FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.