



# Simsky




# What's included


---




**Camera**  
**x 1**



**Mounting  
Bracket & Level**  
**x 1**



**Power Adapter**  
**x 1**




User Manual

**User Manual**  
**x 1**


# Overview

---



# Overview


---



# Quick start

---


## 1. Download&Register



## 2. Plug in the power cord and turn on the switch



## 3.reset the device



## 4. Connect the camera to your smartphone



# Quick start

---

5. Press and hold the button to connect to the screen  
(needs to be purchased separately)



# Specifications

---


|                    |                                                                                                    |
|--------------------|----------------------------------------------------------------------------------------------------|
| Model              | YM300 BU                                                                                           |
| Resolution         | 2560*1440                                                                                          |
| Lens               | f=3.0mm / F2.0;f=6.3 / F2.0                                                                        |
| Field of View      | 110°~18° (Diagonal)                                                                                |
| Pan Range          | 240°                                                                                               |
| Tilt Range         | 70°                                                                                                |
| Connectivity       | Wi-Fi 2.4GHz 802.11b/g/n/ax                                                                        |
| Support System     | Android 11.0 or IOS 13.0 or above                                                                  |
| TF card            | 32GB (not for sale)                                                                                |
| Mounting           | Wall Mount (Standard Package)<br>Floor Stand Mount (Need to<br>Purchase a Replacement Floor Stand) |
| Power              | DC5V / 1.5A                                                                                        |
| Working Temperatur | 32-104°F                                                                                           |
| Dimensions         | 2.68*2.56*4.33inches                                                                               |
| Item Weight        | 7.05ounces                                                                                         |

# Safety instructions

---

## SAFETY

**WARNING:** Strangulation Hazard—Children have STRANGLED in cords. NEVER attempt to use cord without the protective covering. Check protective covering before each use to ensure that the cord is not exposed to your child. Immediately discontinue use if protective covering is damaged or broken.



- This device is designed to be mounted behind a standard crib and against the wall.
- Adult assembly is required. Keep small parts away from children when assembling.
- This product cannot replace adult supervision. Ensure your baby's health by checking on him/her regularly.
- This device is designed for indoor use only.
- This product and its packaging are not toys. Do not allow children to play with them.
- Falling warning: To prevent the product from falling and causing injury, make sure to install the monitor in a stable location, tighten the screws securely, and monitor your device.
- Make sure the camera could capture the baby's facial image clearly after the installation.

# FAQ

---

**I don't hear “received network configuration information,connecting to the network now,please wait a moment”when I pair the monitor.**

Setup routers to a 2.4GHz Wi-Fi network

QR code cannot be recognized, the possible reasons are as follows:

- 1). Screen is too dark
- 2). Too far or too close from the lens
- 3). Reflection

## **How to RESET the Cheego YM300 BU?**

Press and hold the RESET button on the monitor for 5 seconds, then follow the "Reset Device Step by Step" instructions in the Simsky App, completing each step as directed.

# FAQ

---

## **What should I do if mobile phone cannot receive the notification?**

Go to mobile “setting”→“simsky”→“Allow notification”

## **What should I do if there's an echo during intercom?**

During intercom, keep the mobile phone at least 33 feet away from the device to minimize echo and howling, which are normal occurrences.

## **What should I do if the Cheego YM300 BU goes offline (device icon gray)?**

### **Suggestions:**

- 1). Please shut down your device and then reboot it.
- 2). If you have changed your Wi-Fi network, please refer to the RESET instructions to reset your monitor.

# Warranty

---

## **Satisfaction Guarantee & Return Policy**

Thank you for purchasing simsky products. If you are not completely satisfied with your purchase, you may return the product for a full refund within 30 calendar days of setting up a hardware product ( [simsky.com](https://simsky.com)) or within 15 days of activating an online product (simsky authorized online reseller). This satisfaction guarantee requires proof of purchase from an authorized seller. Purchases from 3rd party retailers will need to be returned to the original place of purchase.

## **Limited Warranty**

This limited warranty contains important information about your rights and obligations, as well as limitations and exclusions that may apply to you.

This limited warranty only applies if you are the original purchaser, use and operate the product in the United States or Canada. Please note if you are not resident of the United States or Canada, this Limited Warranty & Return Policy does not apply to you. Products obtained from unauthorized retailers are not covered by this Limited warranty. Please be aware that there are some retailers and websites that claim to be authorized retailers of simsky when they are not. Note that when you purchase from these unauthorized retailers, you are taking a risk, including a risk that these products are used or defective, and this limited warranty will not apply.

# Warranty

---

## **1.What This Limited Warranty Covers?**

Period of coverage.Warrants to the owner of the enclosed product that the product contained in this box ("Product") will be free from defects in materials and workmanship for a period of one (1) year from the date of delivery following the original retail purchase (the "Warranty Period"). If you believe you have received a defective product, we will either repair or replace the defective product or its defective component part(s) in accordance with the terms of this limited warranty. We warranty replacement for the remaining unexpired period of the original product's warranty. This limited warranty is the only warranty available for our products.

## **2.What This Limited Warranty Does Not Cover?**

- Products labeled as "sample" or "Not for Sale" or sold "AS IS."
- Ineligible Products that have been modified, tampered with, improperly maintained or repaired, or altered in any way.
- Products that have been handled, stored, installed, tested, or used not in accordance with the Terms of Service or other instructions provided by simsky.
- Products that have been abused or misused.
- Damages caused by Acts of God, including but not limited to lightning, flood, tornado, earthquake, or hurricane.

# Warranty

---

- Consumable parts, such as batteries, unless the damage is due to defects in materials or workmanship.
- The use of unauthorized service providers for maintenance or repair.
- Unauthorized use of the Product or software that may affect its performance.
- This limited warranty does not cover any software, even if it is packaged or sold with the Products.
- Please refer to the licensing agreement accompanying the software for details of your rights regarding its use.
- This limited warranty does not guarantee that the operation of the product will be uninterrupted or error-free.
- This warranty is non-transferable from the original end-user to others.

## **3.Disclaimer of Warranties**

Except as stated above in section 1 of this limited warranty, and to the maximum extent permitted by applicable law, simsky disclaims all express, implied, and statutory warranties and conditions with respect to the product, including the implied warranties of merchantability, fitness for a particular purpose and non-infringement. To the maximum extent permitted by applicable law, simsky also limits the duration of any applicable implied warranties or conditions to the duration of this limited warranty. For the avoidance of doubt, nothing in this clause 6 is intended to exclude any warranties or guarantees which cannot be excluded under applicable laws.

# Warranty

---

## **4. Your Rights and This Limited Warranty**

We limit the applicability of implied warranties, including the implied warranties of merchantability and fitness for a particular purpose, to the duration of this limited warranty. To the extent permitted by law, we disclaim all other warranties of any kind. Some states and countries do not allow limitations on implied warranties, so the above limitation may not apply to you. Our sole liability for any defect shall be as set forth in this limited warranty and excludes any claims for incidental or consequential damages. Some states and countries do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. No person or entity is authorized to make any other warranty on our behalf. This warranty gives you specific legal rights. You may also have other rights which vary from state to state and country to country.


# Compliance

---



## DECLARATION OF CONFORMITY

Declares that the Model YM-300 equipment is in compliance with Part 15 of the FCC Rules and RoHS regulations.



This symbol means the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment. For more information on disposal and recycling of this product, contact your local municipality, disposal service or the shop where you bought this product.

FCC Statement This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.