

ULTIMEA

USER MANUAL

POSEIDON E40 SMART PROJECTOR

STREAM INTO THE BRIGHT WORLD



Model No.: U0340

Poseidon E40

Contents

03 Smart Projector User Manual

English

18 Smart Beamer Bedienungsanleitung

Deutsch

34 スマートプロジェクターユーザーマニュアル

日本語

50 Smart Projecteur Manuel d'utilisation

Français

66 Smart Proiettoe Manuale d'uso

Italiano

82 Smart Proyector Manual de usuario

Español

WE ARE READY TO HELP



support@ultimea.com

Prefer video tutorial?

Setup guidance video and User Manuals on ULTIMEA website.



support.ultimea.com



@ultimea_official



+1 888-598-8875 (US) Mon-Fri 9am-5pm (PST)
+49 89-628-25828 (EU) Mon-Fri 9am-5pm (CET)

1 Safety Instructions

Read all instructions before you use this device. Do not make any changes or create settings that are not described in this manual. If physical injury, loss of data, or damage is caused by failure to follow instructions, the warranty does not apply.

Setup

- To avoid personal injury or property damage, please comply with the instructions in this manual carefully and do not use the product in any other way.
- To reduce the risk of fire and/or electric shock, do not expose the device to rain or moisture. Objects filled with liquids, such as vases, should not be placed on this device.
- Do not place this device on soft surfaces such as tablecloths or carpets, otherwise the device could be a fire hazard.
- Do not place this device in areas susceptible to excessive dust and dirt or near any appliance generating a strong magnetic field.

- To prevent overheating, do not block or clog the ventilation openings.
- Never place this device in a confined space. Always leave enough space around this device for ventilation.
- Avoid overexposing this device to direct sunlight, heat, large temperature fluctuations, and moisture. Avoid extreme temperatures.
- When this device is running for a long period of time, the surface may become hot. If this occurs, shut it down immediately and unplug the charger. Resume operation after the device has cooled down.
- Always handle this device with care. Avoid touching the lens.
- Do not allow children to handle the device without supervision.
- Do not place heavy or sharp objects on this device.
- To avoid electric shock, do not disassemble the device.
- Avoid extreme vibration. It may damage the internal components.
- Only use attachments or accessories specified by the manufacturer.

- Please comply with the laws and regulations of the country and region where the equipment is located (used), observe professional ethics, pay attention to safety obligations, and strictly prohibit the use of our products or equipment for any illegal purpose.
- When using a projector in a dark environment, be mindful of the safety of your audience. Ensure that equipment such as projectors and power cords are placed in locations where they cannot be easily tripped over or touched, and avoid crossing cords to minimize safety risks.

Power Supply

- Use only the provided power adapter.
- Power off the device before removing the power supply from the socket.
- Protect the power cord from being walked on or pinched, particularly at plugs.
- Unplug this device if there are lightning storms or when unused for a long period of time.
- Before you make or change any connections, ensure that all devices are disconnected from the power outlet.

- Never touch the power cable or the power connector with wet hands.

Hearing Safety

- To prevent hearing damage, do not listen for extended periods at high volume. Set the volume to a safe level.

Caution

- Do not stare directly at the operating beam. The bright light may damage your eyes.

Cleaning

- Use a soft, lint-free cloth. Never use liquid, gaseous, or easily flammable cleansers to clean.
- Do not use any liquid cleaning agents to clean the lens to avoid damaging the coating film on the lens.
- Wipe the surfaces gently. Be careful that you do not scratch the surface.
- Use lens cleaning paper to clean the lens.

Repairs

- Do not make any repairs to this device yourself. Only have your device repaired by an authorized service center.
- Improper maintenance can result in injuries to persons or damage to this device.
- Refer all servicing to qualified service personnel.

System

- Since the Android TV system interface will be updated regularly, and the user interface will be updated through software upgrades, there may be some differences between the interface and the manual. If there is a difference between the manual and the user interface of the final product, please refer to the actual display prevails.

2 What's Included



Poseidon E40
Smart Projector



Remote Control
(Batteries not included)



User Guide



Warranty Card



HDMI Cable



ADAPTER:
Model No.:GQ180-2400833-E1
Input:AC 100-240V, 50/60Hz, 2.5A Max
Output:DC 24, 8.33A, 200W

3 Overview

Power button


Lens

Camera

Speaker

Front IR receiver

ToF Radar sensors



DC-IN


USB port

HDMI port

3.5mm AUX port

Back IR receiver

1/4 inch bracket
screw hole



Power On/Off

- Inserting the power plug using the provided adapter.
- Press the power button or remote control power button once to power on.
- Press the power button or remote control power button twice to power off.




Plug the power adapter into an outlet.



Press the power button to turn on the projector.

Placement



- Place Poseidon E40 on a stable, flat surface in front of the projection surface.
- Please adjust the distance between Poseidon E40 and the projection surface to get the desired projection image.

Projection Distance and Projection Image Size

Projection Image Size(inch)	Distance(m)	Distance(ft)
80	2.17	7.12
90	2.44	8.01
100	2.71	8.89
110	2.98	9.78
120	3.25	10.66

Notice: The projection image size refers to the distance of the diagonal of the image size instead of the length of the image size.

Auto Focus

- Turn the device towards a suitable projection surface or wall, the Poseidon E40 will enter autofocus until get a clear image.

Focus Manual

- Press "F+" / "F-" on the remote control to manually adjust the focus. Please carefully observe the focus icon until get a clear image.

Keystone Correction

- The Poseidon E40 supports Auto keystone, Vertical correction, Horizontal correction and remote Corner Correction.

Auto Keystone


- When the projector image is distorted, it will perform auto keystone correction to restore the image to a rectangle. If you find the auto keystone correction does not work as well as before, follow the instructions below to optimize it.

- Press the  button to go to projector home menu, [Settings]->[Projection Settings]->[Keystone Settings].
- Select [Calibration Settings] and adjust the projector for the correct image.


Vertical / Horizontal correction

When fixing your projector in a place and use Vertical / Horizontal correction. Press the  button to go to projector home menu, select [Settings]->[Projection Settings]->[Keystone Settings]. Please turn off Auto keystone correction and go back to the previous menu. Select [Vertical Correction] / [Horizontal Correction], press left or right button on the remote control to adjust.

Vertical Correction




Horizontal Correction



Corner Correction

If the projected image is stretched or distorted along both axes due to the angle of the projection, press the button  to go to projector home menu, and select [Settings]->[Projection Settings]->[Corner Correction], choose the corner you want and press left or right button on the remote control to adjust.



Keystone Correction Reset

To restore the default settings, press the  button to go to projection settings. Select [Settings]->[Projection Settings]->[Keystone Correction Reset] and press OK.

Zoom In / Out

Press the  button to go to projection settings. Select [Settings] -> [Projection Settings] -> [Zoom In/Out]. Use the remote control to resize the picture size.

Screen Intelligent Obstacle Avoidance

Press the projection shortcut button  to enter the homepage of the projector, go to [Settings]->[Projection Settings]->[Keystone Settings]->[Intelligent Obstacle Avoidance], select the function on/off.

Screen Auto Alignment

Press the projection shortcut button  to enter the homepage of the projector, go to [Settings]->[Projection Settings]->[Keystone Settings]->[Intelligent Screen Alignment], select the function on/off.

6 Projection Settings



Desktop Front Projection



Ceiling Front Projection



Desktop Rear Projection




Ceiling Rear Projection

Press the  button, [Settings]->[Projection Settings]->[Projection Mode], select Desktop Front Projection/Desktop Rear Projection/Ceiling Front Projection/Ceiling Rear Projection.

7 Pair Remote Control


Power on the projector and you will enter Bluetooth remote pairing page. Follow the on-screen instructions to complete the pairing.

- ① Please hold the remote near the projector
- ② Long press  and  together for about 10 seconds.
- ③ When the screen shows "Connected Successfully", your remote LED indicator turns off, and the remote control is paired.



8 Select Your Language

After pairing the remote control, you will be guided to a page to select language, use remote control  or  to select your language. Then press  button to enter the next page.




Android TV Setting

Follow the setup wizard on Android TV, set up a Wi-Fi connection, select the available Wi-Fi and enter the password, sign in to a Google account, and carry out other related procedures. When you complete the Android TV setup wizard, the Android TV home screen will appear. Now you can start watching your favorite shows by downloading streaming apps.

Notice: Due to the requirements of Android TV, using the Android TV requires you to sign in to your Google account. If you have not registered your Google account, please complete the registration before proceeding with use.

Play Through External Sound Devices via Bluetooth

If you want to connect to Bluetooth speakers/headphones on the Android TV interface, select [Settings]->[Remotes & Accessories]->[Add accessory], search for Bluetooth device and click pair.
Note: The Bluetooth connection must be established inside Android TV.



Add New Google Account User

Register a new Google account using Android TV for easier login and payment security. [Settings]->[Accounts & sign-in], add an account or switch accounts.

9 Wireless Connection

Notice: The Chromecast feature only works while you are in the Android TV system.

Cast from Chromecast-enabled Sites/Apps (for Android/iOS devices)


- ① Make sure your device and the Android TV are connected to the same Wi-Fi network, and that you are running the latest version of the Chromecast-enabled app.
- ② Launch the Chromecast-enabled site/app.
- ③ Tap the cast  button and choose the "D1221".

Cast from Chrome Browser tab (for Computers)

- ① Make sure your computer and projector are connected to the same Wi-Fi network
- ② Click "Cast" at the upper right  of the Chrome browser tab, and then choose from the sources whether you want to cast the tab or the screen.
 - Choose "D1221-XXX" to cast.

Mirror from Android Devices

- ① Make sure your Android devices and projector are connected to the same Wi-Fi network.
- ② Download the "Google Home" app on your Android device.
- ③ Open the "Google Home" app, choose "D1221" and tap "Cast my screen".



Mirror from iOS Devices


- ① Make sure your iOS devices and projector are connected to the same Wi-Fi network.
- ② Go to "Google Play Store", search and download "AirScreen" app.



- ③ Open the "AirScreen" app and follow the on-screen instructions on AirScreen.



10 Wired Connections



Play from an HDMI Playback Device

This Poseidon E40 supports connections with various HDMI playback devices, such as PC, DVD player, set-top box (STB), game console or other devices.

- ① Connect this projector to an HDMI playback device with an HDMI cable.
- ② Press the  button on remote control to select [HDMI] and press .

Play from a USB Storage Device

With Poseidon E40, you can enjoy music, video, and pictures, or install apps that are stored on a USB storage device.

Play from the Android TV

- ① Plug in the USB storage device.
- ② Go to "Google Play Store", search and download "File Manager" app.
- ③ Open "File Manager" app and find the USB storage device. Select a file.
- ④ Press  to start playback.

Play from the projector

- ① Plug in the USB storage device.
- ② Press the  button on remote control to select [USB] and press .
- ③ Select a file you plan to play from the file and folder menu.
- ④ Press  to start playback.

Play Through External Sound Devices Via AUX Cable

① Connect one end of the 3.5mm AUX cable to the AUX port on this projector.

② Connect the other end of the 3.5mm AUX cable to the AUX port on headphones or external speakers.

③ Playback on the projector.

Bluetooth Speaker Mode

Press the projection shortcut button  to enter the homepage of the projector, select [Bluetooth Speaker] in the carousel menu, and operate according to the prompts.

11 Shortcut Menu

Press the  button to pop up the shortcut menu.

- Press the navigation button to select the desired option.
- Press  or  button to adjust parameter.
- Press  button to save.

Image Mode	Standard	Keeps natural looking colors with a balance of warm and cool tones
	Light	Provides more picture details and color sharpness
	Soft	Provides warm colors with lower light
	Personal	Manually set the Brightness, contrast, Saturation, Sharpness and Hue
Color Temp	Cold	Provides cold color temp
	Normal	Provides cold normal temp
	Warm	Provides cold warm temp
	Personal	Manually set the Red, Green and Blue
Sound Mode	Standard	Provides standard tones
	Music	Provides more detailed tone
	Movie	Provides home theater-style sound
	Personal	Manually set the sound of each frequency band
Shutdown Timer	Off	Save energy and extend the lifespan of the projector
	10min	
	20min	
	30min	
	60min	
Projection Setting	Zoom In/Out	Zoom in or out of the projection image
	Fast Keystone Correction	Perform keystone correction
	Keystone Correction Reset	Reset keystone correction

12 Companion Mode

Press the power  button to enter the power off option, select Companion Mode, and go to settings.

13 Specifications

OS: Android TV 11.0

Wi-Fi: 2*2 MIMO Wi-Fi 2.4GHz/5GHz 802.11 a/b/g/n/ac

Native Resolution: 1920*1080p

Speaker Drivers: 10W*2

Throw Ratio: 1.23:1

Aspect Ratio: 16:9 / 4:3

Recommended Screen Size : 80" - 120"

Power Consumption: 200W

Power Input: DC 24.0V 8.33A

Modo de imagen	Estándar	Mantiene los colores de aspecto natural con un equilibrio de tonos cálidos y fríos
	Brillante	Proporciona más detalles de imagen y nitidez de color
	Suave	Proporciona colores cálidos con poca luz.
	Usuario	Ajuste manualmente el brillo, el contraste, la saturación, la nitidez y el tono.
Temperatura de color	Frío	Proporciona una temperatura de color fría
	Normal	Proporciona temperatura normal
	Cálido	Proporciona temperatura caliente
	Usuario	Ajuste manualmente Rojo, Verde y Azul
Modo de sonido	Estándar	Proporciona tonos estándar
	Música	Proporciona un tono más detallado
	Película	Proporciona un sonido estilo cine en casa
	Usuario	Ajuste manualmente el sonido de cada banda de frecuencia
Temporizador	Desactivar	Ahorre energía y prolongue la vida útil del proyector.
	10min	
	20min	
	30min	
	60min	
Corrección trapezoidal	Ampliación de la imagen	Acercar o alejar la imagen proyectada
	Corrección trapezoidal rápida	Realizar corrección trapezoidal
	Restablecer la corrección trapezoidal	Restablecer corrección trapezoidal

12 Función de pantalla de espera

Presiona el botón  del control remoto para acceder a Modo de Compañía, y haga los ajustes necesarios.

13 Especificaciones

Sistema: Android TV 11.0

WIFI: 2*2 MIMO Wi-Fi 2.4GHz/5 GHz 802.11 a/b/g/n/ac

Resolución física: 1920*1080p

Potencia de los altavoces: 10W*2

Relación de proyección: 1.23:1

Relación de aspecto: 16:9 / 4:3

Tamaño de proyección recomendado: 80" - 120"

Consumo de energía: 200W

Entrada de energía: DC 24.0V 8.33A

ISED WARNINGS

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s).

Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) L'appareil ne doit pas produire de brouillage;
- (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Le présent appareil est conforme. Après examen de ce matériel aux conformités ou aux limites d'intensité de champ RF, les utilisateurs peuvent, sur l'exposition aux radiofréquences et conformité d'acquiescer les informations correspondantes. La distance minimale du corps à utiliser le dispositif est de 20cm.

FCC STATEMENT:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator&your body.

WARNING

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and use in accordance with the instructions, may cause harmful interference to radio communications.

However there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Declaration of Conformity

We (Manufacturer is responsible for this declaration) Dynanic (Shenzhen) Technology Limited 20th Floor, Building 4, Tianan Cloud Park, Bantian St., Longgang District, Shenzhen, China

Declare under our sole responsibility that the product

Trade name: ULTIMEA

Equipment: Projector

Model No.: U0340

To which this declaration relates is in conformity with the essential requirement set out in the Council Directive on the Approximation of the laws of the Member

States relating to LVD Directive (2014/53/EU) & RoHS (2011/65/EU) product is responsible to affix CE marking, the following standards were applied:

EN IEC 62311:2020	IEC 62321-3-1:2013
ETSI EN 301 489-1	IEC 62321-5:2013
V2.2.3(2019-11)ETSI EN 301 489-17	IEC 62321-4:2013+AMD1:2017
V3.2.4(2020-09)EN 55032:2015	IEC 62321-6:2015
EN 55035:2017	IEC 62321-7-2:2017
EN 61000-3-2:2019	IEC 62321-6:2015
EN 61000-3-3:2013+A1:2019	IEC 62321-8:2017

Signature:

Date: 2

yogo yu

ULTIMEA

Poseidon E40 Smart Projector
Model No.: U0340



Dynanic GmbH
Buchenring 57, 22359 Hamburg, Germany



UK Crossborder limited
7 Bell Yard London WC2A 2JR, UK United Kingdom

Made in China

Manufacturer: Dynanic (Shenzhen) Technology Limited

Address: 20th Floor, Building 4, Tianan Cloud Park, Bantian St.,
Longgang District, Shenzhen, China 518000



If you need our support, kindly reach out to our service team. We are always glad to help.
Bei Bedarf an unserem Kundenservice können Sie sich auf unsere freundliche und zuverlässige Unterstützung verlassen.

+1 888-598-8875 (US)
Mon-Fri 9am-5pm (PST)
+49 89-628-25828 (EU)
Mon-Fri 9am-5pm (CET)
support@ultimea.com

support.ultimea.com



@ultimea_official