

NEVO
SCENT
DIFFUSER

USER MANUAL

DECOR COLLECTION

AromaPlan

READ ALL INSTRUCTIONS BEFORE USING THE DIFFUSER

POWERFUL, SAFE AND EASY TO USE

FC CE RoHS NEVO SCENT DIFFUSER



NEVO SCENT DIFFUSER

DECOR COLLECTION

Product Introduction

The NEVO Scent Diffuser, from AromaPlan's exclusive DECOR Collection, is a premium tabletop fragrance diffuser designed to deliver a sophisticated and perfectly balanced scenting experience for small and medium-sized spaces.

Featuring an elegant, sculptural silhouette available in a curated palette of refined colors, it naturally blends into the most diverse styles of residential or commercial environments, effortlessly combining contemporary luxury with decorative appeal.

Driven by advanced quiet-operation technology, the device ensures high-quality, seamless fragrance dispersion without disturbance, while a subtle, built-in seven-color ambient light at the base enhances the atmosphere.

The NEVO Scent Diffuser is the ultimate choice for those seeking to transform intimate and modern spaces into a comfortable, inviting, and memorable sensory experience.



Coverage
up to 2,000 sq ft



Controlled by the
AromaPlan app



Heatless and waterless
atomization technology




Easily adjust fragrance
intensity and schedules

AromaPlan

Specifications

SIZE	Ø80*250(mm)
CAPACITY	5 fl oz - 150mL
N.W.	0,48kg
COVERAGE	Up to 2,000 SQ FT
INPUT	5V - 1A
POWER	2.5W


Accessories



POWER ADAPTER




PRODUCT MANUAL



ATOMIZER HEAD



FLAT WASHER



3 Colors to Match Your Style

A CURATED PALETTE FOR DIVERSE INTERIORS

OFF-WHITE




VANILLA



MOCHA




GRAY



BLACK



How to refill the fragrance oil



A. Press down the atomization head ①, lift the it until the fragrance oil bottle pops up, then remove the bottle. ②

B. Hold the fragrance oil bottle, rotate it counterclockwise to separate it from the atomization head, then fill it with fragrance oil (*max 150ml*). ③

C. Tighten the fragrance oil bottle (filled with oil) and rotate Atomization head clockwise. ④

D. Insert the fragrance oil bottle and atomization head into the machine main body, then press down to secure. ⑤

E. Plug in the power supply, plug in the power supply, and your device is ready to use. ⑥

Special Instructions for Fragrance Oil Use

The NEVO Scent Diffuser uses advanced cold-air diffusion technology to disperse fragrance oil effectively. For optimal performance, always use the fragrance oil as provided in its original packaging. Do not dilute the fragrance oil with water, alcohol, solvents, or any other liquids, as this may affect the diffuser's performance and internal components.

The diffuser bottle has a maximum capacity of 5 fl oz (150 mL). Please respect the maximum fill level to ensure proper operation and consistent fragrance performance. For best results, use fragrance oils designed for cold-air diffusion systems.


Precautions for use



Control Instructions

Operation Instructions:

- After plugging in the power cord, the machine will automatically adjust to the default: 30 seconds work time, 60 seconds pause time. During operation, the indicator light turns white.
- You can connect to the AromaPlan App to adjust the schedule, intensity level, and LED color.



Instructions



Important Notes:

1. This device is compatible with Bluetooth-enabled devices. Please make sure the Bluetooth function on your phone is turned **ON** before use.




Where to download the AromaPlan App:

Scan the QR Code to download the app on your phone.
Available on the **App Store** and **Play Store**.



Attention: Your NEVO Scent Diffuser can only be set up through the AromaPlan app.

Step-by-Step Setup Guide



1. LOGIN OR CREATE AN ACCOUNT

Before configuring your diffuser or making purchases, you need to Log in or create an account. You can log in quickly using your Google or Apple ID, or fill out a short registration form to create a new AromaPlan account.

2. GETTING STARTED

After downloading the AromaPlan App, tap the icon to launch it. On the Home screen, you'll find product categories and featured selections. At the bottom navigation bar, you'll see our main menu:



Home – browse through the latest news and promotions.

Shop– shop our products.

Cart – review and complete your purchases.

My Diffusers – add, manage, and control your devices.

My AromaPlan – access your account, quick links, and support resources.



3. ADD A NEW DIFFUSER

Go to "My Diffusers" to access the device setup area.


Make sure your bluetooth mode is turned ON to connect to nearby AromaPlan devices.

4. CONNECT TO YOUR DEVICE

Once bluetooth mode is active, the app will automatically scan for available diffusers.


Select the device you wish to set up from the list.






5. SELECT YOUR MODEL

Choose the model of your AromaPlan diffuser (usually identified by its color or design).



6. SELECT LOCATION


Specify where your diffuser will be installed: Home or Business.



7. DEVICE SETTINGS

After adding your new diffuser, it will appear with your other registered devices.

Tap on a diffuser to open its settings and manage advanced configurations.




8. SCHEDULE

You can set up:

- Specific operating hours
- Active days of the week
- Intensity levels

This allows your diffuser to run automatically according to your preferences.





9. INTENSITY SETTINGS

Diffusion intensity is determined by two parameters:

- Work Time – how long the diffuser releases fragrance
 - Pause Time – how long it rests before diffusing again
- Adjust both to achieve your ideal scent level.

10. SCHEDULE FLEXIBILITY

Each diffuser supports up to five schedules. You can edit or delete any schedule at any time.




11. SHOP AROMAPLAN PRODUCTS

Visit the Shop tab to explore our product catalog. Add items to your Cart, Log in or create an account, and complete your purchase directly through the app.

12. MY AROMAPLAN

This section provides quick access to:

- Your account settings
- Product collections
- FAQ and tutorial videos
- Links to our social media channels



Troubleshooting

Before attempting to repair the device, follow the following instructions:

ISSUE	SOLUTION
NO MIST / DEVICE NOT WORKING	1- Check if the device is turned on. 2- Check if the power adapter is a DC 5V-1A power supply, and if the power terminal or outlet is properly plugged in and providing power. 3- Make sure the programmed operating schedule is active; confirm if it is currently in the working time period. 4- Check if there is airflow at the mist outlet and if the air tube is firm and well connected. 5- The air pump may be damaged (<i>contact support for assistance</i>).
WEAK DIFFUSION	1- The atomizer core may be clogged (<i>clean with isopropyl alcohol or contact support for assistance</i>). 2- Check if the atomizing core or oil suction tube is loose or blocked. 3- Check if the sealing ring is damaged, loose, or detached. 4- The air tube may be loose.
OIL SPLASHING	1- The atomizer head may be damaged (<i>contact support for assistance</i>). 2- The device may be tilted or lying down, always keep it in a vertical position (<i>do not invert or tilt the device during use</i>).
OIL LEAKAGE	1- Check if the fragrance oil bottle and atomizer are tightened (<i>the bottle cap may not be properly screwed on</i>). 2- Check if the atomizer sealing ring/gasket is damaged, or out of position. 3- Check if the atomizer head is damaged.
UNUSUAL NOISE	1- The air pump may be loose (<i>check the fit, re-fix it securely and tighten if necessary</i>). 2- If the noise persists or the air pump is damaged (<i>contact support for assistance</i>).

Equipment Cleaning & Maintenance

Clean the device monthly for preventive maintenance, or when:

- Changing to a different fragrance oil.
- Atomization intensity becomes weak.

Standard Cleaning (Routine)

1. Remove the used essential oil bottle.
2. After cleaning, pour a small amount of Isopropyl alcohol into the bottle, install it back on the device.
3. Run the diffuser for 5 to 10 minutes on maximum intensity to clear the internal system.
4. Allow the components to air-dry before adding new fragrance oil.

Note: This diffuser is designed for pure fragrance oil only; do not add water.

Safety Precautions



WARNING

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, property damage, and personal injury.

- To avoid risk of fire or electric shock, connect the appliance directly to a secure electrical outlet. DO NOT connect the cord with wet hands.
- Keep the cord away from high-traffic areas.
- DO NOT operate any appliance with a damaged cord or plug, after the appliance malfunctions, or if it has been dropped or damaged in any way.
- DO NOT use the diffuser in high-temperature or humid environments.
- DO NOT allow the mist to hit the wall directly. Install the diffuser in a ventilated and suitable space.
- NEVER place the diffuser in an area accessible to children.
- NEVER tilt, move, or attempt to empty the appliance during operation.
- DO NOT block the air outlet while the appliance is running.
- Always place the diffuser on a firm, and flat surface. NEVER place it on a rug or carpet, or on a finished floor that could be damaged by exposure to water or moisture.
- DO NOT use flammable, explosive, corrosive, or other dangerous solvents with the diffuser. DO NOT spill water or corrosive liquid on the diffuser's surface.
- Turn off the appliance during extreme weather conditions.
- The appliance should only be used with the power cord provided with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.



ATTENTION

This diffuser must be used only with fragrance oil, without the addition of water. For the best performance of your device, we recommend the exclusive use of AromaPlan fragrance oils.

Customer Service

If you have any questions, need assistance, or wish to report a technical issue, our support team is ready to help.

Email: ***support@aromaplan.com***

Warranty

1. This product carries a 6-month limited warranty from the date of purchase. An original proof of purchase is required to validate the warranty.

2. The warranty covers manufacturing defects only.

The warranty does not cover:

- Damage caused by drops or physical impacts.
- Leaks or spills resulting from improper use of the device.
- Misuse or negligent handling of the equipment.
- Unauthorized repair attempts.
- Any use that does not comply with the user manual instructions.

FCC WARNING:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an power outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20cm between the radiator & your body.



DOWNLOAD THE
INSTALLATION MANUAL
FOR YOUR DIFFUSER BY
SCANNING THE QR CODE

IC WARNING

ISED Statement

English: This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

The digital apparatus complies with Canadian CAN ICES-3 (B)/NMB-3(B).

French: Cet appareil contient des émetteurs/récepteurs exempts de licence qui sont conformes aux RSS exemptés de licence d'Innovation, Sciences et Développement économique Canada. L'exploitation est soumise aux deux conditions suivantes:

- (1) Cet appareil ne doit pas provoquer d'interférences.
- (2) Cet appareil doit accepter toute interférence, y compris les interférences susceptibles de provoquer un fonctionnement indésirable de l'appareil.

L'appareil numérique du ciem conforme canadien peut - 3 (b) / nmb - 3 (b). This device meets the exemption from the routine evaluation limits in section 6.3 of RSS 102 and compliance with RSS 102 RF exposure, users can obtain Canadian information on RF exposure and compliance. Cet appareil est conforme à l'exemption des limites d'évaluation courante dans la section 6.3 du cnr - 102 et conformité avec rss 102 de l'exposition aux rf, les utilisateurs peuvent obtenir des données canadiennes sur l'exposition aux champs rf et la conformité.

This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment.

Cet équipement est conforme aux limites d'exposition aux rayonnements du Canada établies pour un environnement non contrôlé.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Cet équipement doit être installé et utilisé à une distance minimale de 20 cm entre le radiateur et votre corps.

AROMAPLAN UNITED STATES
DISTRIBUTED BY FULLYSENSE LLC

CONTACT US AT:

E-mail: support@aromaplan.com
Phone: +1 (407) 233-4143



FullySense
GROUP