

Remote Control A136RF616B0001 Manual

How to use the IR Programming

The operation steps of infrared programming are as follows:

(take learning the power button on the infrared remote control as an example)

1. Press and hold the 【power 】 button of this product for 3 seconds. When the indicator light flashes slowly, prompt to enter the IR programming mode.
2. Position this product and your TV remote head-to-head on a flat surface with 1 inch apart, press the 【power 】 button of your IR remote control, then The indicator light will go out after flashing, indicating that the infrared programming is completed.
3. There are two buttons 【power 】 and 【mute 】 can be used infrared programmed for this product, and the programming operation can refer to steps 1-2.

红外编程使用方法

红外编程的操作步骤如下：

（以学习红外遥控器的电源键为例）

1. 长按本产品的【电源 】键 3 秒。当指示灯缓慢闪烁时，提示进入红外编程模式。
2. 将本产品与您的电视遥控器在平面上面对面放置，间距 1 英寸，按下您红外遥控器的【电源 】键，然后指示灯闪烁后熄灭，表明红外编程完成。
3. 本产品有【电源 】和【静音 】两个按键可进行红外编程，编程操作可参考步骤 1-2。

Press and hold the **【Power 】** + **【Del 】** buttons for 5 seconds, The indicator light flashes to prompt restore to the factory settings.

长按 **【电源 】** + **【删除 】** 键 5 秒，指示灯闪烁提示恢复出厂设置。

How to Change the Cursor Speed

Please hold **【OK 】** button and then click **【Volume- 】**, You will get a slower speed successfully when the LED light changes from blink to solid.

Please hold **【OK 】** button and then click **【Volume+ 】**, You will get a faster speed successfully when the LED light changes from blink to solid.

如何调整光标速度

请按住 **【OK】** 键，然后点击 **【Volume- 】**，当 LED 灯从闪烁变为常亮时，您将成功获得更慢的速度。

请按住 **【OK】** 键，然后点击 **【Volume+ 】**，当 LED 灯从闪烁变为常亮时，您将成功获得更快的速度。

Backlight function

After the battery is installed, the backlight function is automatically turned on.

Long press the **【Menu 】** button to turn off/on the backlight.

The duration of backlight after activation is 5s, and it needs to be activated again after 5s. Press any key can activation the backlight.

背光功能

安装电池后，背光功能自动开启。

长按 **【Menu 】** 键可关闭 / 开启背光。

背光激活后的持续时间为 5 秒，5 秒后需再次激活。按任意键可激活背光。

Low battery reminder:

The red light flashes slowly when the AAA battery power of the product is lower than 2V. It means that the battery need to be replaced at this time.

低电量提醒:

当本产品的 AAA 电池电量低于 2V 时, 红灯缓慢闪烁。这意味着此时需要更换电池。

Sensor Calibration:

Automatic calibration:

when the device works, the cursor may drift due to changes in voltage and temperature. Please place the device on flat desktop and keep it still. After the device turns into quiescent mode, wake up again to complete calibration.

传感器校准:

自动校准:

设备工作时, 光标可能因电压和温度变化而漂移。请将设备放在平坦的桌面并保持静止。设备进入静止模式后, 再次唤醒以完成校准。

Manual calibration:

press and hold the **【OK^{OK}】** button and install the battery at the same time. After the green LED light turns from flashing to normally on, place the product flat on the desktop and wait for the indicator to turn to flashing, then complete the manual calibration.

手动校准:

同时按住**【确认^{OK}】**键并安装电池。当绿色 LED 灯从闪烁变为常亮后, 将产品平放在桌面, 等待指示灯变为闪烁, 即可完成手动校准。

How to Use

For initial use, plug a USB receiver into the USB port of device and wait for 20-60 seconds to install driver of USB receiver. Move the mouse, the mouse cursor can move on the screen means that pairing is successful.

If it is unsuccessful, press and hold **【OK 】** and **【BACK 】** buttons, LED light begin to flash. Pairing is successful when LED light stop flashing.

使用方法

初次使用时，将 USB 接收器插入设备的 USB 端口，等待 20-60 秒以安装 USB 接收器的驱动程序。移动鼠标，屏幕上的鼠标光标可以移动，说明配对成功。

如果配对不成功，长按**【确认 】**和**【返回 】**键，LED 灯开始闪烁。当 LED 灯停止闪烁时，配对成功。

Note:

1). Air mouse functions:

Some multi-media device maybe is not available for air mouse, so if the key **【OK】** doesn't work during device working, please end close air mouse pointer and try again.

2). Infrared transmission program:

2 keys of infrared program can be available for many popular television, voice devices and A/V receiver, but it is not suitable for all kinds of brands and items. As some remote control cannot be infrared programmed due to Bluetooth or wireless radio frequency technology. Or as the infrared remote control may use an unusual/unique infrared code number, in this case, we cannot program successfully.

3). Battery power:

Please make sure that the battery is sufficiently charged. When the battery is low, the brightness of the backlit and the stability of the air mouse cursor will be affected.

4). Space under work

The actual space of this device will be affected by the electronic magnetic field. Please make sure that there is no electromagnetic interference in the working space.

注意事项:

1). 空中鼠标功能: 部分多媒体设备可能不支持空中鼠标功能, 因此如果设备工作时**【确认】**键不起作用, 请结束并关闭空中鼠标指针后重试。

2). 红外传输编程: 红外编程的 2 个按键可适用于许多流行的电视、语音设备和音视频接收器, 但并不适用于所有品牌和型号。由于蓝牙或无线射频技术, 某些遥控器无法进行红外编程。或者由于红外遥控器可能使用了不常见 / 独特的红外编码, 在这种情况下, 我们无法成功编程。

3). 电池电量: 请确保电池电量充足。当电池电量低时, 背光亮度和空中鼠标光标的稳定性会受到影响。

4). 工作空间该设备的实际使用范围会受到电磁场的影响。请确保工作空间内无电磁干扰。

Description of BT pairing and deleting pairing information.

1. Before using this device, first you must turn on the BT function of the main device.
2. Then long press "OK" + "Return" keys, when the LED turns to flash quickly, the product enters the pre pairing.
3. Click "add search new devices" on the main device to find this air remote's name (Example: G20S PRO), Click the name can to connecting.
4. After the product is successfully connected, the direction of the mouse pointer can be controlled by waving in the air.
5. If the connection is not successful, please perform the operation steps of item 2-4 again.
6. Reconnect efficiency description: The normal reconnect time of this product is 3-5 seconds after it is normally paired with the main equipment.
7. This product can only remember the pairing information of one main device. when the product is connected to a new device, the connection of historical devices is not supported after.
8. in this case, you need to delete the historical connection information of this peripheral can be successfully matched for new search.

蓝牙配对与删除配对信息说明

1. 使用本设备前，首先必须开启主设备的蓝牙功能。
2. 然后长按 “确认” + “返回” 键，当 LED 灯快速闪烁时，产品进入预配对状态。
3. 在主设备上点击 “添加搜索新设备”，找到该空中遥控器的名称（例如：G20S PRO），点击该名称即可进行连接。
4. 产品成功连接后，可通过在空中挥动来控制鼠标指针的方向。
5. 如果连接不成功，请再次执行第 2-4 项的操作步骤。
6. 重连效率说明：本产品与主设备正常配对后，正常重连时间为 3-5 秒。
7. 本产品只能记住一个主设备的配对信息。当产品连接到新设备后，不再支持与历史设备的连接。
8. 在这种情况下，您需要删除该外设的历史连接信息，才能成功匹配新的搜索。

FCC Warning

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:-- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

*** RF warning for Portable device:**

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.