




Wireless Weight-Sensing Pet Fountain 1.0

PS-PRO-120 V2.0



COMFORT • FUTURE

CONTENTS


English	01-06
简体中文	07-12
繁體中文	13-18
日本語	19-24
Deutsch	25-30
Français	31-36
Italiano	37-42
Español	43-48

01 SAFETY INSTRUCTIONS


- Follow the manual for correct installation and usage.
- Not recommended for pets under three months old.
- For indoor use only. Avoid exposure to direct sunlight and open flames.
- Use the provided power adapter only to avoid safety risks.
- Place on a flat surface to prevent tipping or leakage.
- Do not wash the base of the water dispenser.
- Avoid impacting the pump body during cleaning to prevent damage to the ceramic shaft.
- Pets chewing on the power cable may cause electric leakage; secure and hide the cables.
- Unplug the device if not in use for an extended period.
- Children should use the device under adult supervision.
- Repairs should be performed by a professional technician.
- Before long trips, ensure the water tank is adequately filled.
- For any malfunctions, please contact after-sales service.

02 ASSEMBLY INSTRUCTIONS



2.1 Component Names & Diagrams



- | | | |
|-----------------------------------|------------------------------------|------------------------------|
| 1 Drinking Bowl | 2 Primary Filter | 3 Primary Filter Bracket |
| 4 Silicone Seal for Filter Outlet | 5 High-Efficiency Composite Filter | 6 Wireless Water Pump |
| 7 Water Tank | 8 Thermal Plate for Water Tank | 9 Heating Plate for the Base |
| 10 Base of the Water Dispenser | 11 Gravity Sensor | |



- ① Heating Switch ② Heating Indicator Light ③ Water Mode Toggle Button
- ④ Function Indicator Ring ⑤ Filter Reset Button ⑥ Filter Life Indicator Light



- ① Power Switch ② Network Configuration Button ③ Weight Sensor Bracket x4
- ④ Charging Port

2.2 Other Accessories

- (1) User Manual
- (2) Power Adapter
- (3) Certificate of Quality
- (4) Quick Start Guide

03 PRODUCT OVERVIEW

3.1 Button Descriptions

Water Mode Toggle Button: Short press to switch to Fountain Mode (active only when plugged in) or Smart Mode.

Heating Switch: Long press for 3 seconds to toggle the heating function (active only when plugged in).

Filter Reset Button: Long press for 3 seconds to reset the filter's lifespan.

Network Configuration Button: Long press for 5 seconds to reset the network connection.

Power Switch: Toggle left or right to turn the device on or off.

3.2 Indicator Light Descriptions

Water Mode Indicator Light: White light (Fountain Mode)

Green light (Smart Mode)

White/Green Flashing — Charging (active only when plugged in)

White/Green Solid — Fully Charged (active only when plugged in)

Red light (Low Water Warning)

Flashing Red (Low Battery)

Filter Life Reset Light: White light (0-80% filter life used),

Yellow light (80-99% filter life used),

Red light (Filter life expired).

Heating Light: White light (Heating on),

Light off (Heating off).

WiFi Indicator Light: White light (Network connected),

Flashing White (Connecting to network).

04 KEY FEATURES AND BENEFITS

① Weight Sensor:

Tracks your pet's daily water intake, with data displayed on the app down to the milliliter. It also monitors remaining water levels, providing real-time updates on your smartphone.

② Heating:

Conductive heating for safer and quicker operation than traditional heaters, with built-in safeguards against electrical leakage.

③ Multiple Water Dispensing Modes:

Fountain Mode for continuous flow (when plugged in) and Smart Mode that automatically dispenses water upon detecting your pet's approach, suitable for both plugged-in and battery modes.

④ Advanced Filtration:

Primary Filter: Filters larger debris, hair, and particles.

High-Efficiency Filter: Removes impurities, oils, heavy metals, and bacteria, while softening water and improving taste.

⑤ Wireless Water Pump:

Minimizes the risk of electrical leakage and includes dry-run protection.

⑥ Large Capacity Water Tank:

4.0 lb capacity to ensure your pet has enough water daily.

05 TECHNICAL SPECIFICATIONS

Rated Voltage	24V  2A
Rated Power	40 W
Dimensions (L x W x H)	11.2 x 6.7 x 7.0 in
Net Weight	4.0 lb
Capacity	95 fl oz
Battery Capacity	5200 mAh
Material	Food-Grade ABS
Connection	WiFi
Suitable for	Cats and small dogs
Operating Environment	40°F - 104°F

06 INSTALLATION INSTRUCTIONS

Follow the Quick Start Guide for step-by-step assembly.

Network Configuration & App Connection:

Long press the network button for 5 seconds, download and install the PetSnowy app, then follow the instructions to add the water dispenser.

07 DAILY MAINTENANCE AND CARE

Regular Cleaning & Disinfection: Clean the water tank weekly, and perform a thorough cleaning of all parts monthly.

Filter Replacement: Replace the primary filter every two weeks and the high-efficiency filter every eight weeks. After changing the high-efficiency filter, press the reset button to reset the filter life.

08 AFTER-SALES & WARRANTY INFORMATION

After-sales service policies may vary depending on local laws and regulations.

Please contact the point of purchase or authorized after-sales service center for assistance.

01 安全须知

按说明书正确安装使用

不建议三个月龄以下宠物使用

本产品仅限室内使用,避免阳光直射与明火

使用原装适配器,避免安全风险

放置于水平地面,防止倾倒或漏水

禁止冲洗饮水机底座

日常清洁勿撞击泵体,防止损坏内部陶瓷轴

宠物啃咬电源线可能引发漏电,请固定隐藏电线

如长期不使用,请拔掉电源

儿童使用需在成人指导下进行


产品维修应由专业人员操作

长时间外出前,请确保水箱注水充足


如遇故障,请联系售后客服

02 组装说明

2.1 各部件名称及示意图



- | | | |
|-------------|----------|------------|
| 1 饮水盆 | 2 初级滤芯 | 3 初级滤芯支架 |
| 4 滤芯出口硅胶密封件 | 5 高效复合滤芯 | 6 无线水泵 |
| 7 储水箱 | 8 储水箱导热盘 | 9 饮水机底座加热盘 |
| 10 饮水机底座 | 11 重力传感器 | |



① 加热开关


② 加热指示灯

③ 出水模式切换按键

④ 功能指示灯环

⑤ 滤芯重置按键

⑥ 滤芯寿命指示灯



① 开关

② 配网按键

③ 称重感应支架*4

④ 充电接口

⑤ 配网按键

③ 称重感应支架*4

2.2 其他配件清单

- (1) 说明书
- (2) 电源适配器
- (3) 合格证
- (4) 快速指南

03 产品概述

3.1 按键说明

出水模式切换按键:短按切换连续涌泉模式(仅充电时有效)/智能模式

加热开关键:长按3秒开关加热功能(仅充电时有效)

滤芯重置键:长按3秒重置滤芯寿命

配网按键:长按5秒重置网络

拨动开关键:左右拨动开机/关机

3.2 指示灯说明

出水模式灯:白灯长亮 - 涌泉模式

绿灯长亮 - 智能模式

白灯/绿灯闪烁-充电中(仅充电时有效)

白灯/绿灯长亮-充满电(仅充电时有效)

红灯长亮 - 缺水提示

红灯闪烁 - 低电量提示

滤芯寿命重置灯:白灯长亮 - 已用0-80%寿命

黄灯长亮 - 已用80-99%寿命

红灯长亮 - 滤芯寿命到期

加热指示灯:白灯常亮 - 加热开启

白灯熄灭 - 加热关闭

WiFi提示灯:白灯长亮 - 已配网

白灯闪烁 - 正在配网

04 主要功能与特点

① 称重感应:

记入宠物每天的饮水量,精确到每毫升,通过APP展示。检测饮水机的剩余水量,实时显示于手机APP。

② 加热：

传导式加热，更加安全且避免漏电，较传统加热器更方便快捷。

③ 多样化出水模式：

涌泉模式——插电使用，持续出水；智能模式——自动感应宠物接近后出水，适用于插电和电池模式。

④ 滤芯：

初效滤芯——过滤较大的悬浮物、浮毛和碎屑；高效滤芯——细致过滤水中的杂质、油脂，软化水质，去除重金属，抑菌，改善口感。

⑤ 无线水泵：

减少漏电风险，具备防干烧断电保护。

⑥ 大容量蓄水箱：

2.8升容量，保证宠物每天足够的饮水量。

05 技术规格

额定电压	24V --- 2A
额定功率	40 W
尺寸(长×宽×高)	28.4 × 17.1 × 17.8 cm
产品净重	1.8 kg
容量	2.8 L
电池容量	5200 mAh
材质	食用级ABS
连接方式	WiFi
适用对象	猫和小型犬类
适用环境	4-40°C

06 安装说明

参考快速指南进行图片安装

配网及APP连接：

长按配网按键5秒，下载并安装糯雪宠物APP，按指示添加饮水机。

07 日常维护与保养

定期清洗与消毒:建议每周清洗一次水箱,每月彻底清洁所有部件。

滤芯更换:初效滤芯建议两周更换一次,高效滤芯每8周更换一次。

更换高效滤芯后,按滤芯重置键重置滤芯寿命。

08 售后与保修信息

售后服务政策可能因当地法律法规而异。

请联系购买点或授权售后服务提供商。

01 安全須知

請依照說明書正確安裝與使用。

不建議三個月齡以下的寵物使用。

本產品僅限室內使用，避免直接陽光曝曬及明火。

僅使用原裝適配器以避免安全風險。

請放置於平穩的地面上，避免傾斜或漏水。

請勿清洗飲水機底座。

日常清潔時，請避免撞擊泵體，以防損壞內部陶瓷軸。

寵物咬食電源線可能會引發漏電，請將電線固定並隱藏。

如長時間不使用，請拔除電源插頭。

兒童使用本產品時，必須在成人指導下進行。


產品維修請由專業技術人員進行。

長時間外出前，請確保水箱內水位足夠。

如遇故障，請聯繫售後客服。

02 組裝說明

2.1 各部件名稱及示意圖



① 飲水盆

② 初效濾芯

③ 初效濾芯支架

④ 濾芯出口硅膠密封件

⑤ 高效濾芯

⑥ 無線水泵


⑦ 儲水箱

⑧ 儲水箱導熱盤

⑨ 飲水機底座加熱盤

⑩ 飲水機底座

⑪ 重力傳感器



❶ 加熱開關



❷ 加熱指示燈

❸ 出水模式切換按鈕

❹ 功能指示燈環

❺ 濾芯重置按鈕

❻ 濾芯壽命指示燈



❶ 開關

❷ 配網按鈕

❸ 称重感應支架*4

❹ 充電接口

2.2 其他配件清單

- (1) 說明書
- (2) 電源適配器
- (3) 合格證
- (4) 快速指南

03 產品概述

3.1 按鍵說明

出水模式切換按鈕：短按切換涌泉模式（僅在充電模式下有效）/智能模式

加熱開關：長按3秒啟動加熱功能（僅在充電模式下有效）

濾芯重置按鈕：長按3秒重置濾芯壽命

配網按鈕：長按5秒重置網路

開關：左右擺動開機/關機

3.2 指示燈說明

出水模式燈：白燈長亮—涌泉模式

綠燈長亮—智能模式

白燈/綠燈閃爍 — 充電中（僅在充電模式下有效）

白燈/綠燈長亮 — 充滿電（僅在充電模式下有效）

紅燈長亮—缺水提示

紅燈閃爍—低電量提示

濾芯壽命重置燈：白燈長亮—已用0-80%壽命

黃燈長亮—已用80-99%壽命

紅燈長亮—濾芯壽命到期

加熱指示燈：白燈常亮—加熱開啟

白燈熄滅—加熱關閉

Wi-Fi提示燈：白燈長亮—已配網

白燈閃爍—正在配網

04 主要功能與特點

① 稱重感應：

記錄寵物每天的飲水量，精確到每毫升，並通過APP展示。實時顯示飲水機的剩餘水量。

② 加熱功能：

傳導式加熱，提供更安全的使用體驗，避免漏電，並比傳統加熱器更快捷高效。

③ 多樣化出水模式：

涌泉模式：僅在插電時使用，提供持續的水流；智能模式：自動感應寵物接近後出水，適用於插電或電池模式。

④ 濾芯：

初效濾芯：過濾較大顆粒、浮毛與碎屑；高效濾芯：細緻過濾水中的雜質、油脂，軟化水質，去除重金屬，抑菌並改善水的口感。

⑤ 無線水泵：

減少漏電風險，具備防乾燒斷電保護。

⑥ 大容量水箱：

2.8L容量，確保寵物每天有足夠的水源。

05 技術規格

額定電壓	24V === 2A
額定功率	40 W
尺寸(長×寬×高)	28.4 × 17.1 × 17.8 cm
產品淨重	1.8 kg
容量	2.8 L
電池容量	5200 mAh
材質	食品級ABS
連接方式	WiFi
適用對象	貓及小型犬
適用環境	4-40°C

06 安裝說明

參考快速指南進行安裝。

配網及APP連接：

長按配網按鈕5秒，下載並安裝糯雪寵物APP，根據指示添加飲水機。

07 日常維護與保養

定期清潔與消毒：建議每週清潔一次水箱，每月徹底清潔所有部件。

濾芯更換：初效濾芯建議每兩週更換一次，高效濾芯每8週更換一次。

更換高效濾芯後，請重置濾芯壽命。

08 售後與保修信息

售後服務政策可能因當地法律法規而異。

請聯繫購買點或授權售後服務中心。

01 安全に関する注意事項

取扱説明書に従って正しく設置し、使用してください。

3ヶ月未満のペットには使用を避けてください。

本製品は室内専用です。直射日光や火気を避けてください。

安全リスクを避けるため、付属の専用アダプターを使用してください。

倒れや水漏れを防ぐため、平らな場所に設置してください。

本体の底面を洗わないでください。

清掃時はポンプ部分に衝撃を与えないようにし、内部のセラミックシャフトの損傷を防いでください。

ペットが電源コードをかじると漏電の原因になりますので、コードはしっかりと固定して隠してください。

長期間使用しない場合は電源を抜いてください。

子供が使用する際は、大人の監督のもとで使用してください。


製品の修理は専門の技術者によって行われるべきです。

長期間外出する前に、水槽に十分な水を入れておいてください。

故障が発生した場合は、アフターサービスにご連絡ください。

02 組み立ての手順

2.1 部品名および図示



① 飲水ボウル

② 初期フィルター

③ 初期フィルターブラケット

④ フィルター出口シリコンシール

⑤ 高効率複合フィルター

⑥ ワイヤレスウォーターポンプ


⑦ 水槽

⑧ 水槽熱伝導プレート



⑨ 加熱プレート（底座）

⑩ 底座

⑪ 重力センサー



- ① 加熱スイッチ
- ② 加熱インジケータ
ーライト
- ③ 水モード切り替えボタン
- ④ 機能インジケータ
ーリング
- ⑤ フィルターリセット
ボタン
- ⑥ フィルター寿命インジ
ケーターライト



- ① 電源スイッチ
- ② ネットワーク設定
ボタン
- ③ 体重センサープラケ
ット×4
- ④ 充電ポート

2.2 その他の付属品

- (1) 取扱説明書
- (2) 電源アダプター
- (3) 合格证
- (4) クイックスタートガイド

03 製品概要

3.1 ボタン説明

水モード切り替えボタン：短押しで噴水モード（充電時のみ有効）またはスマートモードに切り替えます。

加熱スイッチ：長押しで加熱機能をオン／オフ（充電時のみ有効）。

フィルターリセットボタン：長押しでフィルターの寿命をリセット。

ネットワーク設定ボタン：長押しでネットワークのリセット。

電源スイッチ：左右に切り替えて電源のオン／オフを行います。

3.2 インジケータライト説明

水モードインジケータライト：白色点灯（噴水モード）

緑色点灯（スマートモード）

白/緑ランプ点滅 — 充電中（給電時のみ有効）

白/緑ランプ点灯 — 充電完了（給電時のみ有効）

赤色点灯（給水不足）

赤色点滅（低電量警告）

フィルター寿命リセットライト：白色点灯（0-80%のフィルター寿命使用）

黄色点灯（80-99%のフィルター寿命使用）

赤色点灯（フィルター寿命終了）

加熱表示ランプ：白色点灯（加熱オン）

点灯消灯（加熱オフ）

Wi-Fiインジケータライト：白色点灯（ネットワーク接続済み）

白色点滅（ネットワーク接続中）

04 主な機能と特徴

① 体重センサー：

ペットの毎日の水分摂取量をミリリットル単位で記録し、アプリで表示します。残りの水量もリアルタイムでアプリに表示されます。