

USER MANUAL

7"AUDIO PLAYER



CAUTIONS

Safety Notes

This car radio has been manufactured according to established safety guidelines. However, dangers may still occur if the safety notes in this manual is not observed. This manual is intended to familiarize the user with the car radio's important functions. Read this carefully, prior to using the car radio. Keep this manual in an easily accessible location. In addition, do observe the instructions of the devices used in conjunction with this car radio.

Road Safety

Always observe the following notes for road safety:

1. Car radio must be used in a way that compliments safety of the user when driving the vehicle. It is recommended for the user to park at an appropriate location when operating the car radio. While driving, user is not recommended to use applications that can be prone to distraction e.g. streaming to medias etc.
2. User is advised to keep the volume of the car radio to a moderate level for the protection of the ears and to increase the ability to hear any emergency warning signals (e.g. police and ambulance sirens). Do not increase the car radio volume while the car radio is muted as it is not audible. The car radio volume can be too loud when the car radio is unmuted.

General Safety Notes:

This car radio is intended for installation and operation in a vehicle with the system outage, hence the radio unit must be installed in a DIN slot. Observe the output limits of the car radio. **Do not dismantle or modify** the car radio. Installation and repairs, if necessary, should be performed by a specialist. We are not liable for any loss or damage caused or resulting from unauthorized disassembly or modification to the product.

1. Please do not operate the car radio under extreme temperature conditions (extremely high temperature or extremely low temperature); make sure that temperature within the car ranges from -20 °C to 70 °C before you connect the car radio to the power supply.
2. If the problem persist, please kindly contact your nearest Isuzu Authorized Service Center for further assistance.
3. As USB file formats, codecs, bitrate, resolution and other parameters available in the market are not all the same, there is no guarantee that this car radio can play all media file formats.
Supported formats are as follows:
Audio: WAV/ASF/AAC/EC3/MP1/MP2/MPA/MP3/MP4/M4A/OGG/FLAC/APE
Video: AVI/MPG/MPEG/VOB/MP4/MPEG4/MOV/QT/3GP/WMV/ASF/FLV/SWF/M-KV/TS/TP/TRP/M2TS/MTS
Image: PNG/BMP/JPEG/GIF/JPG
4. Solvents, cleaning and scouring agents as well as dashboard spray and plastics care products may contain materials which can damage the surface and screen of the car radio. Use only dry or slightly moistened cloth to clean the car radio surface and screen. This manual may be updated from time to time without any notice.

Display Overview/Controls



1. Built-in microphone
2. Power button (short tap to mute / long tap to standby)
3. Home button
4. Voice Command (Only activated during Car Play)
5. Volume up
6. Volume down



1. Quick Select Sources: Tap for Top 3 Sources in use.
2. Radio: Tap to enter Radio Tuner interface.
3. USB Media Port: Tap to enter USB Media Player interface.
4. Android Auto: Tap to enter Android Auto interface.
5. CarPlay: Tap to enter CarPlay interface.
6. BT Music: Tap to enter BT Music interface.
7. BT Phone: Tap to enter BT Phone interface.
8. Settings: Tap to enter the system settings

RADIO FEATURES & OPERATION




1. Radio Storage Area. FM: 18 stations, AM: 12 stations. Tap and hold to save the preferred station.
2. Tap to move backward the frequencies; tap and hold to search backward and automatically search for previous valid station.
3. Tap to return to the main interface.
4. Tap to change to Local or Distance.Dx mode is suitable for use in areas with weak signals or when you need to receive radio stations at a long distance, while Loc mode is suitable for use in cities or areas with strong signals to reduce interference signals.
5. Tap to browse all radio stations in the favorites list, each radio station plays for 5 seconds.
6. Tap to Direct Station Entry.
7. Scan the valid radio station automatically.
8. Tap to set up sound equalizer.
9. Tap to move forward the frequencies; tap and hold to search forward and automatically search for next valid station.
10. Tap to enter RDS settings.

USB MUSIC



1. Tap to switch to the previous song.
2. Tap to toggle on the pause/play function.
3. Tap to switch to the next song.
4. Tap to toggle the Repeat all/Repeat Track/ Repeat Folder.
5. Tap to turn the Shuffle feature On or Off. Shuffle feature is for USB playback only.
6. Tap to set up sound equalizer.
7. Tap to enter the playlist.


USB VIDEO



1. Tap to enter the playlist.
2. Tap to toggle the repeat all/repeat one function.
3. Tap to switch to the previous video.
4. Tap to toggle the pause/play function.
5. Tap to switch to the next video.
6. Tap to enter Video settings.

Note: The warning interface will appear on the first video playback after each startup. Tap "I agree" button to enter the video playback interface, and tap "Cancel" to return to the higher-level interface.

USB PICTURE



1. Tap to enter the playlist.
2. Tap to toggle the repeat all/repeat one function.
3. Tap to switch to the previous image.
4. Tap to toggle the pause/play function.
5. Tap to switch to the next image.
6. Tap to Rotating Picture.

BLUETOOTH OPERATION

Before using Bluetooth

Before you can use a Bluetooth device to make hands-free calls or stream audio. It must be authenticated. This is also referred to as "pairing" a device.

Pairing a New Device


The unit broadcasts the pairing signal constantly when no devices are currently connected. Complete the pairing sequence from your Bluetooth device. Refer to the owner's manual for your device for more details. The device name is "ISUZU AUDIO". The unit can be in any mode of operation when pairing is performed. On certain phones, pairing may need to be done more than once.

Connect

The head unit will automatically connect to the last connected device when the connect feature is set to Auto connect On. If the connect feature is set to Auto Connect Off, the head unit will not automatically connect to any device.


Bluetooth Phone

From the main menu. Touch the Bluetooth on the screen. Bluetooth icon will appear when the Bluetooth device is connected.



1. Tap to display the keypad.
2. Tap to display stored contacts. Tap any contact to dial that number.
3. Tap to display a list of recent calls. Tap any number to dial.
4. Tap to display a list of paired devices, and select desired device to connect.
5. Display the signal strength and battery power of the currently paired mobile phone.

BLUETOOTH MUSIC



1. Tap to switch to the previous song.
2. Tap to toggle on the pause/play function.
3. Tap to switch to the next song.
4. Tap to set up sound equalizer.

Wired & Wireless Apple CarPlay Operation



The interface CPAA is depended on phone apps that registered with carplay android auto.

Wired connection


1. Connect an Apple CarPlay compatible device to this unit via USB (Only function for type A)
2. Tap "  " icon. The Apple CarPlay home screen appears.

Wireless connection

Before using Apple CarPlay wirelessly, turn on the Bluetooth and Wifi function on the Phone.

1. Tap "  " icon on the main menu:
2. Tap "Pair phone" to confirm to use wireless Apple CarPlay:
3. Tap "  " icon to search phone device. The available devices appear on the list;
4. Find the desired device on the screen and tap;
5. A pass key will be displayed on the screen;
6. The same key appears on the iPhone, tap "Pair" and then tap "Allow" for the popups;
7. Tap "OK" on the screen to confirm to connect:
8. Tap "Use CarPlay" on the iPhone. The unit configures the connection then starts the application.

Wired & Wireless Android Auto Operation



The interface CPAA is depended on phone apps that registered with carplay android auto.

Wired connection

1. Connect an Android Auto compatible device to this unit via USB(Only function for type A).
2. Tap "  " icon. The Android Auto home screen appears.

Wireless connection

Before using Android Auto wirelessly, turn on the Bluetooth and Wifi function on the Android device.

1. Tap "  " icon on the main menu:
 2. Tap "Pair phone" to confirm to use wireless Android Auto:
 3. Tap "  " icon to search phone device. The available devices appear on the list;
 4. Find the desired device on the screen and tap;
 5. A pass key will be displayed on the screen;
 6. The same key appears on the Android device, tap "Pair" and then tap "Allow" for the popups;
 7. Tap "OK" on the screen to confirm to connect:
- The unit configures the connection then starts the application.

SETTINGS



1. Tap to enter General settings.
2. Tap to enter Audio settings.
3. Tap to enter Display settings.
4. Tap to enter Wi-Fi settings.
5. Tap to enter Bluetooth settings.
6. Tap to enter Camera settings.
7. Tap to enter Radio settings.
8. Tap to enter System version information.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm distance between the radiator and your body: Use only the supplied antenna.

Warranty Term: Against material defects and manufacturing faults for a period of 3 years or 100,000km whichever is earlier for N-series. F-Series warranty 18 months or 80,000km whichever is earlier. Part will not be warranted for the damages due to accident, abuses, modification and misuse.

7 INCH AUDIO PLAYER