User Manual

PeopleLink Sonic Series

Product Manual | Edition V 1.0 | Release 072023 | PPL-UWP-WHP-S-OE12



(English Version)

Please read this Manual before setting up Sonic OE12W Headphone and stick to its requirements strictly for Safety reason. Suggest you save this manual for further inquiries reference.

2017 PeopleLink Unified Communications Pvt. Ltd. All rights reserved.
PeopleLink Unified Communications Pvt. Ltd.
Q3-A3, 10th Floor, Cyber Towers, Hitech City
Madhapur, Hyderabad – 500081 India


No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of PeopleLink Under the law, reproducing includes translating into another language or format. As between the parties, PeopleLink, retains title to and ownership of all proprietary rights with respect to the software contained within its products.

Therefore, you must treat the software like any other copyrighted material (e.g., a book or sound recording). Every effort has been made to ensure that the information in this manual is accurate. PeopleLink, is not responsible for printing or clerical errors. Information in this document is subject to change without notice.

PACKING LIST




PRODUCT OVERVIEW



1. ANC Switch
2. ANC Switch Indicator Light
3. MIC
4. AUX Interface
5. LED Indicator Light
6. Power Switch
7. Volume Down / Previous Track
8. Volume Up / Next Track
9. Charge Indicator Light
10. USB-C Charge Interface

POWER ON/OFF, ANC SWITCH




Power On: Long press the power button 3s, the blue LED light will be steady on 2s and then go off after flash slowly once.
Power Off: Long press the power button for about 4s, the red LED light will up 2s and then go out.

ANC On: Short press the ANC button once, to switch for different ANC levels, with prompt sound "ANC 1" and "ANC 2", and "Ambient Sound". The ANC blue indicator lights up.
ANC Off: Short press the ANC button once, and the ANC blue indicator lights goes off.

Note: In order to avoid the failure of the power switch to the greatest extent, it is recommended to wait for 2-3 seconds to restart again after turn off the headphone.

BLUETOOTH PARING




1. Long press the power button 3s in the power-off state to hear power on. After 5s, hear paring enter the pairing mode, and the indicator light flashes alternately in red and blue.
2. After the first connection, the headset will automatically connect back to the last connected device when it is turned on;
3. If you want to change the device or enter forced pairing, long press the power button 5s in the power off state;
4. Reset: Under the power-on and non-talking state, long-press the power button and the sound plus button 5s at the same time, until the purple light comes on 2s and then goes out completely, hearing two "beep", clear the pairing records and then enter the pairing state.

CONTROL

Mode	Function	Operation Methods
Bluetooth Mode	Play/Pause	Short press the power button once
	Previous Track	Long press "—" button once
	Next Track	Long press "+" button once
	Volume Up	Short press "+" button once
	Volume Down	Short press "—" button once
	Activate Voice Assistant	Long press the power button for 2s and then release
Calling Mode	Answer/Hang up a call	Short press the power button once
	Reject a Call	Long press the power button 2s
	Redial Last Number	Double-click the power button to redial the last call
	Voice Transfer	In the call state, long press the power key 2s and then the call sound is switched between the headset and the mobile phone


AUX-IN



1.Inserting the audio cable will automatically switch to AUX mode.

2.In AUX mode, the functions of increasing/decreasing volume, pausing play, previous /next track on headphones will be invalid, which needs to be operated through the mobile terminal and corresponding APP.

CHARGE



The red light keeps on when charging, and the green light keeps on after fully charged.

ISED Exposure Statement
The device has been evaluated to meet general RF exposure requirement. The device can be used installed and operated with minimum distance 0mm between the radiator and your body.
L'appareil a été évalué pour répondre aux exigences générales d'exposition aux RF.Cet équipement doit être installé et utiiisé avec une distance minimale de 0 mm entre le radiateur et votre corps.

FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
– Reorient or relocate the receiving antenna.
– Increase the separation between the equipment and receiver.
– Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
– Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IC ID

- English: "
This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:
(1) this device may not cause interference, and
(2) this device must accept any interference, including interference thatmay cause undesired operation of the device."

- French:"
Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :
(1) l'appareil nedoit pas produire de brouillage, et
(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement."

RF warning statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.