

100mm

100mm

Designed in Italy
By
Universal srl
Via Sant'Agostino 16,
Milan 20123
VAT 0745480965

White-TiRe® is a registered
trademark of Universal srl
All rights reserved

postale@vite-irbe.it

CE Declaration of Conformity

Univarsale srl
Persone di
Mandat: *Ing. Maurizio Di*
F.C.D. ID: 24440890MC
This device complies with part 15 of The FCC Rules. Operation is subject to the following two conditions: 1) This device must not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

CE Declaration of Conformity

Universal srl declares under its sole responsibility that this product is
conformant to european regulations 2004/108/EC (CEM - Electromagnetic
Compatibility) with respect to the following standards:
- EN 50122:2001+A1:2007
- EN 55024:1998+A1:2001+A2:2003

RoHS

This product is compliant with CE and FCC





CONTROLS & INTERFACES **22**

2. Line In LED

9. POWER Button

11. PREVIOUS/Next </> Button

12. PLAY/PAUSE Button

3. Microphone

5. Bluetooth LED

6. MODE Button

11. NEXT/Play > Button

B. Integrated Microphone

This is the opening, on the Top Panel, which marks the position of the microphone. Do not start inserting into this opening in order to avoid damage to the internal components which will then be covered by the warranty.

C. Bluetooth LED

When connected with Bluetooth with an HFP compliant device, this button allows to accept, reject or terminate a call directly from the device's 3 Touch Panel Incoming call - The button lights up or green:

- Short press to accept the call
- Long press to refuse the call

During a call, the button is always red

- Press once to terminate the call

12. PLAY/PAUSE Touch Button

During the Bluetooth Connection (when AVCP is available) operational modes, this button is used to play and pause the audio tracks.

During the Line Connection operational modes, the button can temporarily set the sound to mute and then restore it at the original state.

11. PREVIOUS/Next </> NEXT/Play > Touch Buttons

In Bluetooth Connection (when AVCP is available) operational modes, allow to:

- Set to PREVIOUS/NEXT track - short press
- Set to NEXT/Play track - long press

In the Line Connection and in Bluetooth Connection (if AVCP is not available) operational modes, allow to:

- Volume DOWN/UP - long press

vibeTribes

expands your sound

18w
WIRELESS
COMP. CALL
TOUCH CONTROL
DANCE CHAIN

vibeTribes

Bluetooth®
(NFC)

mamba
3D SPEAKER

user manual

CONNECTION via BLUETOOTH & NFC

12

Hamba can reproduce any audio signal from an external audio source which is Bluetooth compatible.

Bluetooth Compatibility: Hamba integrates Bluetooth 4.0 technology and is compatible with all the devices integrating the Advanced Audio Distribution Profile (A2DP) protocol for the music playback, the AudioVideo Remote Control Protocol (AVRCP) for the remote control of the device and the Hands-Free Profile (HFP) for the hands free call functionality. The Bluetooth 4.0 is also compatible with all the previous Bluetooth versions.

NFC Compatibility: Hamba integrates NFC (Near Field Communication) pairing mode, allowing the Bluetooth setup-pairing as described below.

Selection of Bluetooth mode: In order to select the Bluetooth Connection Mode, press repeatedly the "Touch Front" button until the "Bluetooth LE" message is shown. After a brief steady light, the "Bluetooth LE" will start blinking. This indicates that Hamba is entering into Bluetooth mode and is ready to be connected to an external Bluetooth audio source.

Pairing with two Bluetooth audio sources: Pairing occurs when two Bluetooth devices communicate with each other and establish a stable connection.

Hamba enables two different pairing modes:

- Standard Bluetooth Pairing:** Verify that your desired external source has the Bluetooth function enabled and set it to "discoverable" mode. Search for Bluetooth devices and include the list of discovered Bluetooth Devices. From the Bluetooth device list, select the device named "Vibe Tribe Mamba". If your device asks for a password, enter "0000" (four zeros) and press OK. Some devices also ask you to tap to connect the connection, where the pairing is complete. Hamba will emit a short sound signal and the "Bluetooth LE" will stop blinking and remain steady on.
- nFC Bluetooth Pairing:** Verify that your desired external source has the NFC function available and turned on. Verify that your desired external source has the Bluetooth function turned on and set it to "discoverable" mode. It is then enough to place the Device close to the Hamba's Touch Front and the pairing will be confirmed with a short sound signal and the "Bluetooth LE" will stop blinking and remains steady on.

Wireless sources may take a couple of tries to successfully connect the first time. In case your device does not connect the first time, repeat the previous steps.

7

INDEX

English 3

Join the Tribe:



Visit our official web site for the latest news and reviews on our products!

WWW.VIBE-TRIBE.EU




Follow us on Facebook! Read about Vibe-Tribe news, events, and promotions on our FB page!



[VIBE-TRIBE.UK/FACEBOOK](https://www.facebook.com/VIBE-TRIBE.UK)

CONNECTIONS TO BLUEBLOOTH® AND NFC

22

Connection with a Bluetooth audio source to connect an already paired device, just connect the external audio source to the AVR® product. However, locate the USB to discover Bluetooth devices and select "Vibe-Tribe" from the list. Namica will emit a short sound signal and the "Bluetooth Link" will remain steady lit.

Operation via the Audio signal coming from the external source

The audio source integrates the AVR® product, following controls will be available both through the Namica & Touch Panel and the paired external Source:

- Play to the Next/Previous track
- Pause/Resume/Stop a track (playback)
- Skip to the Next/Previous track
- Increase/Decrease the volume (need complete AVR® support)
- If the source does not support the AVR® product, following controls should be implemented through the Namica & Touch Panel and the paired External Source:
- Increase/Decrease the volume
- Play to the Next/Previous track
- Pause/Resume/Stop a track (playback)
- Skip to the Next/Previous track

Hands Free Calls via Bluetooth: once the pairing procedure is effective, if the source does not support the AVR® product, Namica can be used as hands free device during your incoming and outgoing calls.

Answering/Refusing Calls When receiving a call, the "Phone Touch Button" will become lit and green allowing the receiver either to:

- Answer the call - short press
- Refuse the call - long press

Ending Calls Once the call has been answered, the "Phone Touch Button" will become lit and red. The receiver terminates the call by short pressing the button. During an Hands-free call, the volume will be controlled both through the Namica & Touch Panel and the phone; we recommend you to regulate the volume settings on both the devices to optimize your experience.

Disconnecting Bluetooth Namica can pair with any external Bluetooth devices. However, can only be connected to, and play audio from, one device at a time.

• If you wish to connect a new external device, it is necessary to first disconnect the one in use. This can be done in two different ways:

- By selecting **Bluetooth Off** and **On again**
- By disconnecting the external audio source

• If through the Namica or external unit an external audio source is interrupted, Namica emits a short audio signal and the "Bluetooth Link" starts blinking indicating the connection is no longer active.

• If the Bluetooth connected external audio source goes out from the Namica Bluetooth range, without the Bluetooth connection being manually disconnected, the pairing signal will start to blink. Namica before being interrupted making Namica available for a new connection.

"VIBRATION RESONANCE" TECHNOLOGY

Congratulations on your purchase of the Vibe-Tone Hamma Wireless Speaker.

This manual is intended to help you correctly install, operate and get the best performance from your Hamma. Read this guide carefully before the usage, then keep it near if you need it.

HAMMA is Vibe-Tone's most powerful vibration speaker, and possibly the world's most advanced portable wireless audio solution.

HAMMA delivers a top audio experience without the hassle of cables and docking stations, giving you the freedom to dance, move, games, and create wherever you want. It's the perfect companion to any mobile phone, mp3 player, tablet or laptop.

HAMMA is powered by a next generation Vibration Core, capable of producing an extremely high fidelity sound, leveraging on the patented Vibration Resonance Technology.

The proprietary extra-powerful Vibration Core converts the low electromagnetic signal into mechanical energy that is transferred to the surface where the unit is placed, transforming them into wide and powerful acoustic sounds, spreading the sound in an amazing way.

The sound driver responds on the surface characteristics:

Material	Sound Experience
Wood	Enriching tones in a round
Metal	Powerful and clear effect
Carboard	Warm effect
Glass	Clear and crystal clear sound
Softest wall	All around effect

MAIN FEATURES

- Output Power: **RMS 18W**
- MC **Bluetooth**
- Bluetooth version: **4.0**
- Bluetooth profile: **A2DP, L2P, HFP, 1.1, HSP, 1.4, AVRCP, 3.0**
- Lithium-ion Battery **2400mAh**
- Dimension / Weight **90x50mm / 400g**

VACUUM BASE

Hamma packs includes one additional space Vacuum Base to be attached between HAMMA and the surface.

Placing HAMMA on the Vacuum Base permits to place and move Hamma easily and very effective to obtain a better sound.

Please note that the Vacuum Base is NOT capable of sustaining the weight of the Hamma unit.

Placing HAMMA on the Vacuum Base is not recommended. Do not put or leave any damage to persons or objects as a result of the positioning of Hamma on any surface other than the "VIB" surface.

BASSY CHAIN

Hamma comes with the built-in ability to connect to other Hammas. This feature and you to provide coverage for larger spaces using a chain of Hammas. For an absolute incredible in a 100m sound experience!

Connection Chain: Choose the unit you wish to act as the master unit. This unit will be the first device of the chain. The master unit will be the only unit connected to an external device. The Vacuum Base permits to place and move Hamma easily and effectively to obtain a better sound. The other units will be only connected to each other. Using the provided cable, connect the cable to the master unit's 3.5" Jack socket. Take the other end of the cable and connect it to the next device Hamma music is to be played. Repeat the operation in order to connect it to the next device Hamma music is to be played. Repeat the operation in order to connect it to the next device Hamma music is to be played.

Please note that you may be any speaker that can connect to the 3.5" Jack socket. Do not connect the Hamma.

Powering the Daisychain: Every unit in the daisychain must be powered on.



WARNING & CAUTIONS

Please read the safety warnings and cautions carefully to ensure your personal safety and prevent property damage.

- Even if equipped with Vacuum bags, Membrane shall be used only on horizontal surfaces.
- Do not operate Membrane in high surface roughness or shoring. Working means: **glueless Membrane** and **glueless Membrane**.
- Charge Membrane fully equipped with Vacuum bags, you must strictly follow the Membrane **usage and safety** and **stop the edge**.
- Charge Membrane completely before using it for the first time.
- Do not use the machine against walls or floors for better adhesion and optimal safety performance.
- Rightly press the cassette into the vertical rollers for better adhesion and optimal safety performance.
- A moderate increase of device temperature is normal during operation.
- Do not attempt to repair, modify, or disassemble your Membrane yourself. If you do not consult an authorized technician.
- Do not insert anything into your Membrane unless otherwise specified in its use instructions. This is dangerous to the internal components.
- Do not expose your Membrane to liquid, moisture, humidity, or rain. Do not charge Membrane near a battery, fire, flames, oil, or steam source. Exposure of Membrane to moisture could result in electric shock.
- Do not attempt to replace your Membrane. It is built-in and is not chargeable.
- Do not touch your Membrane in contact with any sharp objects because this could cause serious damage.
- Clean with a dry soft cloth. Do not use abrasive cleaners or chemicals otherwise to clean your Membrane because it could scratch surfaces and/or reflection.
- Please store Membrane properly, keep inside caps, memory cards and video cables away from direct sunlight or reflection.
- **Keep this owner's guide together with all other cards receipt for accessories and warranty.**

BATTERY RECHARGE

- Put the Switch in "OFF" position and connect the Membrane to a PC or a 5V power supply using the MicroUSB-USB cable. During the battery recharging the red LED is on. The charge time is around 2-3 hours.
- For better battery operation and prolonged battery lifespan, disconnect after recharging the device on battery power until it needs to be charged again.

LINE-CAIN CONNECTION - Mode



Membrane can reproduce any audio signal from an external audio source connected through the included cable.

In order to select the Line to Connect Mode, press the "Mode Touch Button" until "Line to Line" is selected on screen.

Connect the Membrane (Membrane) to the 3.5mm jack input of your desired external source (e.g. PC, smartphone, tablet...) using the included cable. Membrane is ready to play.

CONNECTION OPERATIONAL MODE

In this operational mode, the following functions can be controlled through the Touch Buttons:

- PAUSE/PLAY** - short press "Pause/Play" Touch Buttons
- REPEAT** - long press "REPEAT" and "REPEAT/STOP" Touch Buttons

In this operational mode, the volume level can also be controlled through the paired Bluetooth, or, in an experimental way, by controlling the volume settings in the most effective way to optimize your audio experience

CONTROLS & INTERFACES	1/2
<p>▶ 2-Prong LED</p>	<p>2-Micro USB Port</p>
<p>▶ 1/4-INCH Headset Jack</p>	<p>▶ 1/4-INCH Inputs</p>
<p>▶ 1/4-INCH Out to Busby Chain</p>	
<p>▶ 1/4-INCH Out to Busby Chain</p>	
<p>▶ 1/4-INCH Out to Busby Chain</p>	
<p>▶ 1/4-INCH Out to Busby Chain</p>	
<p>▶ 1/4-INCH Out to Busby Chain</p>	
<p>▶ 1/4-INCH Out to Busby Chain</p>	
<p>▶ 1/4-INCH Out to Busby Chain</p>	
<p>▶ 1/4-INCH Out to Busby Chain</p>	
<p>▶ 1/4-INCH Out to Busby Chain</p>	
<p>▶ 1/4-INCH Out to Busby Chain</p>	
<p>▶ 1/4-INCH Out to Busby Chain</p>	
<p>▶ 1/4-INCH Out to Busby Chain</p>	
<p>▶ 1/4-INCH Out to Busby Chain</p>	
<p>▶ 1/4-INCH Out to Busby Chain</p>	
<p>▶ 1/4-INCH Out to Busby Chain</p>	
<p>▶ 1/4-INCH Out to Busby Chain</p>	
<p>▶ 1/4-INCH Out to Busby Chain</p>	
<p>▶ 1/4-INCH Out to Busby Chain</p>	
<p>▶ 1/4-INCH Out to Busby Chain</p>	
<p>▶ 1/4-INCH Out to Busby Chain</p>	
<p>▶ 1/4-INCH Out to Busby Chain</p>	
<p>▶ 1/4-INCH Out to Busby Chain</p>	
<p>▶ 1/4-INCH Out to Busby Chain</p>	
<p>▶ 1/4-INCH Out to Busby Chain</p>	
<p>▶ 1/4-INCH Out to Busby Chain</p>	
<p>▶ 1/4-INCH Out to Busby Chain</p>	
<p>▶ 1/4-INCH Out to Busby Chain</p>	
<p>▶ 1/4-INCH Out to Busby Chain</p>	
<p>▶ 1/4-INCH Out to Busby Chain</p>	
<p>▶ 1/4-INCH Out to Busby Chain</p>	
<p>▶ 1/4-INCH Out to Busby Chain</p>	
<p>▶ 1/4-INCH Out to Busby Chain</p>	
<p>▶ 1/4-INCH Out to Busby Chain</p>	
<p>▶ 1/4-INCH Out to Busby Chain</p>	
<p>▶ 1/4-INCH Out to Busby Chain</p>	
<p>▶ 1/4-INCH Out to Busby Chain</p>	
<p>▶ 1/4-INCH Out to Busby Chain</p>	

	<div data-bbox="1957 813 2020 823" style="background-color: black; color: white; text-align: center; padding: 2px;">LEGAL NOTICES</div> <div data-bbox="1859 829 1904 839" style="background-color: black; color: white; padding: 2px;">FCC Part 15</div> <div data-bbox="1859 839 2119 909"> <p>FCC STATEMENT: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:</p> <ul style="list-style-type: none"> • Reorient or relocate the receiving antenna. • Increase the separation between the equipment and receiver. • Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. • Consult the dealer or an experienced radio/TV technician for help. <p>FCC NOTICE: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:</p> <ul style="list-style-type: none"> • This device may not cause harmful interference, and • This device must accept any interference received, including interference that may cause undesired operation. <p>FCC CAUTION: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>FCC ID: 2AAGHWWVC To locate the FCC identification numbers, please look on the underside of Monitor.</p> </div>