

FEATURES



When photos arrive, they'll play on a slideshow. Swipe to scroll through photos.



If you love a photo, **tap the Heart button** in the lower right of the screen, and **we'll email the sender to tell them you loved it!**



Skylight requires wi-fi to receive new photos, but you can still **view photos without a wi-fi connection.**



To **zoom into a photo** so it fills the screen, take two fingers (e.g. your two index fingers) and **pinch to zoom.**

Tap the screen to see the **Settings Bar**. From here you can:

- **Delete** photos
- **Rotate** photos
- **Pause** on a favorite photo
- View a **Gallery** of all your photos
- Tap **Advanced Features** to change the **slideshow speed** or **shuffle** your photos
- Tap **How It Works** to check your **Skylight email address** or **reset your WiFi**

SKYLIGHT QUICK START GUIDE



Contents of box:

Your Skylight package contains the following:

- Skylight Frame
- Plastic support stand
- Power adapter
- Quick Start Guide



1. SET UP

- **Screw the plastic support stand** into the hole on the lower right on the back of Skylight.
- If you prefer to mount Skylight on the wall, you can use the hole on the upper back of Skylight.



2. TURN ON

- **Connect the adapter** to Skylight – it plugs into the small hole on the back that says DC IN.
- Connect the adapter to an outlet.
- In about 30 seconds, **the home screen will appear.**




3. CONNECT

- A list of available WiFi networks will appear on the right side of the screen. **Tap to choose your network from the list.** Swipe up and down if the list is long.
- If the name of your network does not appear, wait for 30 seconds and check again.
- If your WiFi requires a password, a prompt will appear. **Type in your network's password** using the on-screen keyboard. Don't make any typos!
- Skylight will let you know once it has successfully connected.



4. ACTIVATE

- Visit **www.ourskylight.com/register** and follow the instructions there to pick your unique Skylight email address.
- **Once you create your Skylight email, our online system gives you a 6-digit code.**
- Just tap that code into your Skylight device after turning it on the first time, using Skylight's on-screen keypad.
- Skylight will automatically retrieve your unique Skylight email address and display it on the screen.



5. SHARE

- Now **everyone in your family can email photos** (as attachments) **to your Skylight email address** (e.g. janessmith@ourskylight.com).
- The subject and contents of the email don't matter – Skylight just grabs photo attachments.
- **About 60 seconds after photos get sent, they appear on your Skylight!**



If you have purchased the Skylight Plus plan, you get access to these premium features:

- Send videos to your Skylight (in addition to photos)
- Add text captions to your photos
- View and download your content on the Skylight Plus web and mobile apps

If you have additional questions, please visit our **User Guide** at **www.skylightframe.com/support** or email us at **info@skylightframe.com**

Learn all about Skylight's features on the next page >>

FCC Requirement

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or

television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC 20cm Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.