





- Z-folding (Z形摺紙)
- Double printing (雙面印刷)



Front

PBteen Emily & Meritt For PB Teen THE BUNNY SPEAKER USER MANUAL  Model No.KA-BT-SPK-GLDBNY SKU No. 9160875 / 9134334	Table of contents 1 Introduction..... 1 2 Packge includes..... 2 3 Product diagram..... 2 4 How to use..... 3 4.1 General function..... 3 4.2 Pairing to mobile phone..... 4 4.3 Charging your speaker..... 6 5 Technology specification..... 6 6 FAQ..... 7 7 FCC Statement..... 8	1.Introduction Congratulations, and thank you for choosing the Bluetooth Wirless Speaker. This manual will help you operate the Bluetooth Wirless Speaker, but you should first familiarize yourself with the Bluetooth functionality of your mobile phone or other devices before using the Bluetooth Wirless Speaker. Safety Rules 1\ Please follow the rules depicted in this manual closely to ensure your safety. Before using this Bluetooth speaker, we would strongly encourage you to read through this user manual. 2\ Be more wary of any edges, uneven surfaces, metal parts, accessories and its packaging so as to prevent any possible injury or damage. 3\ Do not modify, repair or dismantle this Bluetooth speaker. Doing so may result in fires, electric shocks, complete breakdown of this Bluetooth speaker, etc. All of which, are not covered under warranty. 4\ Do not use any diluents or volatile liquid to clean the Bluetooth speaker. 5\ Do not use the Bluetooth speaker in a hazardous location.	2.Package includes 1X Bluetooth Speaker 1X USB Charger 1X User Manual 1X Audio Cable 3.Product diagram Left Right 	4.How to use 4.1.General Functions <table><tr><th>Desired Result</th><th>Required Action</th></tr><tr><td>Turn on & Enter the pairing mode</td><td>Switch the ON/OFF button to "ON" to turn speaker on. (Blue LED quickly flash alternately with two beep tone voice).</td></tr><tr><td>Pairing</td><td>You should use a Bluetooth function mobile phone or other Bluetooth Master Device and to perform pairing action (detail refer to the chapter about pairing)</td></tr><tr><td>Play / Pause</td><td>Press  to play when the device is pausing and press  to pause when the device is playing.</td></tr><tr><td>Turn off</td><td>Switch the ON/OFF button to "OFF" to turn speaker off.</td></tr><tr><td>Low battery warning</td><td>(The LED flash)</td></tr><tr><td>Charging</td><td>Plug the charger to  port of the device. (Red LED is on)</td></tr><tr><td>Answer / End phone call</td><td>Press  to answer phone call, press  again to end call.</td></tr><tr><td>Reject phone call</td><td>Long press  to reject call.</td></tr></table>	Desired Result	Required Action	Turn on & Enter the pairing mode	Switch the ON/OFF button to "ON" to turn speaker on. (Blue LED quickly flash alternately with two beep tone voice).	Pairing	You should use a Bluetooth function mobile phone or other Bluetooth Master Device and to perform pairing action (detail refer to the chapter about pairing)	Play / Pause	Press  to play when the device is pausing and press  to pause when the device is playing.	Turn off	Switch the ON/OFF button to "OFF" to turn speaker off.	Low battery warning	(The LED flash)	Charging	Plug the charger to  port of the device. (Red LED is on)	Answer / End phone call	Press  to answer phone call, press  again to end call.	Reject phone call	Long press  to reject call.
Desired Result	Required Action																					
Turn on & Enter the pairing mode	Switch the ON/OFF button to "ON" to turn speaker on. (Blue LED quickly flash alternately with two beep tone voice).																					
Pairing	You should use a Bluetooth function mobile phone or other Bluetooth Master Device and to perform pairing action (detail refer to the chapter about pairing)																					
Play / Pause	Press  to play when the device is pausing and press  to pause when the device is playing.																					
Turn off	Switch the ON/OFF button to "OFF" to turn speaker off.																					
Low battery warning	(The LED flash)																					
Charging	Plug the charger to  port of the device. (Red LED is on)																					
Answer / End phone call	Press  to answer phone call, press  again to end call.																					
Reject phone call	Long press  to reject call.																					

4.2.Pairing to mobile phone or other device To use your Bluetooth Speaker, you must first pair your speaker with a phone or a computer. Once your Bluetooth Speaker is paired to a specific mobile phone, they will remain paired and automatically recognize each other whenever they are within range. Pairing to a phone and Entertainment: • Turn on your phone and ensure its Bluetooth function is activated. • Turn on the speaker go to the pairing mode. • Search your Bluetooth devices on your phone by following the phone's instructions. Refer to your phone's user manual for more information. • After a few seconds the phone will list the "PB Bunny" as a discover device. Select it and follow your phone instruction to select this pairing. • Your phone will confirm the pairing, and then press Yes/OK. • Finally, the pairing is successful. • You can play music; watch TV/movie and play games with your phone, then you can hear all the sound or music from the speaker.	Pairing to a computer and Entertainment: • If there is no Bluetooth function supported by your computer, a Bluetooth adapter is necessary. Fix the adapter with your computer and ensure its Bluetooth function is activated. • Turn on the speaker go to the pairing mode. • Open the Bluetooth software installed on your computer, and selects "Search your Bluetooth devices" function. Refer to user manual of the Bluetooth software for more information. • After a few seconds the "PB Bunny" will list in Bluetooth software of your computer as a discover device. Select this icon and click right button of mouse to select "pairing" item, then select "connect with audio device" with same operation. • Open your media player soft to play music, watch TV/movie and play game, then all the sound will be playback on your speaker.	4.3.Charging your speaker The speaker is convenient to connect to AC charger or a USB charger with Mini DC 2.0 port marked with. Make sure that your speaker is full charged for at least 6 hours before initial use. Insert one terminal of your charger to AC main or USB port of PC and other terminal to DC 2.0 jack. While charging, the red LED light stays lit. When charging is completed, the LED turns off. Warning: • You must select a qualified charger from a regular manufacturer. • You must charge the Bluetooth Speaker if it has not been used for more than 12 months. 5.Technical specification <table><tr><th>Parameter</th><th>Value</th></tr><tr><td>Bluetooth Specification</td><td>3.0</td></tr><tr><td>Bluetooth Profile</td><td>A2DP, AVRCP, HFP, HSP, GAVDP, IOP</td></tr><tr><td>RF Range</td><td>≤10m</td></tr><tr><td>Frequency Response</td><td>160Hz - 20KHz</td></tr></table>	Parameter	Value	Bluetooth Specification	3.0	Bluetooth Profile	A2DP, AVRCP, HFP, HSP, GAVDP, IOP	RF Range	≤10m	Frequency Response	160Hz - 20KHz	<table><tr><th>Parameter</th><th>Value</th></tr><tr><td>Loudspeaker Output</td><td>3 W</td></tr><tr><td>Signal-To-Noise</td><td>75 dB</td></tr><tr><td>Distortion</td><td>≤1.0%</td></tr><tr><td>Playback Time</td><td>3 - 5 hours</td></tr><tr><td>Charging Time</td><td>1 - 2 hours</td></tr><tr><td>Dimension (L×W×H)</td><td>67mm × 29mm ×140mm</td></tr><tr><td>Weight</td><td>95 g</td></tr></table> 6.FAQ 1. Why is there no power even when the Speaker is power on? Ans: Ensure the battery is being charged up to 6 hours for first time using. The LED is red when it starts charging. 2. There is no sound when playback. Ans: Check the connection between speaker with phone or computer, if the connection is not established, please connect again. Make sure the speaker is paired and connected with your target phone or other master device.	Parameter	Value	Loudspeaker Output	3 W	Signal-To-Noise	75 dB	Distortion	≤1.0%	Playback Time	3 - 5 hours	Charging Time	1 - 2 hours	Dimension (L×W×H)	67mm × 29mm ×140mm	Weight	95 g	FCC statement Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: • Reorient or relocate the receiving antenna. • Increase the separation between the equipment and receiver. • Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. • Consult the dealer or an experienced radio/TV technician for help. FCC ID: 2AABW-PBBTSPBNY
Parameter	Value																													
Bluetooth Specification	3.0																													
Bluetooth Profile	A2DP, AVRCP, HFP, HSP, GAVDP, IOP																													
RF Range	≤10m																													
Frequency Response	160Hz - 20KHz																													
Parameter	Value																													
Loudspeaker Output	3 W																													
Signal-To-Noise	75 dB																													
Distortion	≤1.0%																													
Playback Time	3 - 5 hours																													
Charging Time	1 - 2 hours																													
Dimension (L×W×H)	67mm × 29mm ×140mm																													
Weight	95 g																													
4	5	6	7	8																										

Back