4WD LAND ROVER DEFENDER ROCK CRAWLER

1/8 SCALE 2.4G RADIO CONTROL 4WD OFF ROAD TRUCK

4x4 OFF ROAD



LAND ROVER

4WD LAND ROVER DEFENDER ROCK CRAWLER

1/8 SCALE 2.4G RADIO CONTROL 4WD OFF ROAD TRUCK

8+

RC RADIO CONTROL

1:8

DOUBLE E

E328-003

2.4G

LAND ROVER

www.doubleeagle.cc

4WD LAND ROVER DEFENDER ROCK CRAWLER

1/8 SCALE 2.4G RADIO CONTROL 4WD OFF ROAD TRUCK

06.07.00E328.03

DOUBLE E

4x4 OFF ROAD

4WD LAND ROVER DEFENDER ROCK CRAWLER

1/8 SCALE 2.4G RADIO CONTROL 4WD OFF ROAD TRUCK

4WD LAND ROVER DEFENDER ROCK CRAWLER

1/8 SCALE 2.4G RADIO CONTROL 4WD OFF ROAD TRUCK

Functions

OFF Road 4x4
Simulated Lights
Steering Gear
2.4GHz Remote Control
Go Forward/Backward
Infinitely Variable Speeds
Turn Left/Right



DOUBLE E

BATTERY WARNINGS:

1. Non-rechargeable batteries are not to be recharged.
2. Rechargeable batteries are only to be charged under adult supervision.
3. Rechargeable batteries are to be removed from the toy before being charged.
4. Different types of batteries or new and used batteries are not to be mixed.
5. Batteries are to be inserted with the correct polarity.
6. Exhausted batteries are to be removed from the toy.
7. The supply terminals are not to be short-circuited.
8. The toy is not to be connected to more than recommended number of power supplies.
9. The toy is not intended for children under 3 years old.
10. Regular examination of transformer or battery charger for any damage to their cord, plug, enclosure and other parts, they must not be used until the damage has been repaired.
11. Do not mix old and new batteries.
12. Do not mix alkaline batteries,standard (carbon-zinc) or rechargeable batteries.

Tested according to international standards

NOT SUITABLE FOR CHILDREN UNDER 3 YEARS DUE TO SMALL PARTS
COUNTRY OF ORIGIN:CHINA

WARNING: CHOKING HAZARD - small parts, Not for children under 3 years.

Land Rover and the Land Rover logo are trade marks owned and licensed by Jaguar Land Rover Ltd.

INSTRUCTIONS

- Install 1 pc of 7.4V rechargeable battery into the battery case on the chassic, and then screw the battery cover.
- Install 4 pcs of 1.5V AA batteries into the controller, and then screw the battery cover at the bottom of remote controller.
- Turn on the switch of the car and remote controller.
- To play the car by remote controller.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.

Basic operation introduction

Cell Cover
Power Switch
Pilot Lamp
Turn Left/Right
Power Switch
Direction Control (Turn Left/Right)
Speed Adjustment (Acceleration/Deceleration)
Forward/Backward
Cell Cover

Install 1 pc of 7.4V rechargeable battery into the battery case on the chassis, and then screw the battery cover. (Battery and USB line are included)

Install 4 pcs of 1.5V AA batteries into the controller. (Batteries are not included)

Recharging:

Battery connecting port

The output voltage is ⎓DC5V

The toy is to be connected to Class II epuipment bearing the symbol. ⧈

2.4GHz Auto-matching

1. Put batteries in car and remote controller separately, and then turn on the switch of both. When the indicator of the remote controller flashes slowly, the car is in state of auto-matching. The indicator of the remote controller flash frequently means that the auto-matching is successful.
2. One remote can only match with one car. There is non-interference for each car after matching successfully
3. Turn off switch of remote and vehicle before to match with other vehicles or remote controllers.

Functions introduction

Forward		Direction Control (Turn right)	
Backward		Direction Control (Turn left)	
Turn Left		Speed Adjustment (Decelerate)	
Turn Right		Speed Adjustment (Accelerate)	

Notice: Battery needs to be charged for the first time use.
Images are for reference only and may differ from the real product, specific please prevail in kind.

Please retain this packaging as it contains important information.

Manufacturer:Doubleeagle Industry (China) Limited
Address: Xingda Industrial Park, Chenghai District, Shantou City, Guangdong Province, China.
Website: www.doubleeagle.cc

TAMIYA-CARSON MODELLBAU GMBH & CO.KG
WERKSTRASSE 1, D-90765 FUERTH, GERMANY

Declaration for EU
Frequency bands: 2405MHz-2478MHz
Max. power transmitted: -14.64dBm

MADE IN CHINA

ITEM NO.:E328-003

6 948061 923453