




SABRE v2 PRO WIRELESS MG

GAMING MOUSE

GETTING TO KNOW YOUR MOUSE




A	LEFT MOUSE BUTTON	J	DPI BUTTON
B	RIGHT MOUSE BUTTON	K	USB WIRELESS RECEIVER
C	MIDDLE CLICK/SCROLL WHEEL	L	USB CHARGING / DATA CABLE
D	FORWARD BUTTON		
E	BACK BUTTON		
F	MARKSMAN S OPTICAL SENSOR		
G	USB CHARGING / DATA PORT		
H	100% VIRGIN-GRADE UPE MOUSE SKATES		
I	POWER / WIRELESS MODE SWITCH		

MOUSE STATUS, DPI SETTINGS AND INDICATIONS

Wireless connection and battery status are communicated through MIDDLE CLICK / SCROLL WHEEL LED INDICATOR. The mouse comes preloaded with common competitive DPI settings which can be selected by pressing the DPI BUTTON with the LED lighting to reflect the current stage.

BATTERY STATUS	MIDDLE CLICK / SCROLL WHEEL LED INDICATOR
Battery charging	Pulsing green
Battery critical, recharge required	Pulsing red
Battery low, recharge soon	Blinking red
Battery medium	Blinking amber
Battery high	Blinking green
Battery charged	Green
DPI STAGE STATUS	MIDDLE CLICK / SCROLL WHEEL LED INDICATOR
Stage #1 - 400 DPI	Solid Red
Stage #2 - 800 DPI	Solid Orange
Stage #3 - 1200 DPI	Solid Yellow
Stage #4 - 1600 DPI	Solid Green
Stage #5 - 3200 DPI	Solid Blue

CONHEÇA O SEU RATO



A	BOTÃO ESQUERDO DO MOUSE	J	BOTÃO DE DPI
B	BOTÃO DIREITO DO MOUSE	K	RECEPTOR USB SEM FIO
C	CLIQUE DO MEIO / RODA DE ROLAGEM	L	CABO USB DE CARREGAMENTO / DADOS
D	BOTÃO AVANÇAR		
E	BOTÃO VOLTAR		
F	SENSOR ÓPTICO MARKSMAN S		
G	PORTA USB DE CARREGAMENTO / DADOS		
H	PÉS DO MOUSE DE UPE VIRGEM 100%		
I	INTERRUPTOR DE ENERGIA / MODO SEM FIO		

DEFINIÇÕES E INDICAÇÕES DE DPI E ESTADO DO RATO

O status da conexão sem fio e da bateria é comunicado através do INDICADOR LED DO CLIQUE DO MEIO / RODA DE ROLAGEM. O mouse vem pré-carregado com configurações comuns de DPI para jogos competitivos, que podem ser selecionadas pressionando os botões BOTÃO DE DPI, com a iluminação do LED refletindo o estágio atual.

ESTADO DA BATERIA	INDICADOR LED DE ESTADO DA BATERIA E SEM FIOS
Bateria a carregar	A piscar a verde
Bateria crítica, necessário carregar	A piscar a vermelho
Bateria fraca, carregar brevemente	Vermelho intermitente
Bateria média	Âmbar intermitente
Bateria alta	Verde intermitente
Bateria Carregada	Verde
ESTADO DA FASE DPI	INDICADOR LED DE FASE DPI
Fase N.º 1 – 400 DPI	Vermelho
Fase N.º 2 – 800 DPI	Laranja
Fase N.º 3 – 1200 DPI	Amarelo
Fase N.º 4 – 1600 DPI	Verde
Fase N.º 5 – 3200 DPI	Azul