

Ningbo Prosound Electronics Co., Ltd

Bluetooth Speaker

Model: W MARU

User Manual

Quickstart

Out of the box: Charge your Maru with the provided Power Cable for 2 hours or until the 4 side LEDs are full and white.

You can play your Maru with or without the Power Cable plugged to your Maru.

Using your Maru

Turn On: Press the Control Button for 1 second, you will hear a start sound and the LED on the front of the Control Button will light up and start flashing.

Turn Off: Press the Control Button for 1 second, you will hear off sound and the LED on the front of the Control Button will turn off.

Pause/Play: Quick single press will pause the sound and another quick single press will play again.

Connecting using Bluetooth

Quick double click the Control Button, the front LED will start flashing fast, it is now in search mode.

Open the Bluetooth menu on your source device, make sure Bluetooth is ON and then locate W Maru in the list of available devices.

The front LED will stop flashing and you will hear a sound cue, you are now connected. Play any media on your device like you would normally do and the sound will now play on your Maru.

Your Maru will from now on automatically connect to your device when both are on and in range in the future. Make sure your Bluetooth is ON on your device!

Switching to another device in Bluetooth

Maru can handle connection from two devices at the same time.

Quick double click the Control Button, the front LED will start flashing, turn ON Bluetooth on your second device then locate W Maru in the list of available devices.

When playing one device, press pause on it and then press play on the second device to play.

Connecting two Maru together / Stereo Pair Mode

Turn on both Maru, press the Stereo Pair Button two sec on each maru then you will hear a sound cue and the front LEDs will flash orange color, both Maru are in search mode. You will then hear another sound cue and the front LED will turns solid on both maru, they are now paired.

Once you have paired two Maru, they will automatically connect to each other when you turn them on.

Connecting your device while in Stereo Pair Mode: like in single MODE double press any maru front button twice and follow the normal steps.

Turning off one Maru will turn off both Maru.

Turning off Stereo Pair Mode

Double click any of the Maru Stereo Pair Button.

Note that Stereo Pair Mode is only available with Bluetooth, using the supplied Audio cable will shut down Stereo Pair Mode and Bluetooth.

Connecting 2 devices to your Stereo Pair Mode

Double click on front button on any MARU just like in single function. Once connected if your friend device is playing on the two MARU, press pause on device of your friend, then press Play on your device and your music will start playing after a few seconds.

Note you can only connect a maximum of 2 devices at the same time.

Connecting using Audio input

Connect the supplied 3.5mm Audio cable to your Maru and device.

Press play on your device to play your sound on the Maru.

Note that if the Audio cable is plugged in, the Bluetooth function will automatically shut down.

Unplug the audio cable before reconnecting via Bluetooth.

Side LEDs shows your battery level and charging progress. From left to right, each LEDs shows 25%, 50%, 75% and full status.

Troubleshooting

Press the reset button to reset to factory settings.

Drawing showing the button

Make sure Bluetooth is ON on your device.

Make sure you are in range within 10 meters and no obstacles are between your Maru and device.

Make sure your Maru is not out of power.

Please contact our customer service at

support@w-collections.com

with your questions, we will be glad to hear from you.

How can I repair my speaker?

1. Please send an email to support@w-collections.com and explain the issue with your speaker.
2. Our support team will provide you with additional details and detailed instructions.
3. When your parcel is received by our repair center, you will be sent an email.

N.B.: Products returned by carrier without physical protection or badly protected will be under the responsibility of the client.

Federal Communications Commission (FCC) Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by **Ningbo Prosound Electronics Co., Ltd** may void the FCC authorization to operate this device.

Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.