


Start here


Following items are included

Ear hooks

Ear cushions

USB cable

Product overview



Basic operation

Volume control

Press the Volume "+" or "-" to turn volume up or down, you hear beep once reach the maximum or minimum volume.

Status indicator

Instruction	LED status	Voice prompts
Power on	Stays blue 2 seconds	Power on
Power off	Stays red 2 seconds	Power off
Standby	Blink blue twice every 5 seconds	/
Pairing	Flashes Red and Blue alternately	Pairing
Incoming call	Flashes blue continuous	/
Charging	Stays on red while charging, Stays on blue after fully charged	Battery low

Pairing


Pair one phone

1. Press and hold the Multifunction button for about 5 seconds until LED flashes blue and red alternately, you hear "Power on" and "Pairing", now earphone is in pairing mode.

2. Activate Bluetooth on your phone and set it to search for new devices.




3. Select "Muses4": If your phone asks, enter 0000 (four zeros) for the passcode or accept the connection. The LED indicator stops flashing red and blue once successfully paired, you hear "Connection successful". Some phone list an option to "Play through earphone", select to use the earphones.



Pair another phone

Multipoint technology enables you to pair another phone and take a call from either.

To pair with another mobile phone, follow the steps for "Pair one phone". After pairing successfully, restart the earphone to connect to 2 paired mobile phone automatically.



Call

Answer a call

Press the Multifunction button once.

Reject a call

Press and hold the Multifunction button for about 2 seconds.

End a call

Press the Multifunction button once.

Redial the last call

Double-press the Multifunction button in standby mode. The mobile phone will redial the last call number.

Mute on/off

Press the Volume "+" for about 2 seconds to mute on/off.

Switch between the earphone and phone

Press the Volume "+" for about 2 seconds during a call, the call will be switched to the mobile phone, redo this operation again, the call will be switched to the earphone.

End current call and answer new call

When a new call rings during a call, press the Multifunction button once to answer new call and end current call simultaneously.

On hold current call and answer new call

When a new call rings during a call, hold the Multifunction button for 2 seconds to hold current call and answer new call. To switch between hold call and active call, Hold the multifunction button for 2 seconds.

Music

(Need media player support)

Music play / pause

Press Multifunction button once to play / pause music. (Some phones may require you to start a media player first)

Track back/forward

Press the Volume "+" for 2 seconds once to skip track forward, press Volume "-" for 2 seconds once to skip track backward.


Switch Music and Call

When a call rings during a music playing, the music automatically pauses to allow you to answer or ignore the call. Once the call is ignored or ends, the music is resumed.

More features


Battery Indicator

When the earphone is connected to a device with iOS system, a battery indicator will appear at the upper right of the system, indicating battery status of the earphone.



Auto power-off

When the distance between the earphone and the mobile phone is beyond effective range, a voice prompt "Connection lost" and earphone disconnects with the mobile phone, the earphone will power off automatically once no active for 10 minutes.



Automatic connection after powering on

When the earphone and phone have been paired once, they will automatically connect when the earphone is on and Bluetooth is activated on the phone.

Connection standby

After successful pairing and connection, you will hear the voice prompt "Connection successful", the earphone will be in turning on mode or standby mode automatically and the blue LED will flash once every 5 seconds, when the earphone disconnect the phone, you will hear the voice prompt "Connection lost".

Charging

Your earphone has enough power to complete the pairing and a few calls. When battery is low, you will hear the voice prompt "Battery low". It takes 1.5 hours to fully charge the earphone. The red LED turns on during charging. The red LED will turn off and the blue LED will turn on after being fully charged.

Note: The lifetime of the battery will be significantly reduced if your earphona is left uncharged for a long period. We recommend that you recharge your earphone at least once a month.

Hard reset

In turning on mode, press and hold the Multifunction button with the charger plugged to reset the earphone and power off(you can release the Multifunction button 2 seconds after mounting the charger).

canjice

Bluetooth headset

FCC ID:2AAIH-MS04

Muses 4 INSTRUCTION

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.