


User Manual			
LED LIGHT UP SPORT EARBUD	How To Charge Your Bluetooth LED Earbud	FCC statement:	 WARNING:
	• Use the micro USB cable provided with this earbud. • Connect the micro USB plug to micro USB charging port on the earbud, then connect the USB plug to a USB port on a computer or wall adapter to begin charging. • The LED indicator will turn red and the wire will light up while it is being charged and will turn blue once fully charged. NOTE: Earbud can not be charged while playing music. Please charge this earbud when it is not in use. Do not charge in vehicle. You must select a qualified charger from a regular manufacturer. You must charge the bluetooth earbud if it has been not used for more than 3 months. Lower earbud power and / or low audio device power may cause poor operation and / or no Bluetooth connection. 	This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. NOTE This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: • Reorient or relocate the receiving antenna. • Increase the separation between the equipment and receiver. • Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.	• Charge and operate only as indicated in this manual, as improper use may result in damage to the product or injury. • To avoid risk of shock or injury, do not dismantle the device or insert any objects into the earbuds. • To avoid electronic interference and/or compatible conflicts, turn off the product in any facilities where posted notices instruct you to do so. • Do not pull the earbuds charging cable. Damage may result to the cable. • Keep out of reach of children. This is not a toy. • Avoid exposure to moisture, liquids, heat, flame and high voltage equipment. • Retain these instructions as they contain important information. • Do not short circuit the input terminals of the Bluetooth earbuds. • Do not drop, place heavy weight or allow heavy impact to the earbuds. • Do not heat or apply heat or dispose of the in fire. • Do not use the product while driving or crossing the road. RF warning statement: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. FCC ID: 2AAJQGE00058 Distributed by Five Below Merchandising, Inc. 1818 Market Street, Suite 2000 Philadelphia, PA 19103 Made in China Visit Us At: www.fivebelow.com Keep All Relevant Information For Future Reference
Package Contents	Technical Specifications		
• LED Light Up Sport Earbud x1 • Micro USB Charging Cable x1 • User Manual x1	• Model Number: GE00058 MU16003 • Bluetooth Version: V4.2 BR/EDR(NO BLE MODE) • Maximum Bluetooth Distance: 33ft / 10m • Battery Capacity: 80 mAh • Voltage: 3.7 V • Length: 40 cm • Playing Time: 1.5hours • Charging Time: 1.5hours • Charging Way: USB DC 5V • Frequency Response: 20Hz ~ 20KHz		
Power On/Off	FAQ:		
• ON/OFF Short press for pause or play / long press for ON or OFF. • NEXT/V+ Short press for next song / long press to increase volume. • PREV/V- Short press for previous song / long press to reduce volume.	1) Why can't I use my earbud? Answer: Please ensure that the earbud is fully charged for your first use. 2) Why won't sound come out of the earbud? Answer: Check whether the playback device and the earbud are successfully connected. If the audio device is not properly connected, please reconnect. Please also adjust your mobile phone or earbud volume to a suitable volume level. 3) Why can't I find this earbud in my bluetooth options? Answer: Make sure the Bluetooth is in "visible mode". If no pairing occurs, the Bluetooth function will automatically shut off. Please reopen Bluetooth to "visible mode". If there is a program error, please reboot your phone, and if program error is caused by your Bluetooth earbud, please restart the earbud.		
How To Use:			
• Hold down the ON / OFF button for 3-5 seconds, When the LED indicator flashes to blue & red, the Bluetooth function is activated. • Activate the bluetooth function on your phone within range and select "SERIES8 BT BUD" from the list shown. • The blue light will be flashing slowly and you will hear a "beep" sound when it pairs successfully. The wire will follow Bluetooth LED light to flash as well. Long press ON / OFF button for 3 seconds can change the light mode (light up mode / flashing mode). Tips: • The bluetooth earbud will automatically connect with the last successfully paired device when power on. Note: Use the mobile phone to answer a phone call, the Bluetooth Earbud has NO answer incoming call function.			