

BOOK SIZE: 3" W X 3" H (FOLDED)
PAPER: 100 LBS. MAGAZINE PAPER

INKS


K

DO NOT PRINT

CUT LINE

FOLD LINE

10-PANEL FOLD



WHAT'S INCLUDED

- Wireless Speaker
- Charging Cable
- User Manual



SAFETY PRECAUTIONS

- Do not expose to water or extreme temperatures.
- Only use the included charging cable.
- Unplug when fully charged to prolong battery life.
- Keep out of reach of small children.

IMPORTANT NOTICE

This product's specifications, features, and technology may change without prior notice to improve performance and functionality.

GETTING STARTED


CHARGING THE SPEAKER

- 1- Plug the included charging cable into the speaker's charging port (DC5V IN).
- 2- Connect the other end to a USB power source (such as a computer or USB wall adapter).
- 3- Charging takes about 2–3 hours. A full charge gives several hours of playback.

POWER ON/OFF

- Use the switch to turn it On/Off.
- The speaker will start in Bluetooth® mode and search for available Bluetooth® devices to pair for the first time.

CONTROL BUTTONS OVERVIEW



- ① Power Switch: On/Off
- ② Mode: Switch between Bluetooth® / FM / USB
- ③ Play/Pause: Play or scan (FM)
- ④ Next / Previous: Track or station control
>>Press & hold Next/Previous for volume +/-
- ⑤ Light: Change LED modes

BLUETOOTH® MODE

- 1- Turn on the speaker.
- 2- On your phone or device, go to Bluetooth® settings and select the “LESPPR” from the list.
- 3- Once connected, you'll hear a tone or see an indicator light.

To disconnect, turn off Bluetooth® on your device or press the mode button to switch to a different mode.

FM RADIO MODE

- 1- Press the Mode button to switch to FM.
- 2- Press the Play/Pause button to auto-scan and save available stations.
- 3- Use the Next/Previous buttons to change stations.

LIGHT MODES

Press the Light button to cycle through the 5 multicolor animated light modes.

TRUE WIRELESS STEREO (TWS) FUNCTION

TWS mode requires 2 compatible speakers (sold separately)

- 1- Place both speakers in the same room, turn them on in Bluetooth® mode. Do not connect them to your device yet.
- 2- Long-press the MODE button on one of the speakers until you hear a tone. The speakers will sync and enter TWS mode.
- 3- Enable Bluetooth® on your audio device. Search for available devices and select the speaker. In TWS mode, only one speaker name will appear.

To exit TWS mode, long-press the MODE button again.

USB PLAYBACK

- 1- Insert a USB drive with MP3 files into the USB port.
- 2- The speaker will automatically start playing the files.
- 3- Use the buttons to pause, skip, or repeat songs.

SPECIFICATIONS

Speaker Output: 5W*2
Bluetooth® Version: 5.3
Functions: BT/FM/USB/RGB LIGHTS/TWS
Battery: Rechargeable 1500mAh
Frequency: 2400-2483.5MHz
Input: 5V 1A
Charging Port: Micro USB
Charging Time: 3-4 hrs
Play Time: 2 hrs
Waterproof Level: IPX4
Extras: Carrying handle
FCC ID: 2AANZLESPR

FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy. If not installed and used by the instructions, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radiation Exposure Statement
The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.



VIBE™ © DGL GROUP, LTD. ALL RIGHTS RESERVED. Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. No portion of this design or packaging may be reproduced without written permission. Product illustrations and specifications may vary slightly from the actual product. All other trademarks are the property of their respective owners. Distributed by DGL Group, Ltd., Edison, NJ 08817

vibe

USER MANUAL
DG-LESPPR-HOL25

