

100g铜版纸折页，正反面印刷，73.66*76.2 mm

INKS


K

DO NOT PRINT

CUT LINE

FOLD LINE

8-PANEL FOLD



THANK YOU FOR CHOOSING HYPE!

Please read this user manual carefully before using the product and keep it for future reference. Also, make sure your box has the following items:

Package Contents
1 x Wireless Speaker
1 x USB-A to USB-C Charging Cable

SAFETY PRECAUTIONS


- Do not play music at excessive volumes to prevent damage to hearing and the speaker.
- Do not use the speaker in wet or damp environments to avoid damage.

IMPORTANT NOTICE
This product's specifications, features, and technology may change without prior notice to improve performance and functionality.

FUNCTIONS

- 1 Mode/Light Switch**
 - Press to switch between Bluetooth®, FM radio, and TransFlash (TF) modes.
 - Long-press to cycle between light modes.
 - In Bluetooth® mode, press to reject an incoming call.
- 2 Power Button (On/Off)**
 - Long-press to turn the speaker on or off.
- 3 Play/Pause Button**
 - Press to play or pause music.
 - Long-press to activate or deactivate TWS mode. *See TWS section for details.
 - In Bluetooth® mode, press once to answer a call, press again to end it, and double-press to redial the last number.

- 4 Volume Down/Previous Track**
 - Press to play the previous track.
 - Long-press to decrease volume.
- 5 Volume Up/Next Track**
 - Press to play the next track.
 - Long-press to increase volume.
- 6 Animated Lights**
- 9 Hanging Loop**
- 7 Charging Port (USB-C)**
 - Turn off the speaker before charging.
 - Connect the included USB-C cable to a computer or a compatible AC adapter (not included).
 - A red light indicates charging; the light turns off when fully charged.
- 8 TF Card Slot**
 - Insert a memory card (up to 32GB) to play stored audio files.



TRUE WIRELESS STEREO (TWS) FUNCTION
TWS mode requires two compatible speakers (sold separately)

- Place both speakers in the same room and turn them on in Bluetooth® mode. Do not connect them to your device yet.
- Long-press the Play/Pause button on one of the speakers until you hear a tone. The speakers will sync and enter TWS mode.
- Enable Bluetooth® on your audio device. Search for available devices and select the speaker. In TWS mode, only one speaker name will appear.
- To exit TWS mode, long-press the Play/Pause button again.

SPECIFICATIONS

Speaker Output: 5W (x1)	Battery: Rechargeable 500mAh
Bluetooth® Version: 5.3	Charging Port: USB Type-C
Functions: BT/FM/TF/LEDs/Handsfree	Dimensions: 94 cm x 94 cm x43 cm
Charging Time: 1-2 hours	Play Time: 2-3 hours
FCC ID: 2AANZMBTSPKRLP	Weight: 201g
Bluetooth Frequency: 2.402-2.480GHz	

FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy. If not installed and used by the instructions, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

DGL

HYPE is a trademark of DGL Group, LLC. • All other trademarks and trade names are those of their respective owners • BLUETOOTH® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. • No portion of this design may be reproduced without written permission. The illustrated product and specifications may differ slightly from those supplied. Distributed by DGL Group, Ltd. 2045 Lincoln Highway, 3rd Floor, Edison, NJ, 08817, USA.

hype

GLO
LED WIRELESS SPEAKER
POP-MBTSPKRLP

USER MANUAL

Bluetooth®

