



App store

d and open a VR compatible



left and right while you are using the headset. Continue to adjust the focal point until the image comes into focus.

ds until the red & Blue LED stops flashing.

Note: This list is subject to change without notice
release of new apps and technological updates

cartridge with the device's camera aligned to opening.

replace them with working parts free of charge. Hyper reserves the right to exchange the product for

2) Mark the RMA number on the outside of the package in such a way that it is visible and clearly legible.

For questions or comments, please feel free to contact us via email at support@dglusa.com.

1