




OTONE®
OTONE AUDIO

Blufiniti



User Manual




Notice d'utilisation
Benutzerhandbuch
Инструкция




Product Information

Fiche d'information produit




Produktinformationsbroschüre




Информация о продукте






NFC 









Red, Rouge, Rota, Красный



Blue, Bleu, Blau, синий





CAUTION

RISK OF ELECTRIC SHOCK
DO NOT OPEN



**PLEASE
READ
FIRST**

CAUTION: To reduce the risk of electric shock, do not remove the cover. No user serviceable parts inside. Refer to qualified personnel.

WARNING: To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture.



The lightning flash with arrowhead, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electrical shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating maintenance (servicing) instructions in the guide accompanying this device.



Don't throw away the battery with general house waste, dispose of it correctly as chemical waste.

**Disposal of Old Electrical & Electronic Equipment
(Applicable in the European Union and other
European countries with separate collection
systems)**



This symbol on the product or on its packaging indicates that this product shall not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. The recycling of materials will help to conserve natural resources. For more detailed information about recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

CAUTION: Please read these important safety instructions carefully

- **Read Instructions**—All the safety and operating instructions should be read before the unit is operated.
- **Retain Instructions**—The safety and operating instructions should be retained for future reference.
- **Heed Warnings**—All warnings on the unit and in the operating instructions should be adhered to.
- **Follow Instructions**—All operating and use instructions should be followed.

■ **Attachments**—Only use attachments recommended by the manufacturer as non-recommended attachments may cause hazards.

■ **Water and Moisture**—Do not use the unit near water—for example, near a bath tub, wash bowl, kitchen sink, or laundry tub; in a wet basement; or near a swimming pool.

■ The apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the apparatus.

■ **Power-Cord Protection**—Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords where they enter a plug, or exit from the unit.

■ **Lightning**—For added protection for the unit during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect from other devices. This will prevent damage to the unit due to lightning and power-line surges.

■ **Overloading**—Do not overload wall outlets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.

■ **Object and Liquid Entry**—Never push objects of any kind into the unit through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind on the unit.

■ **Damage Requiring Service**—Unplug the unit from the wall outlet and refer servicing to service qualified personnel under the following conditions:

When the power-supply cord or plug is damaged,

If liquid has been spilled, or objects have fallen into the unit,

If the unit has been exposed to rain or water,

If the unit does not operate normally by following the operating instructions,

If the unit has been dropped or damaged in any way, and great care should be exercised in handling, and the unit should be examined by qualified service personnel.

When the unit exhibits a distinct change in performance- this indicates a need for service.

■ **Heat**- The unit should be situated away from heat sources such as radiators, heat registers, stoves, or other units (including amplifiers) that produce heat.

■ **No naked flame sources**, such as lighted candles, should be placed on the apparatus.

This product conforms to all the applicable requirements of the standards EN 60065 (safety), EN 55013 and EN 55020 and as defined by EU Directive 1999/5/EC and is CE-marked accordingly.

This Class B digital apparatus complies with the R&TTE Directive using the essential requirements of EN 300 440-2 and EN 301 489-17.

Please note that this product uses radio frequency bands not harmonized within EU. Within the EU this product is intended to be used in Austria, Belgium, Denmark, Finland, France, Germany, Greece, Ireland, Italy, Luxembourg, The Netherlands, Portugal, Spain, Sweden, United Kingdom and within EFTA in Iceland, Norway and Switzerland.

All features and specifications are subject to change without notice or liability this may be done to upgrade or improve existing designs or features.

The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. and of such marks by OTONE Audio is under license. Other trademarks names are those of their respective owners.

This product is compliant with and adopts the Bluetooth® Specification successfully passed all interoperability tests that are specified in the Bluetooth® specification. However, interoperability between the device and other Bluetooth® -enabled products is not guaranteed.

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Orientate or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC WARNING

Any changes or modifications not expressly approved by the party responsible for compliance could void the users authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

Warranty

1 – DEFINITIONS

The following terms and expressions, shall unless the context requires otherwise, have the meanings set out below:

The Manufacturer: OTONE Audio Limited.

The Purchaser: The original purchaser of the unit.

Unit: The original OTONE Audio speaker system.

UK: The United Kingdom.

The Service Centre: Any body/organisation/sub-contractor whom has been authorised to carry out work on behalf of the manufacturer.

Fault or any other variation of the word: Any manufacturing defects in materials and/or workmanship under normal use.

Opening times: 9am-5pm Monday-Friday, except bank and/or public holidays. Purchaser's Address: The details that appear on the warranty registration.

Return to base: Whereby the purchaser shall be responsible for the safe delivery and all costs associated with the delivery of the unit to the Service Centre.

The manufacturer is ONLY liable for repair and return delivery back to the purchaser.

DOA: Dead On arrival - Units that are faulty on the date of purchase or within the first 30 days after the purchase date.

2 – WARRANTY

OTONE Audio Limited, shall warrant to the purchase of the unit for a period of 2 years from the date of purchase, any unit confirmed as faulty will be either repaired or exchanged at the manufacturer's cost.

3 – PROCEDURE

The warranty procedure set out herewith must be followed strictly by the purchaser. The purchaser is required to contact the Service Centre on the following number :+44 (0)161 924 2269 (UK) during the opening times.

The model number, Serial Number, Fault Description, Purchase Date and Address are required to be supplied to the Service Centre, by the purchaser. The Service Centre will investigate the nature of the fault and validity of the manufacturer warranty. If the unit is determined as faulty and:

Either: A- is within the first 30 days of purchase, the Service Centre will arrange for the faulty unit to be collected (please note the manufacturer does not guarantee a next day or a.m./p.m. collection) and a replacement unit of the same/similar specification will be delivered at the same time to the purchaser's address.

Or: B- is reported after the first 30 days but within the first 2 years of purchase, the purchaser will arrange for the faulty unit to be delivered to the Service Centre. The faulty unit will be repaired within 5 working days from receipt of the faulty unit. Once tested it will be dispatched to the purchaser's address.

Please note the following:

- Should any dispute arise with the purchase date, a copy of the sales receipt will be required to be forwarded by the purchaser to the Service Centre.
- Any unit that is reported as faulty within the DOA period that has been security marked in anyway (e.g. security label, security ink etc.) shall be repaired not replaced.
- OTONE Audio Limited reserves the right to replace any unit with a similar model of the same or better specification without the purchaser's consent.
- DOA units should be reported to the Service Centre within 30 days from date of purchase.
- Deliveries and collections will be arranged during the stated opening times.

Limited Warranty

Please note the warranty is void if any of the following occur:

Any physical damage including but not limited to, cracked PCB's or abused housing and/or bezel, any failure damages due to customers mishandling, improper maintenance or use against the operating instructions, any damage due to misuse, abuse or negligence.

If any alteration/modification has been made to the unit and/or it has been serviced by a person not authorised by the manufacturer.

If any serial number or appliance plate is removed or defaced.

Where no fault is found by the Service Centre on units returned for service, the manufacturer may, at its discretion, charge the customer a handling fee to cover transport and investigation.

The limited warranty is given by OTONE Audio Limited. This limited warranty is only effective upon registration of the unit within 7 days of the purchase date. Please see overleaf for details on product registration.

The manufacturer warrants this product free against any and all manufacturing defects in material and workmanship under normal use and is limited to repair, adjustment and/or replacement free of charge.

The manufacturer does NOT warrant that the product will meet the purchaser's requirements in that the operation of the unit will be uninterrupted or error-free, or that all errors will be corrected. The manufacturer is not responsible for problems caused by changes in the operating characteristics of any device that may be attached to the unit.

The manufacturer will NOT be responsible for any direct, indirect, special, consequential or incidental loss of profits or savings arising out of use or inability to use the unit. In no case shall the manufacturer's liability exceed the purchase value of the unit. This restriction of liability does not affect the purchaser's statutory rights as a consumer or his rights with a distributor/dealer.

PROUDUCT REGISTRATION

Please register your product online with OTONE Audio by visiting www.otoneaudio.com and click on 'Service' and then 'Register your OTONE product'

OTONE Audio Limited
2nd Floor Station House,
Stamford New Road,
Altrincham
Cheshire
WA14 1EP
England

Tel: +44 (0)161 924 2269
Email: support@otoneaudio.co.uk
www.otoneaudio.co.uk

	ATTENTION RISQUE DE DÉCHARGE ÉLECTRIQUE, NE PAS OUVRIR	
À LIRE AVANT TOUTE UTILISATION		
ATTENTION : Afin de réduire le risque de décharge électrique, ne pas démonter. Aucune pièce interne ne nécessite l'intervention de l'utilisateur. Faire appel à un professionnel qualifié. AVERTISSEMENT : Afin de réduire le risque d'incendie ou de décharge électrique, ne pas exposer cet appareil à la pluie ou à l'humidité.   Le triangle équilatéral contenant un éclair terminé par une flèche vise à avertir l'utilisateur de la présence d'une « tension dangereuse » non isolée à l'intérieur du boîtier du produit, cette tension étant suffisamment élevée pour présenter un risque de décharge électrique. Le triangle équilatéral contenant un point d'exclamation vise à avertir l'utilisateur de la présence d'importantes instructions relatives à l'utilisation et à l'entretien (maintenance) dans le guide qui accompagne cet appareil.		

 	Ne pas jeter la batterie avec les déchets ménagers, mais l'éliminer correctement avec les déchets chimiques. Élimination des équipements électriques et électroniques usagés (applicable dans l'Union européenne et dans d'autres pays européens utilisant des systèmes de collecte séparée) Ce symbole apposé sur le produit ou sur son emballage indique que le produit ne doit pas être considéré comme un déchet ménager. Il doit être déposé au point de collecte adéquat assurant le recyclage des équipements électriques et électroniques. En vous assurant que ce produit est éliminé correctement, vous aiderez à prévenir d'éventuelles répercussions négatives sur l'environnement et la santé susceptibles de survenir lors d'une élimination inappropriée du produit. Le recyclage des matériaux permettra de préserver les ressources naturelles. Pour des informations plus détaillées sur le recyclage du produit, veuillez contacter votre service public local, votre service de collecte des déchets ou le magasin où vous avez acheté le produit.
--	---

ATTENTION : Veuillez lire attentivement ces importantes instructions de sécurité.

- Lisez les instructions : ces instructions d'utilisation et de sécurité doivent être lues avant la première utilisation de l'appareil.
- Conservez les instructions : les instructions d'utilisation et de sécurité doivent être conservées à des fins de référence ultérieure.
- Avertissements : tous les avertissements relatifs aux produits indiqués dans les instructions d'utilisation doivent être pris en compte.
- Respectez les instructions : toutes les instructions d'utilisation et de fonctionnement doivent être respectées.