

108mm

WIRELESS MOUSE

PACKAGE CONTENTS

- Wireless Mouse
- USB Receiver
- User's Manual with Warranty Information

FEATURES & SPECIFICATIONS

Radio Frequency: 2.4G Hz
Resolution: 1200 DPI (max)
Power: 3V, 10mA, (2AAA batteries--not included)
Compatibility: Windows XP/7/8/10, MAC OS
Operating Distance: 10 meters
Size: 100*59*36mm

INSERTING BATTERIES

To power your mouse, open the battery compartment located on the bottom of your mouse, and insert 2 AAA batteries (not included). Make sure to insert batteries with the correct polarity (+,-) as displayed in the battery compartment.

SETUP

1. Remove the USB receiver from the bottom of your mouse.
2. Insert the USB receiver into one of your computer's USB ports.
3. Make sure that your computer is powered on.

CAUTION

1. Do not expose your mouse to extreme temperatures.
2. Do not let children or the infirm use your mouse without adult supervision
3. When your mouse is not in use for extended periods, remove the batteries and keep the USB receiver in the storage slot on the bottom of the mouse.

ITEM: TE21-WM-TA

USER'S MANUAL

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

2.4G Wireless Mouse USB Receiver
FCC ID:2AAPK-TE21 FCC ID:2AAPK-TE21R

Sakar One Year Warranty

This warranty covers the original consumer purchaser only and is not transferable.

This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

What Is Not Covered by Warranty

Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.

To Obtain Warranty Service and Troubleshooting Information:
Call 1-877-397-8200 or visit our website at www.sakar.com.



UNIVERSAL
USB RECEIVER



COMFORTABLE
DESIGN