

Net K4

Instructions

FCC ID: 2AAQ2NETK4

Directory

1.2 Installing the SIM card, battery and memory card (SD card)	29
Before installing the replacement battery or SIM card , turn the phone off. SIM card.....	29
Have your phone number , service information and phone book / information recording . For more information about the SIM card , please contact your local network operator.	29
Note: This native Android system supports dual SIM dual standby single-pass mode.	29
Please use original batteries and accessories supplied . Factors that affect battery performance a lot , such as providing wireless service provider system configuration , functions or set the strength of the network signal , the ambient temperature when using the phone performed , the phone is connected to an external device , and how much you voice, data content and usage patterns when executing a program	29
WARNING: To avoid the risk of improper use of the battery caused by fire or combustion :.....	29
• Do not attempt to open , disassemble , or service the battery pack	29
• Do not short-circuit pressure contact with the external device or exposed to fire or water.	30
• Do not expose to temperatures exceeding 50 ° C environment.	30
Required • Use the specified battery replacement.....	30

• in accordance with local government regulations to recycle or dispose of the battery.....	30
Installing and removing the SIM card.....	30
1 turn to the back of the phone , find SIM1 and SIM2 slot position, and then slide the SIM card slot completely . When installing , make sure SIM1 and SIM2 metal contact pads down and note Cutaway direction	30
(2) When you need to remove the SIM card , turn it off , remove other external power supply and battery , and then remove the SIM card.....	30
Installing and removing the memory card	30
Find the memory card slot , the memory card metal contacts facing down , align the notch card slot gap, the memory card into the slot.....	30
1.3 Getting to know your phone	33
The first time you start the phone	33
1 After installing the SIM card and battery , hold the top of the phone 's power button to turn on the phone . The boot mode, press the power button to turn off the screen and lock , press the lighted screen.	33
(2) If you want to shut down , first unlock the phone , and then press the power button , the phone will pop up the Options menu, choose Shut Down , flight mode (offline mode) , silent mode , vibration mode , standard mode.....	33
Using the touch screen.....	33
Your phone supports the following operations. You can operate	

the phone through these actions	33
1 Touch : Touch the desired item with your finger to confirm the selection or launch applications. Touch and hold the screen until the phone responds. For example , in most cases , you can touch and hold the screen to open the options menu the current interface.	33
2 Slide : On the screen , slide your finger horizontally or vertically . For example, you can slide your finger left and right to switch pictures.....	34
3 Drag: Touch and hold your finger desired item , and then drag it to any location on the screen . For example , you can use drag and drop to move or delete the icon on the home screen	34
Note: If you touch and hold some of the interface will display the menu options.	34
4 Zoom: In some applications (such as gallery or browser) , you can view a picture or web page when using two fingers (for example, thumb and index finger) to zoom in on the screen to zoom in or out	34
Lock and unlock the screen	34
Can be locked to prevent accidental operation through the keys and touch screen.	34
1 When the phone is open , press the power button to lock the screen. After a period of inactivity the phone will automatically lock the screen.....	34
Note: When you lock the screen , you can still receive messages and voice calls.	34

2 Press the power button to wake up the screen , and then unlock the screen via the following methods: Follow the instructions displayed on the screen and drag to unlock the screen.....	35
If you have set the screen unlock pattern , you will see to draw graphics on the screen to unlock the screen prompts . For more information, see "Managing Mobile / protect the phone ."	35
PIN protection	35
If your SIM card is preset PIN code , enter the PIN code will see a prompt to use the phone . For more information, see "Managing Mobile / protect the phone ."	35
Note : PIN code may be supplied with the SIM card provided by the network operator. If you lose your PIN , contact your network operator.	35
Replacing Desktop Wallpaper.....	40
1 Touch and hold an empty area of the home screen or in the home screen, press the Menu key and tap Wallpaper.	40
2 Touch wallpaper or gallery to select pictures.	40
2. Enter text	40
When you start a program or select text or numbers you need to enter the field , will appear on-screen keyboard . Use the landscape onscreen keyboard When entering text , you can turn the phone sideways to display the horizontal keyboard , which is more convenient thumb input.	40
NOTE: To automatically change the screen orientation , you need to select the direction of the checkbox (this option Tap the	

application icon - > Settings - > Display) . Landscape keyboard is supported only on the part of the application.	41
Use the keyboard to enter text.....	41
You can enter text via mobile phone screen keypad.	41
Press the Return key to hide the keyboard , touch area can display text or numeric keypad	41
Your phone comes preset a variety of input methods , you can switch to each other , touch the application icon - > Settings - > language and input method, input settings accordingly	41
Edit Text	41
You can enter text using the onscreen keyboard to select , copy or cut operation , and then paste the text into the text field the same program or a different program.	42
1 Press and contains the text you want to select the text field , the selected character will appear below the blue background and the two sides appear to move symbols.	42
Around 2, with the two symbols move your finger to move the cursor to the needs of the selected text , finger off the screen , select the text after the background will be displayed	42
3 Click the first icon displayed on the screen at this time above the "Select All" to select all the contents of the text column	42
After 4 Select the text you want to copy , click on the icon "Copy or Cut" , the selected text will be copied to the clipboard.	43
5 In the same or another application , press and hold your finger	

need to paste the text field until the two mobile symbols.....	43
6 Move your finger to move the cursor to the position you want to paste the text , finger off the screen , text marquee opens.	43
7 Click "Paste ."	43
3. Calls	43
3.1 to open and close the phone function	43
Many countries require a passenger on the aircraft must turn off the phone . Another way to turn off the phone function is to switch your phone to airplane mode (offline mode) . When you enable Airplane Mode , it turns off all wireless radios on your phone, including mobile phones , Bluetooth and WLAN.	44
Enable or disable offline mode	44
Tap the application icon - > Settings - > Wireless & networks. Select "offline mode " check box to enable or disable this mode. When enabled, the status bar will show the offline mode icon . Tip: When you disable offline mode , the phone function is turned back , and restore the previous state of Bluetooth and WLAN	44
Note: In standby screen , open the notification bar , click on the appropriate icon at the top of the screen WLAN, Bluetooth , offline mode functions to open or close operations.	45
3.2 Making a call.....	45
You can contact friends and contacts in many ways , including using the dial pad , contacts and call history.....	45

Voice dialing	45
1 Touch the application icon - > dialing, dialing display panel or on the home screen, click dialing, dialing display panel	45
2 On the screen, touch the desired phone number , enter at the same time , the list will appear in the top of the screen to match the contact or number. Or enter a contact's alphabet or letters , the list can also be displayed this contact.	45
3 Tap the Delete icon to remove the phone number by one digit from behind. Touch and hold the delete icon to clear the entire set of phone numbers.....	46
4 Touch Voice call icon (call) dialing, dialing video calls	46
Dial-up interface options	46
1 , dial-up interface options of two kinds , one is not to enter the number	46
Speed Dial : Set the number keys 2-9 shortcut dial numbers	46
Contact: Click to jump to the contact interface.....	46
Settings: Click to enter the call setup.....	46
2 , enter the number of dial-up interface options.....	46
IP dialing: the IP dialing (provided you have set the relevant SIM card IP dialing prefix)	46
Speed Dial : Set the number keys 2-9 shortcut dial numbers	47
Send SMS : Click to enter text editing interface	47
Add to Contacts : Enter the numbers would have been added to the contact (when dialing the number you have entered the	

interface is not saved to the contact when there is the option, if the input number is saved in the contact does not have this option).....	47
Prolonged pause two seconds : Press the Menu key to select as prolonged pause two seconds after the call 13800138000 and then enter a prolonged pause and then select the input 2 seconds after 2 seconds after entering the outgoing call interface to automatically execute the query feature phone bill	47
Extend the waiting time: If the call 13800138000 press the menu button to select and enter a prolonged wait time , and then enter the option to extend the waiting time after 2 seconds, the call will be prompted to " send the following audio 1,2 ? " Choice after sending perform the corresponding function.	48
Contact: Click to enter the contact.	48
Settings: Click to enter the call setup.....	48
Making a call from Contacts	48
1 Touch the application icon - > contacts, display contact list....	48
2 Touch the desired contact from the list. At this point can also click the search button , the search box enter the contact you want to find a contact name or other keyword.	48
3 Touch the phone number you want to dial	48
Making a call from Call History	49
1 Touch the application icon - > enter dial interface, touch screen above the "Call Log" icon.	49

2 Scroll to select the call log list , tap the phone number you want to dial .	49
3.3 Telephone Answering and hang up	49
When there is an incoming call , drag to the right ' Phone ' icon to answer the phone , and then touch ' " hang up " icon to end the call. When there is an incoming call, press the up or down key the speaker muted.	49
When a call comes in , drag left ' Phone ' icon , you can hang up the call, or drag up ' Phone ' icon hang up calls to that number to send text messages	49
3.4 call for other operations	49
Your phone also supports other calling features that make communication easier and easier (from left to right icon)	50
A dial pad : Click on the icon to bring up the hidden dial	50
2 Hands : Click on this icon to open the function of the sound output from the headphones into the speaker	50
3 Mute: Click on this icon to open the other party can not hear your voice	50
4 Hold: Click on this icon to open after the function call status changes to maintain .	50
5 Add : add a call	50
6 During a call , press the Menu button to enter the recording option to automatically save the contents of the call and start recording after recording after starting only be turned off by the	

call.....	51
7 During the conference call , press the Menu key and touch " management conference call " in the pop-up interface , select one of the parties in private conversations	51
8 To end the conference call and disconnect all callers , tap the ' hang all '	51
Note: To learn whether the network is to provide a conference call feature, please consult the network operator.....	51
3.5 Call Settings.....	51
Dialing or call recording interface , touch the Menu button - > Settings , enter the call settings menu , you can select other settings for voice calls and set accordingly	52
. Voice calls.....	52
Voicemail : You can set the voice mail service , voice mail settings.	52
IP number prefix : After opening this function, enter the IP prefix to set the IP phone	52
Call forwarding : Network services allow you to call certain businesses under certain circumstances be transferred to default on a phone number that you specify . You can set up the phone and cancel the call forwarding feature. The service requires network support , please contact your network provider to open this business . The features include: always , forward on busy , forward on no answer adapter , the adapter can not be switched	

on when the adapter handle different situations , such as the various calls 53

Call restriction : You can set up any combination of the following call restrictions to improve safety. Some network providers may not offer such a service call restriction , the specific use , please contact your network provider. Network providers will offer a four barring password so that you can enable call barring . In this menu, you can make calls to each of the following restrictions: barring all calls, international calls dial ban , the ban on international calls abroad , to reject all calls , reject calls when roaming , to remove all restrictions , change the call barring password 54

Other settings: can the SIM card phone number , call waiting feature set , respectively 54

Video Phone..... 54

Replace local video images : You can set the camera off when the local display to the other pictures. 54

Replace each video : No video display when the other alternative picture..... 55

Replace other video images : You can set the video display when no other party to the local picture..... 55

After opening the camera : This option allows the switch to open the camera 55

The other view is greater than the local view : Open The other

view is greater than the local view.....	55
Automatic fall : After opening this as they do not support video calls, voice calls will automatically fall	55
Make a video call : When turned on the local video display outgoing video calls.	55
Video call: divided display , asking me, do not show , open to display local video interview video phone	55
Other settings : Refer to the phone features voice instructions .	55
Other settings	55
Fixed dialing : You can enable fixed dialing , change the PIN2, set fixed dialing list	56
Call Reminder: setting can be turned on or off , call 50 seconds after opening with a reminder function	56
Quick Reply : re-edit or modify the default reject SMS templates	56
TTY mode : TTY (text telephone) equipment, listening, speaking and actions have impaired ability to dedicated special text phone accessories . Optional accessories TTY devices can be connected to the phone , to make and receive calls . TTY device must be plugged into the headphone jack , and the phone is set for the next three TTY modes in a model work	56
When you set the phone TTY mode , whether or not connected with TTY devices , mobile phones are working in this mode.	56
4. Manage your phone	56

Tap the application icon - > Settings to set up your phone.....	57
Wireless and network	57
SIM card management: SIM card information bar, you can set which SIM cards currently in use ; default SIM card in the column , you can choose voice calls , messages, data connection settings ; in other settings bar, optional on International roaming SIM card contacts and settings	57
WLAN and settings: open WLAN, set up and manage wireless access points.	57
Bluetooth and settings: turn on the Bluetooth , the connection management , device name and detectability	57
Traffic Usage : You can view the SIM card or WLAN traffic usage.	57
Flight mode: Disable all open Wi-Fi	57
VPN: You can manually add, delete, modify add VPN, you must first set the screen lock screen PIN or password , pattern before adding VPN.	58
Network sharing and portable hotspot : You can use WLAN hotspots , USB sharing networks , Bluetooth sharing networks and network sharing and portable hotspot settings.....	58
Mobile network : You can view the data usage, change the network mode, access point name , select a network operator in the network carriers	58
USB Internet : Open this to a shared network Windows PC via a	

USB cable	58
Equipment.....	58
Profiles : Your phone offers a variety of scenarios, so that you can define a ringing phone for different events and environments . First, based on the current scene , choose different scenarios, including standard , silent , meeting , outdoors. Then simply personal profile settings can be manually add profile profile name manually entered by themselves can also click on the bottom right corner of the screen ' reset ' icon restored to default profile settings	59
Display : You can set the phone's lock screen notifications , wallpaper , automatically rotate the screen brightness, font size, dormancy.....	59
Storage: SD card and phone memory view related information display, storage location settings file to SD card or phone memory , SD card can be uninstalled or formatted.....	59
Battery: the battery power usage, state of charge , this interface can open, close, battery percentage display	60
Applications : manage and delete installed applications . View and control the current storage space services and applications used in running	60
Personal	60
Location information access: mobile phone GPS positioning -related functions to be set.....	60

Security:	60
1 Set up screen lock	60
None: Disable screen unlock protected.	60
Slide : Set the slide to unlock.	60
Pattern: If you touch the pattern , the system will guide you to create a pattern , you must draw the pattern to unlock the screen. You will be prompted to draw or re- draw your own pattern . Click the Settings screen unlock pattern , according to the description on the screen, you can customize the unlock pattern. Connecting the screen of at least four points , the pattern can be provided to complete the unlock . At this time , location, and security settings list screen lock into Change screen lock	61
PIN: Enter a numeric PIN to unlock the screen	61
Password: Enter the password to unlock the screen	61
2 Set up SIM card lock : Click Set up SIM card lock , you can turn this feature on . When turned on, you must enter a password to use the phone SIM card . You can also change the original SIM card PIN code	62
3 Visible passwords : open password visible feature, when you enter a password, enter the characters displayed on the screen.	62
4 Select the Device Manager : The device managed accordingly	62
5 Unknown sources : Set whether to allow the installation of non-Market applications provided	62

When set to allow your phone and personal data will be more vulnerable to attack an unknown source applications . You agree that the use of these applications for the resulting damage or loss of handsets take full responsibility	62
6 Trusted Credentials : allow applications to access secure certificates and other credentials.	63
7 from SD card installed : click, install from SD card encryption certificate.	63
8 Clear Credentials: Clear credential storage of all contents	63
Language and input method : select the appropriate language and keyboard settings and select the default input method.	63
Backup and Reset :	63
A backup of my data: open play this application data , WLAN passwords and other settings backed up to Google servers.....	63
2 , the backup account : account settings backup	63
3, automatic restore: After reinstalling an application , the system will restore the backup settings and data.	63
4 , reset DRM: remove all DRM licenses.	64
5 , restore the factory settings : by restoring the factory settings, erase all data on your phone. Clear data include : accounts, system and application data and settings , downloaded applications . Does not delete the data include : the current system software , SD card files, such as music or photos	64
6. Exchange information	70

6.1 SMS MMS	70
You can send text messages (SMS) and multimedia messaging (MMS) to other mobile phones . Maximum number of characters is 160 character messages . If you continue to enter the word limit is reached , will be sent out as an SMS , but accounting for the number of text messages. This is called cascading message.	
MMS also known as multimedia messaging , can contain text and pictures, such as a recording , audio files or pictures.	70
Note : When you add themes or accessories , the phone will automatically be converted to MMS messages	70
Send a text message.....	70
1 Touch the application icon - > Information - > Touch the New icon in the bottom left of the screen to create a new text message.	70
2 Touch " recipient " field , and then enter the phone number you want. After you enter the phone number , matching contacts will appear on the screen. Touch appears recipient or continue entering the recipient's phone number.	71
Or tap the icon next to enter the recipient's contact list , select the desired recipient from the list.	71
3 Touch " type information " field, enter the message content , you can add expression.....	71
4 Tap "Send" (arrow icon) to send text messages via the SIM 1 or SIM card 2 come	71
Send multimedia messages.....	71
1 Touch the application icon - > Information - > Touch the New	

icon in the bottom left of the screen to create a new MMS	71
2 Touch " recipient " field , and then enter the phone number you want.....	71
3 Press the Menu button to display information about the options menu , then touch " Add Theme " added the message subject , message will automatically switch into a multimedia message mode.....	71
4 Touch the screen at the top right of the "plus" icon to add an attachment . You can send multiple files image files, music files and video files.	72
5 If you need to add multiple attachments in the message, select Attach -> Slide -> add slides , select the desired picture.....	72
6 Touch the "send" icon to send multimedia messages via two SIM card 1 or SIM card.....	72
Note : To receive delivery reports and know when to receive MMS messages , in the message list , press the Menu key, then tap "Settings ." Under MMS settings section, select " Send Report " box.....	72
Menu Options.....	72
After entering the information in the dialog browse interface to select press the menu button pops up a dialog to enter the option	72
Select : Select specific information to delete, lock forwards	72
Add Shortcut : You can create a home page shortcut icon	72
Video Phone: make a video call dialing.....	72
Insert common phrases : access to frequently used phrases	

selection interface.....	73
Insert contacts : You can insert contact information , contact information is inserted in the text edit box will be displayed	73
Add Topic : into the theme editor , edit the message will automatically become the theme MMS	73
Chat settings: wallpaper for the session , information notification settings.	73
The information saved as a draft.....	73
When writing a text or multimedia message , press the return key to automatically saved as a draft message. To continue to write the message , tap the message list information , continue to edit the information , and then touch " send " to be sent.	73
Read and reply to a message.....	73
When the phone receives a new text message or multimedia message , which will be played according to different notification settings for ringtones, vibration or briefly in the status bar displays information content.....	73
When you receive a new text or multimedia message in the notification area of the status bar will display the new message icon.....	74
With a contact (or number) and from the text messages and multimedia messages are concatenated into a text message conversation . Concatenate text or multimedia messaging allows you to see a contact to send and receive text messages (similar to a chat program) on the screen. SMS conversations will be listed in order of time of receipt , the latest message at the top of the	

column conversations	74
1 Touch the application icon - > message list displays messages conversation	74
2 Tap the conversation you want to read the information content of the message	74
3 You can enter the content of the message content in the input field, and then touch the "send" reply directly to the sender.	74
Note : Touch multimedia playback button to view the information	74
Forward or delete messages.....	74
1 Touch the application icon - > Information Display message conversation list . Then select the message conversation	75
2 Touch the screen to enter the details of the message , touch and hold the reader 's information , the pop-up menu of options. Touch the "Forward " or " delete ."	75
Note: If you need to delete the message conversation , touch and hold it . Then touch.....	75
Bottom of the screen " delete" icon. To delete the conversation when a certain piece of information , press and hold the message you want to delete , and then touch the options menu 'Delete' , a confirmation prompt appears , touch the "Delete ."	75
Other operations	75
Tap the application icon - > Information Display message conversation list . You can press the Menu key to open the options panel , and then do one of the following options :.....	75
• Touch the "Delete all sessions " Delete all current conversation .	

.....	75
• Touch the "Settings" to set the information function.	76
• Touch "push information " to operate the push message.....	76
Information Set.....	76
In the message list screen, press the Menu key and tap "Settings ."	
.....	76
You can set text or multimedia message options. Set the following options are available :.....	76
1 Select the basic settings , you can do the following:	76
Wallpaper : You can set a background picture session	76
Information Font Size : Set the size of the message text is displayed	76
Show E-mail address : Turn this when selecting contacts, e-mail address will be included	76
Delete old messages : the limit is reached when the amount of information that can automatically delete old messages.	76
SMS limitations: Display the current number of messages per session maximum storage . After deleting old information menu is selected, you can specify the number of messages you want to save the settings.....	77
MMS limit : Displays the number of current maximum storage per session MMS . After deleting old information menu is selected, you can specify the number of MMS settings to be saved	77
Cell Broadcast : This feature with the operators concerned	77
Open the WAP PUSH: Set whether to receive service	

information	77
2 SMS settings.....	77
Required to send reports : Select this option to receive a delivery report for sending status information	77
Manage SIM card information : Displays information stored in the SIM	77
Editing common phrases : Edit common phrases to use when writing new information.....	77
Short Message Service Center : You can view or edit the message service center number.....	78
SMS storage location : Set SMS storage location (phone or SIM card)	78
3 MMS settings	78
Message : Use MMS to send a single message to multiple recipients	78
Required to send reports : Select this option to receive a delivery report for sending status information	78
Read the report required : Select this option to receive read the report, to find out if your recipient has read the message or the information will be deleted unread	78
Allowed to return to read reports : Turn this option, each time new information after reading , allow automatic return to read the report	78
Automatic acquisition : Select this option to automatically retrieve all your MMS messages. When this option is selected , will automatically multimedia information header , body, and	

attachments downloaded to the phone. If you clear this check box , only the retrieval of multimedia information in the message header and displays the list	79
Roaming auto acquisition: Select this option to automatically retrieve all your MMS messages when roaming, but the sharp rise in this action may make the data connection costs.....	79
Creation mode : Set the desired mode of preparation of MMS .	79
MMS size limits : You can set the size of MMS messages	79
Priority: set the priority level of the current MMS	79
4 . Notification settings.....	79
Notice : If you want when you receive a new text or multimedia message letter notification in the status bar , select this option. .	79
Mute: on, off mute settings, no beep when to information	80
Select ringtone : If you want the phone to ring when you receive a new message , touch this option and then select the new text and multimedia messages Jane exclusive ringtones. Please note that the ring tone briefly plays when selected.....	80
Vibration: vibration switch setting to information	80
Pop-up message prompts : Are pop-up box is set to the information	80
Care and Maintenance.....	98
Battery Handling Precautions.....	98
• The phone is a rechargeable battery as a power source. When power is weak, the battery charging. To preserve battery life , the best before charging the battery power runs out	98

• When the battery charger is not in use , keep it separate from the power supply source. Do not connect the charger and the battery more than a week , overcharging will shorten battery life.

..... 98

• Temperature limits of the battery can affect the charging . So before charging , the battery may need to look cool or warm . If the battery temperature exceeds 50 degrees Celsius, the battery will not charge. 98

• Keep the battery on its original purpose , to avoid short circuit. When connected directly to the conductive material can cause a short circuit battery positive and negative 98

• Do not use damaged batteries..... 99

• The battery in extremely hot or extremely cold places will result in shorter battery life , the battery is exposed to cold or hot places may cause the phone feature does not work properly , even when the battery fully charged , too. 99

• Do not expose the battery to fire , do not waste batteries thrown away , please send battery recycling , please follow local regulations for disposal of batteries !..... 99

Mobile Maintenance 99

The following suggestions will help take care of your mobile phone : 99

• phone with all accessories away from children to touch the place 99

• Please keep the body dry and liquid metal circuit will cause corrosion	99
• Keep the body away from heat, high temperatures will shorten the life of electronic devices , so that the plastic melt and damage the battery.....	99
• Do not attempt to open the cabinet or phone disintegration , non-professional demolition may cause damage to the body	99
• Do not use strong acid or alkaline detergents to clean the body .	100
• Use only original mobile phone accessories. Violation of these will void the warranty.....	100
SAR.....	100
Mobile phones use electromagnetic radiation Specific Absorption Rate (SAR) is the unit of measurement . According to the National	100
Standard , SAR limit is 2.0W/Kg. SAR tests when using standard operating positions shift.....	100
Mobile phones , mobile phones transmit at the highest power level . Although SAR is determined using	100
Maximum power level , the actual use of the mobile phone may be lower than the maximum SAR	100
This is because the mobile phone is designed to use the minimum power required to reach the network . Through.....	100
In general, the closer the lower power output of mobile phones .	

.....	100
This product is electromagnetic radiation Specific Absorption Rate (SAR) a maximum of ** W / Kg, in line with national standards	100
Requirements of GB 21288-2007	101
SAR values at various locations there will be some differences, they all conform to the limits prescribed by the State	101
Requirements. Please note that this product may cause improvements in SAR value differences after the product ;	101
In any case, the product must be designed within the standard limits	101

Note: The images used in the specification described in this manual is only used if the phone does not match, please phone the actual display prevail.

1 Preparing for use

1.1 Schematic appearance and KEYS

Description : Appearance is for reference only , please prevail in kind

1 Power button (located on the right side of the phone) : Press to turn on or turn the phone off .

In any screen , press the backlight button to turn off the phone and locked , and then you turn on your phone background lights.

2 front camera

(3) the volume keys (located on the left phone) : increase or decrease the ringer or media volume.

- You can adjust the ringer volume on the main screen or any application program interface (except during a call or play radio / music / video) . Press the phone volume keys (up and down the side keys) to adjust the ringer volume to your desired . Ringer volume window appears on the screen , display the volume . If the lowest ringer volume , press **VOLUME DOWN** once to set your phone to vibrate mode , the phone will vibrate and the

vibration mode icon will be displayed on the status bar.

Tip: To quickly switch your phone to vibrate mode , press the power button , and then touch the options menu in silent mode . You can also adjust the ringer volume on the Settings screen. To adjust the volume , open the application icon - > Settings - > Profiles - > Volume .

- When playing radio, music or watching video , press the phone's volume keys (up and down the side keys) to adjust the media volume. Will appear radio / music / video volume window on the screen to display the volume .

4 function buttons located below the screen (left to right) :

Menu key : open the current screen menu.

HOME key : Direct return to the main screen interface , long press the home key to enter the list of recently run applications .

Back key : return to the previous screen or exit a running program .

5 After the camera

1.2 Installing the SIM card, battery and memory card (SD card)

Before installing the replacement battery or SIM card , turn the phone off. SIM card

Have your phone number , service information and phone book / information recording . For more information about the SIM card , please contact your local network operator.

Note: This native Android system supports dual SIM dual standby single-pass mode.

Please use original batteries and accessories supplied . Factors that affect battery performance a lot , such as providing wireless service provider system configuration , functions or set the strength of the network signal , the ambient temperature when using the phone performed , the phone is connected to an external device , and how much you voice, data content and usage patterns when executing a program .

WARNING: To avoid the risk of improper use of the battery caused by fire or combustion :

- Do not attempt to open , disassemble , or service the battery pack .

- Do not short-circuit pressure contact with the external device or exposed to fire or water.
- Do not expose to temperatures exceeding 50 ° C environment.

Required • Use the specified battery replacement.

- in accordance with local government regulations to recycle or dispose of the battery.

Installing and removing the SIM card

1 turn to the back of the phone , find SIM1 and SIM2 slot position, and then slide the SIM card slot completely . When installing , make sure SIM1 and SIM2 metal contact pads down and note Cutaway direction .

(2) When you need to remove the SIM card , turn it off , remove other external power supply and battery , and then remove the SIM card.

Installing and removing the memory card

Find the memory card slot , the memory card metal contacts facing down , align the notch card slot gap, the memory card into the slot.

Battery installation and removal

1 After inserting the SIM card and memory card, install the battery. The battery terminal of the battery bay copper interface copper contact tip, then carefully placed in the battery.

After the battery cover on the housing and push down until it is completely fit with the phone.

2 Make sure the phone is turned off before removing the battery. Lift up and remove the cover, lift up from the lower end of the battery, and then remove the battery.

1.2 Battery Charging

Supplied fresh batteries have some margin of power, we recommend that before you start using your phone, install the battery and charging ahead. After several full charge and completely exhausted repeated use, battery performance will reach the best condition. There are two ways to charge:

- Use the AC power cord to connect the phone and power.
- Use the USB sync cable to connect your phone and computer.

Tip: Use the supplied AC power cord and USB sync

cable to charge the phone battery.

Mobile devices when charging, a charging icon will be displayed on the main screen interface in the status column.

After the battery is fully charged, the status bar interface in today's power icon displays the full grid.

WARNING! ! • Do not remove the battery charging status.

- Based on the principles of safety, when the battery overheating happens, stop charging.

1.3 Getting to know your phone

The first time you start the phone

1 After installing the SIM card and battery , hold the top of the phone 's power button to turn on the phone . The boot mode, press the power button to turn off the screen and lock , press the lighted screen.

(2) If you want to shut down , first unlock the phone , and then press the power button , the phone will pop up the Options menu, choose Shut Down , flight mode (offline mode) , silent mode , vibration mode , standard mode.

Using the touch screen

Your phone supports the following operations. You can operate the phone through these actions .

1 Touch : Touch the desired item with your finger to confirm the selection or launch applications. Touch and hold the screen until the phone responds. For example , in most cases , you can touch and hold the screen to open the options menu the current interface.

2 Slide : On the screen , slide your finger horizontally or vertically . For example, you can slide your finger left and right to switch pictures.

3 Drag: Touch and hold your finger desired item , and then drag it to any location on the screen . For example , you can use drag and drop to move or delete the icon on the home screen .

Note: If you touch and hold some of the interface will display the menu options.

4 Zoom: In some applications (such as gallery or browser) , you can view a picture or web page when using two fingers (for example, thumb and index finger) to zoom in on the screen to zoom in or out .

Lock and unlock the screen

Can be locked to prevent accidental operation through the keys and touch screen.

1 When the phone is open , press the power button to lock the screen. After a period of inactivity the phone will automatically lock the screen.

Note: When you lock the screen , you can still receive messages and voice calls.

2 Press the power button to wake up the screen , and then unlock the screen via the following methods: Follow the instructions displayed on the screen and drag to unlock the screen.

If you have set the screen unlock pattern , you will see to draw graphics on the screen to unlock the screen prompts . For more information, see "Managing Mobile / protect the phone ."

PIN protection

If your SIM card is preset PIN code , enter the PIN code will see a prompt to use the phone . For more information, see "Managing Mobile / protect the phone ."

Note : PIN code may be supplied with the SIM card provided by the network operator. If you lose your PIN , contact your network operator.

1.4 Home Interface

Drag your finger touch and hold the desired item, and then drag it to any location on the screen. For example, you can use drag and drop to move or delete the icon on the home screen.

A notification area of the status bar: Displays the phone's notification icon.

- 2 Status column area: Displays phone status icons.
- 3 Display area: Touch the icon to open the associated application.
- 4 application icons: Touch to open and select the application.

Status Icons

	Network signal strength		A general notice
	EDGE is connected, is using EDGE		Play music
	Voice call in progress		Connected WLAN network
	Call forwarding is turned		Flight mode
	Missed calls		Silent mode
	New SMS or MMS message		Vibration mode
	Alarm is turned		Low battery is very low

	Bluetooth is turned on		The battery is charging
	Connected to PC		The headset is connected

Use the notifications panel

Notification will display a new message, calendar events and ongoing activities, such as call forwarding or the current call status. You can also open the Notifications panel to see the network operator, or open the message, reminder, or event notification. When a new notification icon appears in the status bar notification area when, touch and hold the status bar, then slide your finger downward to open the Notifications panel. You can perform the following actions in the notification panel:

- Touch a notification to open the related application.
- Touch Clear to clear all notifications notice.

- Touch and hold the bottom of the panel, then slide up to close the Notifications panel.

Using the application icon

The application icons have all the applications on your phone. Touch the application icon to open it, touch the back button below the screen, HOME button to close it and return to the home page.

Extended Home screen

Home screen extends beyond the screen width to provide more space to add shortcuts , widgets , and more projects . On the Home screen, slide your finger across the screen , you can move to the left or right side of the extended Home interface.

New home screen icon

1 Tap the application icon , enter the main menu , slide right into the widget page ;
2 Select the item you want to add to the home screen , touch and hold the selected item , when the phone vibrates, the items on a blank area on the Home screen .

Note: On the application icon , you can also touch and hold an application icon.

When the phone vibrates , the icon into the blank area on the Home screen .

Mobile Home screen icon

1 Touch and hold an icon on the Home screen until the icons zoom and the phone vibrates .

2 Press and hold your finger does not move , drag the icon to the desired location on the screen , then lift your finger to leave.

Remove the Home screen icon

1 Touch and hold an icon on the Home screen until the icons zoom and the phone vibrates .

2 Press and hold your finger does not move , drag the icon to delete the icon until the icons and application icon turns red , then your finger off .

Replacing Desktop Wallpaper

1 Touch and hold an empty area of the home screen or in the home screen, press the Menu key and tap Wallpaper.

2 Touch wallpaper or gallery to select pictures.

2. Enter text

When you start a program or select text or numbers you need to enter the field , will appear on-screen keyboard . Use the landscape onscreen keyboard When entering text , you can turn the phone sideways to display the horizontal keyboard , which is more convenient thumb input.

NOTE: To automatically change the screen orientation , you need to select the direction of the checkbox (this option Tap the application icon - > Settings - > Display) . Landscape keyboard is supported only on the part of the application.

Use the keyboard to enter text

You can enter text via mobile phone screen keypad.

Press the Return key to hide the keyboard , touch area can display text or numeric keypad .

Your phone comes preset a variety of input methods , you can switch to each other , touch the application icon - > Settings - > language and input method, input settings accordingly .

Edit Text

You can enter text using the onscreen keyboard to select , copy or cut operation , and then paste the text into the text field the same program or a different program.

1 Press and contains the text you want to select the text field , the selected character will appear below the blue background and the two sides appear to move symbols.

Around 2, with the two symbols move your finger to move the cursor to the needs of the selected text , finger off the screen , select the text after the background will be displayed .

3 Click the first icon displayed on the screen at this time above the "Select All" to select all the contents of the text column .

After 4 Select the text you want to copy , click on the icon "Copy or Cut" , the selected text will be copied to the clipboard.

5 In the same or another application , press and hold your finger need to paste the text field until the two mobile symbols.

6 Move your finger to move the cursor to the position you want to paste the text , finger off the screen , text marquee opens.

7 Click "Paste ."

3. Calls

3.1 to open and close the phone function

Many countries require a passenger on the aircraft must turn off the phone . Another way to turn off the phone function is to switch your phone to airplane mode (offline mode) . When you enable Airplane Mode , it turns off all wireless radios on your phone, including mobile phones , Bluetooth and WLAN.

Enable or disable offline mode

Tap the application icon - > Settings - > Wireless & networks. Select "offline mode " check box to enable or disable this mode. When enabled, the status bar will show the offline mode icon . Tip: When you disable offline mode , the phone function is turned back , and restore the previous state of Bluetooth and WLAN .

Note: In standby screen , open the notification bar , click on the appropriate icon at the top of the screen WLAN, Bluetooth , offline mode functions to open or close operations.

3.2 Making a call

You can contact friends and contacts in many ways , including using the dial pad , contacts and call history.

Voice dialing

1 Touch the application icon - > dialing, dialing display panel or on the home screen, click dialing, dialing display panel .

2 On the screen, touch the desired phone number , enter at the same time , the list will appear in the top of the screen to match the contact or number. Or enter a contact's alphabet or letters , the list can also be displayed this contact.

3 Tap the Delete icon to remove the phone number by one digit from behind. Touch and hold the delete icon to clear the entire set of phone numbers.

4 Touch Voice call icon (call) dialing, dialing video calls .

Dial-up interface options

1 , dial-up interface options of two kinds , one is not to enter the number

Speed Dial : Set the number keys 2-9 shortcut dial numbers .

Contact: Click to jump to the contact interface.

Settings: Click to enter the call setup.

2 , enter the number of dial-up interface options

IP dialing: the IP dialing (provided you have set the relevant SIM card IP dialing prefix)

Speed Dial : Set the number keys 2-9 shortcut dial numbers .

Send SMS : Click to enter text editing interface .

Add to Contacts : Enter the numbers would have been added to the contact (when dialing the number you have entered the interface is not saved to the contact when there is the option, if the input number is saved in the contact does not have this option)

Prolonged pause two seconds : Press the Menu key to select as prolonged pause two seconds after the call 13800138000 and then enter a prolonged pause and then select the input 2 seconds after 2 seconds after entering the outgoing call interface to automatically execute the query feature phone bill .

Extend the waiting time: If the call 13800138000 press the menu button to select and enter a prolonged wait time , and then enter the option to extend the waiting time after 2 seconds, the call will be prompted to " send the following audio 1,2 ? " Choice after sending perform the corresponding function.

Contact: Click to enter the contact.

Settings: Click to enter the call setup.

Making a call from Contacts

1 Touch the application icon - > contacts, display contact list.

2 Touch the desired contact from the list. At this point can also click the search button , the search box enter the contact you want to find a contact name or other keyword.

3 Touch the phone number you want to dial .

Making a call from Call History

- 1 Touch the application icon - > enter dial interface, touch screen above the "Call Log" icon.
- 2 Scroll to select the call log list , tap the phone number you want to dial .

3.3 Telephone Answering and hang up

When there is an incoming call , drag to the right ' Phone ' icon to answer the phone , and then touch ' " hang up " icon to end the call. When there is an incoming call, press the up or down key the speaker muted.

When a call comes in , drag left ' Phone ' icon , you can hang up the call, or drag up ' Phone ' icon hang up calls to that number to send text messages .

3.4 call for other operations

Your phone also supports other calling features that make communication easier and easier (from left to right icon) .

A dial pad : Click on the icon to bring up the hidden dial.

2 Hands : Click on this icon to open the function of the sound output from the headphones into the speaker .

3 Mute: Click on this icon to open the other party can not hear your voice.

4 Hold: Click on this icon to open after the function call status changes to maintain .

5 Add : add a call

6 During a call , press the Menu button to enter the recording option to automatically save the contents of the call and start recording after recording after starting only be turned off by the call.

7 During the conference call , press the Menu key and touch " management conference call " in the pop-up interface , select one of the parties in private conversations .

8 To end the conference call and disconnect all callers , tap the ' hang all ' .

Note: To learn whether the network is to provide a conference call feature, please consult the network operator.

3.5 Call Settings

Dialing or call recording interface , touch the Menu button - > Settings , enter the call settings menu , you can select other settings for voice calls and set accordingly

. Voice calls

Voicemail : You can set the voice mail service , voice mail settings.

IP number prefix : After opening this function, enter the IP prefix to set the IP phone .

Call forwarding : Network services allow you to call certain businesses under certain circumstances be transferred to default on a phone number that you specify . You can set up the phone and cancel the call forwarding feature. The service requires network support , please contact your network provider to open this business . The features include: always , forward on busy , forward on no answer adapter , the adapter can not be switched on when the adapter handle different situations , such as the various calls .

Call restriction : You can set up any combination of the following call restrictions to improve safety. Some network providers may not offer such a service call restriction , the specific use , please contact your network provider. Network providers will offer a four barring password so that you can enable call barring . In this menu, you can make calls to each of the following restrictions: barring all calls, international calls dial ban , the ban on international calls abroad , to reject all calls , reject calls when roaming , to remove all restrictions , change the call barring password .

Other settings: can the SIM card phone number , call waiting feature set , respectively .

Video Phone

Replace local video images : You can set the camera off when the local display to the other pictures.

Replace each video : No video display when the other alternative picture.

Replace other video images : You can set the video display when no other party to the local picture.

After opening the camera : This option allows the switch to open the camera .

The other view is greater than the local view : Open The other view is greater than the local view.

Automatic fall : After opening this as they do not support video calls, voice calls will automatically fall .

Make a video call : When turned on the local video display outgoing video calls.

Video call: divided display , asking me, do not show , open to display local video interview video phone .

Other settings : Refer to the phone features voice instructions .

Other settings

Fixed dialing : You can enable fixed dialing , change the PIN2, set fixed dialing list .

Call Reminder: setting can be turned on or off , call 50 seconds after opening with a reminder function .

Quick Reply : re-edit or modify the default reject SMS templates .

TTY mode : TTY (text telephone) equipment, listening, speaking and actions have impaired ability to dedicated special text phone accessories . Optional accessories TTY devices can be connected to the phone , to make and receive calls . TTY device must be plugged into the headphone jack , and the phone is set for the next three TTY modes in a model work .

When you set the phone TTY mode , whether or not connected with TTY devices , mobile phones are working in this mode.

4. Manage your phone

Tap the application icon - > Settings to set up your phone.

Wireless and network

SIM card management: SIM card information bar, you can set which SIM cards currently in use ; default SIM card in the column , you can choose voice calls , messages, data connection settings ; in other settings bar, optional on International roaming SIM card contacts and settings .

WLAN and settings: open WLAN, set up and manage wireless access points.

Bluetooth and settings: turn on the Bluetooth , the connection management , device name and detectability .

Traffic Usage : You can view the SIM card or WLAN traffic usage.

Flight mode: Disable all open Wi-Fi .

VPN: You can manually add, delete, modify add VPN, you must first set the screen lock screen PIN or password , pattern before adding VPN.

Network sharing and portable hotspot : You can use WLAN hotspots , USB sharing networks , Bluetooth sharing networks and network sharing and portable hotspot settings.

Mobile network : You can view the data usage, change the network mode, access point name , select a network operator in the network carriers .

USB Internet : Open this to a shared network Windows PC via a USB cable .

Equipment

Profiles : Your phone offers a variety of scenarios, so that you can define a ringing phone for different events and environments . First, based on the current scene , choose different scenarios, including standard , silent , meeting , outdoors. Then simply personal profile settings can be manually add profile profile name manually entered by themselves can also click on the bottom right corner of the screen ' reset ' icon restored to default profile settings .

Display : You can set the phone's lock screen notifications , wallpaper , automatically rotate the screen brightness, font size, dormancy.

Storage: SD card and phone memory view related information display, storage location settings file to SD card or phone memory , SD card can be uninstalled or formatted.

Battery: the battery power usage, state of charge , this interface can open, close, battery percentage display .

Applications : manage and delete installed applications . View and control the current storage space services and applications used in running .

Personal

Location information access: mobile phone GPS positioning -related functions to be set.

Security:

1 Set up screen lock

None: Disable screen unlock protected.

Slide : Set the slide to unlock.

Pattern: If you touch the pattern , the system will guide you to create a pattern , you must draw the pattern to unlock the screen. You will be prompted to draw or re- draw your own pattern . Click the Settings screen unlock pattern , according to the description on the screen, you can customize the unlock pattern. Connecting the screen of at least four points , the pattern can be provided to complete the unlock . At this time , location, and security settings list screen lock into Change screen lock .

PIN: Enter a numeric PIN to unlock the screen .

Password: Enter the password to unlock the screen .

2 Set up SIM card lock : Click Set up SIM card lock , you can turn this feature on . When turned on, you must enter a password to use the phone SIM card . You can also change the original SIM card PIN code .

3 Visible passwords : open password visible feature, when you enter a password, enter the characters displayed on the screen.

4 Select the Device Manager : The device managed accordingly .

5 Unknown sources : Set whether to allow the installation of non-Market applications provided . When set to allow your phone and personal data will be more vulnerable to attack an unknown source applications . You agree that the use of these applications for the resulting damage or loss of handsets take full responsibility .

6 Trusted Credentials : allow applications to access secure certificates and other credentials.

7 from SD card installed : click, install from SD card encryption certificate.

8 Clear Credentials: Clear credential storage of all contents .

Language and input method : select the appropriate language and keyboard settings and select the default input method.

Backup and Reset :

A backup of my data: open play this application data , WLAN passwords and other settings backed up to Google servers.

2 , the backup account : account settings backup .

3, automatic restore: After reinstalling an application , the system will restore the backup settings and data.

4 , reset DRM: remove all DRM licenses.

5 , restore the factory settings : by restoring the factory settings, erase all data on your phone.

Clear data include : accounts, system and application data and settings , downloaded applications . Does not delete the data include : the current system software , SD card files, such as music or photos .

Account

Add Account: You can add Google, the company, three types of e-mail accounts.

After login account, this account has been added to show.

System

Date and Time : Enter this menu to set the date and time. Can set the date , select the time zone , set the time to set up the operation . Set to open or close the 24- hour format feature, you can format the time display settings ; enter the selected date format, you can select your favorite date display format , but also can automatically determine the date and time, time zone via the network.

Timer switch : switch were set time and date , set up and turned on, when the appropriate time comes , I will follow the switch settings

and perform operations boot or shutdown actions.

Accessibility

Press the " Power " button to end the call : When turned on, during a call, press the power button to end a call instead of turning off the screen.

About phone : view phone status , power usage and other information.

5 Contacts

Contacts allows you to save and manage contact information such as phone numbers and addresses . You can use the information stored in your phone . Contacts application allows you to easily find people who want to contact .

Tap the application icon - > Contacts, or in the main interface, click the Contacts icon . Contact list will show the contact's name . Touch a contact to open the contact details screen. Touch and hold the contact you can open the Options menu or click the menu key to access the touch screen options menu .

Create a new contact

New contacts on the phone

- 1 Touch the application icon - > Contacts, contacts list appears.
- 2 Touch the bottom right of the screen to add a list of icons .
- 3 New Contact screen , enter all the information stored for that contact in , slide down to move between fields.
- 4 Upon completion of touch "Done" to save the contact, or press the Menu key and then touch " abandon " to give up to save the contact.

Copy contacts

You can copy stored on the SIM card , phone or SD card contacts to the appropriate storage location.

1 Touch the application icon - > Contacts, the contact list is displayed.

2 Press the Menu key , then tap "Import / Export" , you can choose to copy the address book from a different storage location records to another storage location .

Add to Favorites Contact

You can select a specific group in your contact list , for example, contacts with phone numbers , manage contacts and more convenient.

In the contact list , tap phone contacts into the contact details screen , tap the star icon top right , star icon from gray to white. At this point the contact will be added to the contact list on the Favorites icon .

Edit contact information

You can always change the contact information stored .

1 Touch the contact you want to modify the contact list, enter the contact details screen.

2 Press the Menu key and tap "Edit ."

3 Edit the contact information and tap "Done ." To ignore all changes made to the contact information , press the Menu key and select " abandon " to abandon modify the contact.

Find a contact

If the contact list is long, there are several ways to find a contact .

- Slide your finger up or down the screen to browse your contacts.
- On the contact interface , the touch screen bottom left of the "Search" icon pop-up text box , enter the contact's name you want to find or letters , the screen will display a list of matching contacts .

Groups

To left to enter the group interface

New: Add a group to the phone or SIM card, you can specify a group member in the new group. Touch the upper left corner of the completion of 'Finish ' to save the group or 'Cancel ' to discard group.

Modify : Modify group information .

Delete: Delete group.

Contact list options

Delete Contact : Select the designated

contact can be deleted.

Contacts to display: Specify all contacts or SIM, phone contacts and display custom contact .

Import / export contacts : You can import contacts from a SIM card to export mobile phone, account number, phone contacts to the SIM card , SD card , phone memory , or import from storage to the phone .

Account : You can open, close automatically synchronize application data.

Share visible contacts : Select the designated contact can share contacts via Bluetooth , MMS , information , memory cards, e-mail and other means.

Contact details of the interface menu options

Review: edit contact information .

Share : You can share the contacts via Bluetooth, MMS, message , card, e-mail and other means.

Delete : Delete the contact.

Set the tone : set the ringtone to the contact .

Automatically reject a call : open the item,

this contact does not display incoming caller interface .

Placed on the main screen : Create a shortcut icon for the contact on the main screen .

In the contact details of the contact interface, you can click the icon to set (photos , select a photo from the gallery) contact picture , click on the icon to the upper right corner contacts Collection (only contacts stored on the phone , the account only favicons) , Click on the top left corner on a contact name is returned , touch click phone numbers for voice dialing, click the icon to make a video call dialing, click on the icon to enter the editing interface information send a message .

6. Exchange information

6.1 SMS MMS

You can send text messages (SMS) and multimedia messaging (MMS) to other mobile phones . Maximum number of characters is 160 character messages . If you continue to enter the word limit is reached , will be sent out as an SMS , but accounting for the number of text messages. This is called cascading message.

MMS also known as multimedia messaging , can contain text and pictures, such as a recording , audio files or pictures.

Note : When you add themes or accessories , the phone will automatically be converted to MMS messages .

Send a text message

1 Touch the application icon - > Information - > Touch the New icon in the bottom left of the screen to create a new text message.

2 Touch " recipient " field , and then enter the phone number you want. After you enter the phone number , matching contacts will appear on the screen. Touch appears recipient or continue entering the recipient's phone number.

Or tap the icon next to enter the recipient's contact list , select the desired recipient from the list.

3 Touch " type information " field, enter the message content , you can add expression.

4 Tap "Send" (arrow icon) to send text messages via the SIM 1 or SIM card 2 come .

Send multimedia messages

1 Touch the application icon - > Information - > Touch the New icon in the bottom left of the screen to create a new MMS .

2 Touch " recipient " field , and then enter the phone number you want.

3 Press the Menu button to display information about the options menu , then touch " Add Theme " added the message subject , message will automatically switch into a multimedia message mode.

4 Touch the screen at the top right of the "plus" icon to add an attachment . You can send multiple files image files, music files and video files.

5 If you need to add multiple attachments in the message, select Attach - > Slide - > add slides , select the desired picture.

6 Touch the "send" icon to send multimedia messages via two SIM card 1 or SIM card.

Note : To receive delivery reports and know when to receive MMS messages , in the message list , press the Menu key, then tap "Settings ." Under MMS settings section, select " Send Report " box.

Menu Options

After entering the information in the dialog browse interface to select press the menu button pops up a dialog to enter the option .

Select : Select specific information to delete, lock forwards .

Add Shortcut : You can create a home page shortcut icon .

Video Phone: make a video call dialing.

Insert common phrases : access to frequently used phrases selection interface.

Insert contacts : You can insert contact information , contact information is inserted in the text edit box will be displayed .

Add Topic : into the theme editor , edit the message will automatically become the theme MMS .

Chat settings: wallpaper for the session , information notification settings.

The information saved as a draft

When writing a text or multimedia message , press the return key to automatically saved as a draft message. To continue to write the message , tap the message list information , continue to edit the information , and then touch " send " to be sent.

Read and reply to a message

When the phone receives a new text message or multimedia message , which will be played according to different notification settings for ringtones, vibration or briefly in the status bar displays information content.

When you receive a new text or multimedia message in the notification area of the status bar will display the new message icon.

With a contact (or number) and from the text messages and multimedia messages are concatenated into a text message conversation . Concatenate text or multimedia messaging allows you to see a contact to send and receive text messages (similar to a chat program) on the screen. SMS conversations will be listed in order of time of receipt , the latest message at the top of the column conversations .

- 1 Touch the application icon - > message list displays messages conversation .

- 2 Tap the conversation you want to read the information content of the message .

- 3 You can enter the content of the message content in the input field, and then touch the "send" reply directly to the sender.

Note : Touch multimedia playback button to view the information .

Forward or delete messages

1 Touch the application icon - > Information Display message conversation list . Then select the message conversation .

2 Touch the screen to enter the details of the message , touch and hold the reader 's information , the pop-up menu of options. Touch the "Forward " or " delete ."

Note: If you need to delete the message conversation , touch and hold it . Then touch

Bottom of the screen " delete" icon. To delete the conversation when a certain piece of information , press and hold the message you want to delete , and then touch the options menu 'Delete' , a confirmation prompt appears , touch the "Delete ."

Other operations

Tap the application icon - > Information Display message conversation list . You can press the Menu key to open the options panel , and then do one of the following options :

- Touch the "Delete all sessions " Delete all current conversation .

- Touch the "Settings" to set the information function.
- Touch "push information " to operate the push message.

Information Set

In the message list screen, press the Menu key and tap "Settings ."

You can set text or multimedia message options. Set the following options are available :

1 Select the basic settings , you can do the following:

Wallpaper : You can set a background picture session .

Information Font Size : Set the size of the message text is displayed .

Show E-mail address : Turn this when selecting contacts, e-mail address will be included .

Delete old messages : the limit is reached when the amount of information that can automatically delete old messages.

SMS limitations: Display the current number of messages per session maximum storage . After deleting old information menu is selected, you can specify the number of messages you want to save the settings.

MMS limit : Displays the number of current maximum storage per session MMS . After deleting old information menu is selected, you can specify the number of MMS settings to be saved .

Cell Broadcast : This feature with the operators concerned .

Open the WAP PUSH: Set whether to receive service information .

2 SMS settings

Required to send reports : Select this option to receive a delivery report for sending status information .

Manage SIM card information : Displays information stored in the SIM .

Editing common phrases : Edit common phrases to use when writing new information.

Short Message Service Center : You can view or edit the message service center number.

SMS storage location : Set SMS storage location (phone or SIM card) .

3 MMS settings

Message : Use MMS to send a single message to multiple recipients .

Required to send reports : Select this option to receive a delivery report for sending status information .

Read the report required : Select this option to receive read the report, to find out if your recipient has read the message or the information will be deleted unread .

Allowed to return to read reports : Turn this option, each time new information after reading , allow automatic return to read the report .

Automatic acquisition : Select this option to automatically retrieve all your MMS messages. When this option is selected , will automatically multimedia information header , body, and attachments downloaded to the phone. If you clear this check box , only the retrieval of multimedia information in the message header and displays the list .

Roaming auto acquisition: Select this option to automatically retrieve all your MMS messages when roaming, but the sharp rise in this action may make the data connection costs.

Creation mode : Set the desired mode of preparation of MMS .

MMS size limits : You can set the size of MMS messages .

Priority: set the priority level of the current MMS .

4 . Notification settings

Notice : If you want when you receive a new text or multimedia message letter notification in the status bar , select this option.

Mute: on, off mute settings, no beep when to information .

Select ringtone : If you want the phone to ring when you receive a new message , touch this option and then select the new text and multimedia messages Jane exclusive ringtones. Please note that the ring tone briefly plays when selected.

Vibration: vibration switch setting to information .

Pop-up message prompts : Are pop-up box is set to the information .

6.2 E-mail

Email application with e-mail wizard that lets you add a common Web-based email service providers (such as Yahoo!, Sohu, 163 as well as other manufacturers) external POP3 or IMAP on the phone , Exchange e-mail account .

Tap the application icon - > Mail application opens.

Add e-mail account

The first time you use the e-mail function , you need to set the e-mail address .

1 Touch the application icon - > E-mail E-mail

address into the setting interface .

According to the other tips email account and password information entered , tap Next or manual settings to set the mail server.

3 Check the e-mail parameters, select POP3 e-mail accounts or make IMAP, Exchange accounts.

4 Follow the prompts to set up to receive e-mail server and outgoing server .

5 Set email check frequency, by default , such as sending e-mail from this account • • settings.

6 Enter the account name and outgoing e-mail you want to display the name, then tap "Done ."

Note : Creating an e-mail account, you need to press the Menu key and touch Add account to create another email account.

Compose and send e-mail

1 Touch the application icon - > E-mail .

2 On your account interface , touch the email account you want to use .

3 On the Inbox screen , press the Mail icon " writing ."

4 Enter the recipient 's e-mail address in the To field.

5 Enter the subject and content of the email.

6 Touch the "send" to send e-mail.

Note : Touch a draft saved messages can be saved as a draft .

Receive and read e-mail

You can send and receive e-mail via phone , as follows:

- To read e-mail , tap an email account in the definition of e-mail . You then will be able to log in directly to E-mail and read the Inbox. Tap the e-mail header to view e-mail messages.
- To receive new e-mail , please log in e-mail address , and then press the Menu key and tap "Refresh" to receive new e-mail. You can also tap the account settings - > Inbox check frequency , set the frequency to check for new e-mail automatically .

7. Establish a connection

7.1 network connection

The phone's networking capabilities allow you via GPRS / EDGE (if the SIM card is available) or WLAN to the Internet directly .

GPRS / EDGE

Your phone will automatically set when you first start to use GPRS network operators provided / EDGE service (if the SIM card is available) .

1 Touch the application icon - > Settings.

2 Touch " traffic usage / More ... " and then touch " mobile networks ."

3 In the list of settings on the mobile networks ,

touch the network operator or access point name (APN) to check the network connection.

Note : In general , the phone will automatically read the SIM card access point. So do not modify the parameters of the access point , so can not connect to the network .

Create a new access point

When you need to add another GPRS on your phone / EDGE online, please obtain the access point name and settings (including username and password) to your network operator.

1 Touch the application icon - > Settings , tap flow usage / More ... - > Mobile networks - > Access Point Names.

2 On the APN screen, press the Menu key , then touch the "New APN".

WLAN

WLAN provides up to 100 meters range wireless network access . To use WLAN on your phone , you must be online to a wireless access point.

Note: The availability and range of WLAN signal depends on the number , infrastructure, and other objects that may signal penetration .

Open the WLAN and connect to a wireless network machine

1 Touch the application icon - > Settings. Select

"WLAN" selection box to open the WLAN. The phone will then scan for available wireless networks.

2 Touch "WLAN settings ." Then WLAN network section displays the network name and security settings detects WLAN networks (open network or WEP encryption) . Touch to online WLAN networks. If you select an open (safety feature is not enabled) network , the phone will automatically connect to the network. If you selected a WEP encrypted network , you must enter the password , and then tap "Connect ."

Note: unless you reset your phone to factory defaults , or else the next phone you want to connect to a previously encrypted connection over the wireless network , you do not need to re-enter the WEP password. Find WLAN network itself , that is, the phone does not need to perform additional steps can be connected to a WLAN network. For certain closed wireless networks may need to provide a user name and password.

7.2 browser

You can open the browser to start surfing the web . This browser has been fully optimized and have many advanced features that allow you to

enjoy browsing the Internet on your phone .

Note : You must have data (GPRS / EDGE) active or WLAN connection to connect to the Internet .

Tap the application icon - > Browser to open the browser interface.

1 Go to website

In the browser interface , touch screen at the top of the URL field . Enter the web page address using the keyboard . When you enter the URL , the corresponding web address will appear on the screen.

2 . Browse the web

After opening the page, you can slide the screen with your finger to browse and view web pages in other regions .

3 Organize Bookmarks.

In the browser interface , go to a web page , press the Menu key and tap the "Save to bookmarks" , editing the book signing and tap "OK ."

4 New Window

After opening a browser tap into the new interface touch the top of the '+' to create a new window.

Bluetooth 7.3

The phone supports Bluetooth wireless

connection by the way . You can create between your phone and other compatible devices wireless connection , then the data transfer, you can establish a wireless connection between your phone and the device from up to 10 meters . Bluetooth connection may be subject to interference obstacles , such as walls or other electronic devices.

Turn on Bluetooth and set your phone to discoverable

1 Touch the application icon - > Settings.

2 Touch "Bluetooth" and tap selection box to turn on Bluetooth . Bluetooth is turned on , the status bar will display the Bluetooth icon.

3 Bluetooth visible property defaults to open. Touch phones Bluetooth name , you can select " two minutes , five minutes , one hour ," or " never time out " so that other Bluetooth devices can search to the phone.

Bluetooth pairing

Before you can use the phone as a Bluetooth device , you need to pair your phone with the target device , as follows:

1 Make sure your phone is Bluetooth-enabled .

2 Touch "Search Device ." Bluetooth devices within range of the phone will start scanning .

3 Touch the device you want to pair .

4 Enter the password to complete the pairing.

Note: To allow other Bluetooth devices to its successful docking , the two devices must use the same password.

Send and receive files via Bluetooth

You can use Bluetooth , pictures , videos or music files to share with family and friends , the Bluetooth received files will be saved in the bluetooth folder.

8 .synchronization information

You can use some applications on the phone to synchronize information . When you pass on the network

These applications add, change or delete information , the updated information will appear in the hand

Machine .

Note: This is the data simultaneously. This program will be conducted in the background without shadow

Affect normal operation of the phone . When synchronization , data synchronization notification bar icon is displayed .

You can use contacts and other applications on

the phone , on the computer you use to access and

Edit the same personal information (e-mail and contacts, etc.) .

Select the application you want to synchronize

Tap the application icon - > Settings - > Accounts.

Note : By default, whenever you make a change or receive a new message , contact the All personal data will be synchronized.

Tip : Select Auto-sync to automatically synchronize all applications. Disable Automatic synchronization, you can also select individual check box to manually synchronize Processing each application .

Via USB connection

1 Use a USB cable to connect the device to the computer.

2 Tap the notification panel "USB connected" to enter, and then touch the "Open USB memory Storage devices . "

3 At this point the card will become a removable disk on your computer , can easily

Fast access to data between computers and removable disks.

Note : To use the memory card as U disk,

memory card installed before use .

Using the SD card as a USB storage device

In order to facilitate transfer music and pictures from your computer to the SD card, you can set the SD card USB storage device.

Use USB cable to connect your phone to your computer. Computer SD card will be treated as a removable disk . You can now exchange files between your computer and the phone's SD card.

Remove the SD card when turned on (* Please phone the actual date)

If you need to remove the SD card in the boot state , follow these steps.

1 Open the application icon , then tap "Settings ."

2 Scroll down the screen, then tap "Storage - > Unmount SD card ."

9 . Multimedia and Camera

You can use your phone to listen to music and take pictures.

9.1 Music

Music can play audio files on the memory card .

You must copy audio files to save

Memory card , and then open the music .

Note: To use this feature, please install the memory card.

Open Music Player

Tap the application icon - > Music , open the music player and displays the media library.

Note : When the phone is playing music in the background, you can open the Notifications panel , then tap

Touch a music file to switch to the music player interface .

Use the Media Library

Content stored on the phone is divided into the following categories: artist, album , song and play

Playlist . You can touch the desired category , to demonstrate compliance with the music files listed in this category

Table .

Create a playlist

1 Class Touch music library interface.

2 In the list that appears , navigate to where you want to add to the playlist of songs.

3 Touch and hold the song , and then touch on the Options menu , " Add to Playlist ."

4 added to the play list interface, add the song to the current playlist or new

Build a playlist.

Edit Playlist

1 playlists Touch music library interface .

2 On the play list editing interface , you can do the following:

- Touch and hold the playlist of songs , then you can play from the playlist , delete, or as ringtones and search .

9.2 Photo and Video

The camera application can automatically find photos stored on a memory card and video .

In addition , the camera application to the folder classification of these photos and videos . You can make

View and edit photos with the camera application , or contact the photos as desktop diagram

Like , and watch videos stored on a memory card .

Note: To use this feature, please install the memory card.

Turn on the camera

To open the camera application , perform the following steps:

- Tap the application icon - > Camera to open . When the camera is turned on , the screen orientation will change as you hold the phone .
- Touch the screen area below the camera icon button in the pop-up option to select the

camera or video camera to switch the camera and video modes.

- The remaining number of shots that can be taken will be displayed in the lower left corner of the screen (in video mode , the screen will display the top left of the length of recording time available) .
- After entering the photo or video mode , click on the appropriate icon in the icon area can be set to set the camera -related parameters.
- viewfinder preview screen, tap the touch screen to switch the camera icon at the bottom right front and rear camera .

1 In Photo mode , touch the bottom of the screen to shoot the middle icon to take a picture.

2 In video mode , the middle bottom of the screen shooting touch icons to start shooting video, Click the icon again to stop recording .

3 After capturing a photo or video, you can touch the screen icon in the bottom right into the gallery , that

Can delete , share , settings and other operations.
Gallery

Photos on the camera preview screen , touch the bottom right of the screen to enter the gallery icon .

Or tap the application icon - > Gallery to open .
Classification based photo and video storage location , and then save the files in the folder The . You can touch one folder to view the photo or video.

- 1 Touch the desired folder that contains the pictures to view .
- 2 Touch the desired picture in full- screen mode to view pictures. View in full screen mode Pictures , please sliding around the picture to see the previous or next picture.

Edit and set the picture

When in full- screen mode to view pictures , press the Menu button to display the control panel . You can select

Options or settings you want to edit the picture .

1. Crop Image

Press the Menu button to display the control panel . Then touch the " pruning ."

- Tap the relevant area to adjust the cutter . Touch and drag to the center of the inner and outer cutting

Cropper arrows to adjust the crop 's size.

- Touch and hold inside the cropper , then drag your finger to the desired location .
- Touch "Cancel" to discard the changes .

- Touch the "Crop " to save the crop good pictures.

2 Rotate Image

Press the Menu button to display the control panel . Then touch the " left / right rotation ."

3 display pictures in a slide show

Press the Menu button to display the control panel . Then touch the " slideshow ." Selected folder

The pictures will be displayed in slideshow mode .

4 Use a picture as the desktop or call image

Press the Menu button to display the options panel , and then select " Set as the photo ."

Use a picture as wallpaper or contact icon .

5 Other operating

You can also use the control panel to edit , delete, print pictures or view pictures details

Interest .

6 share pictures

When in full- screen mode to view pictures , touch the top of the screen "share" icon. From the obvious

Options menu is shown , select Bluetooth, e-mail or message , a picture with a friend of

Enjoy .

Play Video

Touch want to see the video in the media library to start the video. Touch the screen to display Playback control panel. You can then rewind the video , pause or resume playback video.

9.3 Radio

This device provides radio.

Note: You need a headset acts as an antenna , before using insert earphones.

2 indoors or shielded environment, the effect of radio listening may be affected . You can improve the effect of the following ways : close windows, adjust the headset line position or manual tuning .

10 Other tools

10.1 Alarm

The machine has alarm function , you can meet different requirements by setting the alarm clock to remind .

1 Touch the application icon - > clock to enter the clock setting interface.

2 Touch "Set Alarm" to enter the alarm setting interface.

10.2 Calendar

You can use the calendar to view dates and set reminders for appointments and meetings .

Create Event

1 Touch the application icon - > Calendar , open the calendar .

2 On any calendar view screen, press the Menu key , then touch the "New Events " Open Event details screen.

3 Use the keypad to enter the event name .

4 perform one of the following :

- If there is a time limit range , touch the start date and end date set

And time .

- If special circumstances , such as a birthday or a whole-day event , set the start date and end date Period , and then select the All day check box.

5 Enter the event location and description.

6 Select the calendar you want to save the event .

7 set reminder event reminder time, and then select whether to re- repetition frequency

Complex activity occurred.

8 . Upon completion of touch "Done ."

Event Reminder

If you set up an event reminder , reminder when the time comes, will be an event reminder icon
Now the notification area of the status bar .

10.3 Calculator

Tap the application icon - > Calculator to open the calculator.

- Press the Menu key to open the calculator options panel. You can then select the basic panel or high

Level panel. In the Advanced panel, you can perform calculations based on advanced features.

Tap the virtual keys to enter numbers or mathematical operators.

Note: You can slide the screen left and right to switch Basic panel and Advanced panel .

10.4 recorder

Tap the application icon - > recorder turned on the recorder .

1 shows the length of recording time.

2 displays the volume of the audio recorded .

3 Tap to start playing or pause recording.

4 Touch to start recording sound.

5 Touch to stop recording or stop playing the recording.

Care and Maintenance

Battery Handling Precautions

- The phone is a rechargeable battery as a power source. When power is weak, the battery charging. To preserve battery life , the best before charging the battery power runs out .
- When the battery charger is not in use , keep it separate from the power supply source. Do not connect the charger and the battery more than a week , overcharging will shorten battery life.
- Temperature limits of the battery can affect the charging . So before charging , the battery may need to look cool or warm . If the battery temperature exceeds 50 degrees Celsius, the battery will not charge.
- Keep the battery on its original purpose , to avoid short circuit. When connected directly to the conductive material can cause a short

circuit battery positive and negative .

- Do not use damaged batteries.
- The battery in extremely hot or extremely cold places will result in shorter battery life , the battery is exposed to cold or hot places may cause the phone feature does not work properly , even when the battery fully charged , too.
- Do not expose the battery to fire , do not waste batteries thrown away , please send battery recycling , please follow local regulations for disposal of batteries !

Mobile Maintenance

The following suggestions will help take care of your mobile phone :

- phone with all accessories away from children to touch the place .
- Please keep the body dry and liquid metal circuit will cause corrosion .
- Keep the body away from heat, high temperatures will shorten the life of electronic devices , so that the plastic melt and damage the battery.
- Do not attempt to open the cabinet or phone disintegration , non-professional demolition

may cause damage to the body .

- Do not use strong acid or alkaline detergents to clean the body .
- Use only original mobile phone accessories. Violation of these will void the warranty.

SAR

Mobile phones use electromagnetic radiation Specific Absorption Rate (SAR) is the unit of measurement . According to the National Standard , SAR limit is 2.0W/Kg. SAR tests when using standard operating positions shift Mobile phones , mobile phones transmit at the highest power level . Although SAR is determined using

Maximum power level , the actual use of the mobile phone may be lower than the maximum SAR .

This is because the mobile phone is designed to use the minimum power required to reach the network . Through

In general, the closer the lower power output of mobile phones .

This product is electromagnetic radiation Specific Absorption Rate (SAR) a maximum of ** W / Kg, in line with national standards

Requirements of GB 21288-2007 .

SAR values at various locations there will be some differences, they all conform to the limits prescribed by the State

Requirements. Please note that this product may cause improvements in SAR value differences after the product ;

In any case, the product must be designed within the standard limits .



部件名称 (Parts)	有毒有害物质或元素 (Hazardous Substance)					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr ⁶⁺)	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
主机 (Phone)	X	O	O	O	O	O
电池 (Battery)	X	O	O	O	O	O
附件 (Accessories)	X	O	O	O	O	O
O：表示该有毒有害物质在该部件所有均质材料中的含量均在SJ/T 11363—2006标准规定的限量要求以下。 X：表示该有毒有害物质至少在该部件的某一均质材料中的含量超出SJ/T 11363—2006标准规定的限量要求。 注：本产品有“X”原因是：现阶段没有可供选择的替代技术或部件。						

Important Safety Information

Safety Information

When using the phone , you must comply with in order to protect users and their environment and the development of safety regulations.

Traffic Safety

- Unless there is an emergency situation, if to ensure the safety and freedom of hands-free device is not installed, please do not use the phone while driving , in order to ensure that all the attention focused on driving , stop in a safe place and then use the phone . Please comply with the relevant laws and regulations.
- In case there is not enough to protect the car in certain electronic systems may be affected by radio waves emitted by your phone .
- We recommend only using your phone in a car with an external antenna .
- Only a qualified technician to your phone

installed in your car.

Aircraft Safety

- Turn off before boarding the phone , because it affects the operation of the aircraft and the entire cellular network . Use of mobile phones on aircraft is illegal and in violation of these safety regulations will be prosecuted or cause a denial of service network .

Environmental Safety

- Remember when in any place to comply with the existing special regulations in place to prohibit the use of mobile phones , or it may cause interference or danger must be shut down.

- Use any radio transmitting equipment , including cellular phones, may inadequately protected medical devices interfere. If you have any questions in this regard may be directed to a physician or medical device manufacturers .

- Your phone might be interested in hearing aids , pacemakers and other medical electronic equipment interference. Please observe the recommended physician or medical device manufacturer .

- wherever possible explosion , such as gas

stations, chemical plants , recommends that users turn off the phone . Compliance with the use of wireless devices restrictions.

Mobile phone authenticity of identification tips

Dear user :

Hello , in order to ensure your legal rights , it is recommended that you carefully read the tips to inspect your purchase of mobile telephone authenticity.

Should be affixed on the phone you purchase the size of 30mm × 12mm Jinwangbiaozhi (blue or green) , otherwise, you buy the phone is certainly not

Regular manufacturers of mobile telephones.

Print first line of information on network access flag (by the numbers and " - " the composition) is a permit issued by the Ministry of Information Industry, the number of manufacturing enterprises ,

Each model has only one number ; second line of information is the mobile phone model you purchase ; third line information is scrambled , is a set of encrypted authentication code is

calculated after generation , the scrambling code is unique.

You can be Jinwangbiaozhi checking the authenticity .

(A) website : Login WWW.TENAA.COM.CN website , enter "sign verification " section and follow the prompts to enter the relevant information can be verified.

Website 24 hours free service , convenient , we recommend that you use this method inspection.

(B) artificial Telephone: Services: Jinwangbiaozhi check the authenticity of the information and the serial number of the mobile phone . The way is free, does not charge any inquiry fee , you only need to call time, whether long-distance and other communications carriers to pay the cost of communication . Hours: Monday to Friday (except holidays) 8:00-11:30 am 1:00-5:00 pm Telephone inquiries 010 -8,205,876,782,050,313

(C) Short Message Authentication: (1) query method : move the user to enter information : RW (space) Permit No. (space) scrambling code (space) mobile phone serial number .

Example : RW 02-0574-050269
2pcn4ltlaylnt5p 355455000027257; China
Unicom users to enter information : GJTQ
(spaces)

License Number (space) scrambling code (space)
mobile phone serial number . Example : GJTQ
02-0574-050269 2pcn4ltlaylnt5p
355455000027257

Enter the "* # 06 #" get IMEI on the phone.
When security check enter IMEI , simply enter
the number continuously , without entering "/" or
" - " ; (2) entered, sent to 106,677,667,788 , you
can wait for a reply conclusions ; (3) rates: one
for each reply result information received \$ 1.

By way of checking if the above display
Jinwangbiaozhi conclusion is false, it means that
you are buying is not a regular production of
mobile phone manufacturers .

You can also check in to apply for a mobile
phone network license when the style and
appearance of the mobile phone that you
purchase for more than

Compared with , inconsistencies , but also that
you buy are not regular manufacturer of

production.

You can visit the website
WWW.TENAA.COM.CN " certificate query "
column, by license number (first row on
Jinwangbiaozhi information) query.

FCC RF EXPOSURE INFORMATION:

WARNING!! Read this information before using your phone

In August 1986 the Federal Communications Commission (FCC) of the United States with its action in Report and Order FCC 96-326 adopted an updated safety standard for human exposure to radio frequency (RF) electromagnetic energy emitted by FCC regulated transmitters. Those guidelines are consistent with the safety standard previously set by both U.S. and international standards bodies. The design of this phone complies with the FCC guidelines and these international standards. Use only the supplied or an approved antenna. Unauthorized antennas, modifications, or attachments could impair call quality, damage the phone, or result in violation of FCC regulations. Do not use the phone with a damaged antenna. If a damaged antenna comes into contact with the skin, a minor burn may result. Please contact your local dealer for replacement antenna.

BODY-WORN OPERATION:

This device was tested for typical body-worn operations with the back of the phone kept 10mm from the body. To comply with FCC RF exposure requirements, a minimum separation distance of 10mm must be maintained between the user's body and the back of the phone, including the antenna. Third-party belt-clips, holsters and similar accessories containing metallic components shall not be used. Body-worn accessories that cannot maintain 10mm separation distance between the user's body and the back of the phone, and have not been tested for typical body-worn operations may not comply with FCC RF exposure limits and should be avoided. For more information about RF exposure, please visit the FCC website at www.fcc.gov

Your wireless handheld portable telephone is a low power radio transmitter and receiver. When it is ON, it receives and also sends out radio frequency (RF) signals. In August, 1996, the Federal Communications Commission (FCC) adopted RF exposure guidelines with safety levels for hand-held wireless phones. Those guidelines are consistent with the safety standards previously set by both U.S. and international standards bodies:

<ANSI C95.1> (1992) / <NCRP Report 86> (1986) / <ICNIRP> (1996)

Those standards were based on comprehensive and periodic evaluations of the relevant scientific literature. For example, over 120 scientists, engineers, and physicians from universities, government health agencies, and industry reviewed the available body of research to develop the ANSI Standard (C95.1). Nevertheless, we recommend that you use a hands-free kit with your phone (such as an earpiece or headset) to avoid potential exposure to RF energy. The design of your phone complies with the FCC guidelines (and those standards).

Use only the supplied or an approved replacement antenna. Unauthorized antennas, modifications, or attachments could damage the phone and may violate FCC regulations.

NORMAL POSITION:

Hold the phone as you would any other telephone with the antenna pointed up and over your shoulder.

RF Exposure Information:

This product is in compliance with FCC RF Exposure requirements and refer to FCC website search for FCC ID: 2AAQ2NETK4 to gain further information include SAR Values.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Do not use the device with the environment which below minimum -10°C or over maximum 50°C, the device may not work.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Ad Hoc function is supported but not able to operate on non-US frequencies.