

TEST SETUP PHOTO(S) – EUT POSITION 1



TEST SETUP PHOTO(S) – EUT POSITION 2



TEST SETUP PHOTO(S) – EUT POSITION 3



TEST SETUP PHOTO(S) – EUT POSITION 4



TEST SETUP PHOTO(S) – EUT POSITION 5



TEST SETUP PHOTO(S) – EUT POSITION 6



TEST SETUP PHOTO(S) – 9 KHz TO 30 MHz



TEST SETUP PHOTO(S) – 30 MHz TO 1 GHz



TEST SETUP PHOTO(S) – 1 GHz TO 18 GHz



TEST SETUP PHOTO(S) – 18 GHz TO 26 GHz

