

Model Name: MID773-MTK27

Model Name: MID773-MTK27

Turning on


- 1 Press and hold the Power button  to get started.
- 2 Follow the initial Setup Wizard prompts.
- 3 To use the Google Play store, sign into or create a Google account.

Standard Mode & Child Mode

About Standard Mode
After completing the Setup Wizard the Standard Mode home screen is displayed.
All apps are available without restriction in Standard Mode.

Launching Child Mode
1. Select the Child Mode icon on the top right of the display.
2. Create and confirm the Child Mode password.
3. After the password is accepted, the Child Mode home screen is displayed.

About Child Mode
Child Mode is a safe environment for younger children that includes Parental Controls (app restrictions), games, books, videos, and more.



The diagram illustrates the process of turning on the device and setting up Standard Mode and Child Mode. It includes the following steps and screenshots:

- Startup screen:** The first screen shown is the "smarttab" startup screen with the "powered by android" logo.
- Setup Wizard:** The second screen is the "Welcome" screen of the Setup Wizard, showing language options (English - United Kingdom, English - United States) and a "Next" button.
- Google account:** The third screen is the "Add your account" screen, prompting the user to sign in to get the best out of their device. It includes fields for "Enter your email" and "Or create a new account".
- Standard Mode (home screen):** The fourth screen is the Standard Mode home screen, which is a wooden-textured screen with the "smarttab" logo and icons for "Set it up" and "Tap here".
- Child Mode password setup:** The fifth screen is the "Set Child Mode Password" screen, which prompts the user to enter a "Pincode Password" and a "Confirmation Password".
- Child Mode (home screen):** The sixth screen is the Child Mode home screen, which is a blue screen with icons for "Arcade", "Read & Learn", and "Videos", along with a Mickey Mouse character.

Standard Mode (home screen)

Child Mode (home screen)

Information: If you use Gmail™, you already have a Google account—if not, you can create an account now.

Navigation Bar

On certain apps the Navigation Bar does not appear. To access the Navigation Bar, swipe up on the bottom of the screen as shown below.

Connecting

Wi-Fi and Bluetooth®

If you did not set up Wi-Fi during the initial setup or would like to connect to a Bluetooth device, you can do so by selecting Settings > Wi-Fi on the Standard Mode and Child Mode Apps Screens.

Expandable storage

Inserting a Micro SD card

The tablet supports Micro SD cards up to 64GB (not included).

To install a Micro SD card into the tablet, carefully insert the card as shown below into the card slot until it clicks and locks into place.

To remove the Micro SD card, gently press it inward to eject.

Connecting to a computer

Connect the tablet to the computer using the included USB cable as shown below.

FCC Regulatory Compliance

This product has been tested and found to comply with the requirements for a Class B digital device under Part 15 of the Federal Communications Commission (FCC) rules. These requirements are intended to provide reasonable protection against harmful interference in a residential environment. This device may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Do not attempt to repair or modify this equipment.

Warning: Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device must not cause harmful interference, and
- (2) If this device does cause such interference, the user must stop using the equipment unless it can be demonstrated that the device must stop using this type of equipment to ensure compliance with the Class B FCC limits.

Shielded cables must be used with this type of equipment to ensure compliance with the Class B FCC limits.

Information Regarding Exposure to Radio Frequency Energy

The manufacturer of this equipment has evaluated the electromagnetic field (EMF) emissions from exposure to RF energy sent by the Federal Communications Commission of the United States (FCC). Information on your device is on the back of the FCC and can be found under the Display Case section of <http://www.fcc.gov/oet/rf> after scrolling on the FCC ID for your Device, which can be found on the back of the Device.

If your electronic device has internal memory or wireless personal or other confidential data may be stored, you may want to perform a data sanitization process before you dispose of your device to assure another party cannot access your personal data. Data sanitization varies by the type of product and its software, and you may want to research the latest sanitization process for your device before disposal. You may also wish to check with your local recycling facility to determine safe data sanitization procedures during the recycling process.

Designed by Southern Telecom/Made in China
Distributed by: Southern Telecom Inc., 144C Elm Street Brooklyn, NY 11231 © 2015 All Rights Reserved. SmartTab is a registered trademark of Southern Telecom Inc. Other contents © 2015 Southern Telecom. All rights reserved.
PSS & PSS Kids logo © 2015 Public Broadcasting Service.

The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. Google Play is a trademark of Google Inc. The Android robot is reproduced or modified from work created and shared by Google and used according to terms discribed in the Creative Commons 3.0 Attribution License. All other trademarks and trade names are those of their respective owners.

Battery Disposal & Recycling

This device contains a Lithium-Ion battery. The battery must be recycled or disposed of properly. Please contact your local waste management office for information on battery recycling or disposal, or visit www.batterystewardship.org.

Legal information

Warranty

The Product Including any accessories included in the original packaging supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original consumer purchaser for defects in materials and workmanship ("Warranty") as follows:

To obtain warranty service:

- Contact the Customer Support number located below, or go to our website portal to receive an RFD number.
- Provide proof of the date of purchase within the package dated bill of sale.
- Return the product to the address below.
- Include a return shipping address (in US, Canada), a telephone contact number, and the defective unit within the package.
- Describe the defect or reason you are returning the product.

Customer Support:

1-877-768-8441 (Toll Free)
Monday - Friday 9AM - 5PM (EST)

Click on "Product Support"

To receive Warranty service, the original consumer purchaser must contact Southern Telecom, or an authorized service provider for confirmation/determination and service procedures. Proof of purchase is required. A valid bill of sale is required, evidencing that the Product is within the applicable Warranty period(s). MUST BE presented to Distributor, or an authorized service provider of the Distributor, in order to obtain the requested services.

This Warranty covers manufacturing defects in materials and workmanship encountered in the normal, noncommercial use of the Product, and does not cover commercial use, misuse, installation, software issues, repairs, adjustments, cosmetic damage or damage due to acts of nature, accident, misuse, abuse, negligence, commercial use or modification, or to any part of the Product. In addition, this Warranty does not cover impact, burning, oil, grease, water, liquid spills, corrosion, fire, theft, tampering, unauthorized repair, alteration, or modification. This Warranty is void if the factory-applied serial number has been altered or removed from the Product. This Warranty is valid only in the country where the consumer purchased the product, and only applies to products purchased and serviced in that country.

No WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE FOREGOING WARRANTY PERIOD HAS EXPIRED. THIS WARRANTY IS VOID WHEREVER IT MAY BE APPLIED. NO OTHER WARRANTIES ARE GIVEN BY DISTRIBUTOR. RETURN, REPLACEMENT OR REFUNDAL OF THE PURCHASE PRICE BY DISTRIBUTOR IS SUBJECT TO THE FOLLOWING CONDITIONS AND THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR, ITS MANUFACTURERS, BE LIABLE FOR ANY INCIDENTAL, DIRECT OR INDIRECT, PUNITIVE OR CONSEQUENTIAL DAMAGES SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT, EXCEPT AS SET FORTH HEREIN. NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMERS' RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTORS. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL END USER. SOME STATES DO NOT ALLOW LIMITATION ON HOW LONG A CONTRACT CAN BE ENFORCED. Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or the exclusion of implied warranties. No limitation or exclusion shall apply to the extent permitted by law, legal rights, and they may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty apply.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.