

Setup Photos

Front To Face View



EUT Setup Configuration 1

Body Touch View



EUT Setup Configuration 2

EUT Photos

EUT Configuration 1EUT Configuration 2

**EUT Configuration 3****EUT Configuration 4**



EUT Configuration 5



EUT Configuration 6

EUT Configuration 7

Battery

EUT Configuration 8



EUT Configuration 9