

Appendix A

Duty Cycle


Condition	Mode	Frequency (MHz)	Antenna	Duty Cycle (%)	Correction Factor (dB)	1/T (kHz)
NVNT	a	5180	Ant1	50	3.01	0.4
NVNT	a	5180	Ant2	50	3.01	0.4
NVNT	a	5200	Ant1	50	3.01	0.4
NVNT	a	5200	Ant2	50	3.01	0.4
NVNT	a	5240	Ant1	50	3.01	0.4
NVNT	a	5240	Ant2	50	3.01	0.4
NVNT	a	5260	Ant1	50	3.01	0.4
NVNT	a	5260	Ant2	50	3.01	0.4
NVNT	a	5280	Ant1	50	3.01	0.4
NVNT	a	5280	Ant2	50	3.01	0.4
NVNT	a	5320	Ant1	49.5	3.05	0.4
NVNT	a	5320	Ant2	50	3.01	0.4
NVNT	a	5500	Ant1	50	3.01	0.4
NVNT	a	5500	Ant2	50	3.01	0.4
NVNT	a	5600	Ant1	50	3.01	0.4
NVNT	a	5600	Ant2	50	3.01	0.4
NVNT	a	5700	Ant1	50	3.01	0.4
NVNT	a	5700	Ant2	50	3.01	0.4
NVNT	a	5745	Ant1	49.5	3.05	0.4
NVNT	a	5745	Ant2	50	3.01	0.4
NVNT	a	5785	Ant1	50	3.01	0.4
NVNT	a	5785	Ant2	50	3.01	0.4
NVNT	a	5825	Ant1	50	3.01	0.4
NVNT	a	5825	Ant2	49.5	3.05	0.4
NVNT	n20	5180	Ant1	40.48	3.93	0.59
NVNT	n20	5180	Ant2	40.48	3.93	0.59
NVNT	n20	5200	Ant1	40.48	3.93	0.59
NVNT	n20	5200	Ant2	40.48	3.93	0.59
NVNT	n20	5240	Ant1	40.48	3.93	0.59
NVNT	n20	5240	Ant2	39.76	4.01	0.61

NVNT	n20	5260	Ant1	40.48	3.93	0.59
NVNT	n20	5260	Ant2	40.48	3.93	0.59
NVNT	n20	5280	Ant1	40.48	3.93	0.59
NVNT	n20	5280	Ant2	39.29	4.06	0.61
NVNT	n20	5320	Ant1	40.48	3.93	0.59
NVNT	n20	5320	Ant2	40.48	3.93	0.59
NVNT	n20	5500	Ant1	40.48	3.93	0.59
NVNT	n20	5500	Ant2	40.48	3.93	0.59
NVNT	n20	5600	Ant1	40.48	3.93	0.59
NVNT	n20	5600	Ant2	39.29	4.06	0.61
NVNT	n20	5700	Ant1	39.76	4.01	0.61
NVNT	n20	5700	Ant2	40.48	3.93	0.59
NVNT	n20	5745	Ant1	40.48	3.93	0.59
NVNT	n20	5745	Ant2	40.48	3.93	0.59
NVNT	n20	5785	Ant1	40.48	3.93	0.59
NVNT	n20	5785	Ant2	40.48	3.93	0.59
NVNT	n20	5825	Ant1	39.76	4.01	0.61
NVNT	n20	5825	Ant2	40.48	3.93	0.59
NVNT	n40	5190	Ant1	48.98	3.1	0.42
NVNT	n40	5190	Ant2	48.98	3.1	0.42
NVNT	n40	5230	Ant1	48.48	3.14	0.42
NVNT	n40	5230	Ant2	48.98	3.1	0.42
NVNT	n40	5270	Ant1	49.49	3.05	0.41
NVNT	n40	5270	Ant2	48.98	3.1	0.42
NVNT	n40	5310	Ant1	48.98	3.1	0.42
NVNT	n40	5310	Ant2	48.39	3.15	0.42
NVNT	n40	5510	Ant1	48.98	3.1	0.42
NVNT	n40	5510	Ant2	48.98	3.1	0.42
NVNT	n40	5590	Ant1	48.98	3.1	0.42
NVNT	n40	5590	Ant2	48.98	3.1	0.42
NVNT	n40	5670	Ant1	48.98	3.1	0.42
NVNT	n40	5670	Ant2	48.98	3.1	0.42
NVNT	n40	5755	Ant1	48.98	3.1	0.42
NVNT	n40	5755	Ant2	48.98	3.1	0.42
NVNT	n40	5795	Ant1	48.98	3.1	0.42
NVNT	n40	5795	Ant2	48.48	3.14	0.42
NVNT	ac20	5180	Ant1	40.48	3.93	0.59
NVNT	ac20	5180	Ant2	40.48	3.93	0.59
NVNT	ac20	5200	Ant1	40.48	3.93	0.59
NVNT	ac20	5200	Ant2	40.48	3.93	0.59
NVNT	ac20	5240	Ant1	40.48	3.93	0.59
NVNT	ac20	5240	Ant2	40.48	3.93	0.59
NVNT	ac20	5260	Ant1	40.48	3.93	0.59
NVNT	ac20	5260	Ant2	40.48	3.93	0.59


NVNT	ac20	5280	Ant1	40.48	3.93	0.59
NVNT	ac20	5280	Ant2	40.48	3.93	0.59
NVNT	ac20	5320	Ant1	40.48	3.93	0.59
NVNT	ac20	5320	Ant2	40.48	3.93	0.59
NVNT	ac20	5500	Ant1	40	3.98	0.59
NVNT	ac20	5500	Ant2	40.48	3.93	0.59
NVNT	ac20	5600	Ant1	40.48	3.93	0.59
NVNT	ac20	5600	Ant2	40.48	3.93	0.59
NVNT	ac20	5700	Ant1	40.48	3.93	0.59
NVNT	ac20	5700	Ant2	40.48	3.93	0.59
NVNT	ac20	5745	Ant1	40.48	3.93	0.59
NVNT	ac20	5745	Ant2	40	3.98	0.59
NVNT	ac20	5785	Ant1	40	3.98	0.59
NVNT	ac20	5785	Ant2	40.48	3.93	0.59
NVNT	ac20	5825	Ant1	40.48	3.93	0.59
NVNT	ac20	5825	Ant2	40.48	3.93	0.59
NVNT	ac40	5190	Ant1	48.98	3.1	0.42
NVNT	ac40	5190	Ant2	49.49	3.05	0.41
NVNT	ac40	5230	Ant1	49.49	3.05	0.41
NVNT	ac40	5230	Ant2	49.49	3.05	0.41
NVNT	ac40	5270	Ant1	48.48	3.14	0.42
NVNT	ac40	5270	Ant2	48.98	3.1	0.42
NVNT	ac40	5310	Ant1	48.98	3.1	0.42
NVNT	ac40	5310	Ant2	48.98	3.1	0.42
NVNT	ac40	5510	Ant1	48.98	3.1	0.42
NVNT	ac40	5510	Ant2	48.98	3.1	0.42
NVNT	ac40	5590	Ant1	48.48	3.14	0.42
NVNT	ac40	5590	Ant2	48.98	3.1	0.42
NVNT	ac40	5670	Ant1	48.48	3.14	0.42
NVNT	ac40	5670	Ant2	49.49	3.05	0.41
NVNT	ac40	5755	Ant1	48.98	3.1	0.42
NVNT	ac40	5755	Ant2	49.49	3.05	0.41
NVNT	ac40	5795	Ant1	48.98	3.1	0.42
NVNT	ac40	5795	Ant2	48.98	3.1	0.42
NVNT	ac80	5210	Ant1	31.51	5.02	0.87
NVNT	ac80	5210	Ant2	31.51	5.02	0.87
NVNT	ac80	5290	Ant1	31.51	5.02	0.87
NVNT	ac80	5290	Ant2	31.51	5.02	0.87
NVNT	ac80	5530	Ant1	31.51	5.02	0.87
NVNT	ac80	5530	Ant2	30.56	5.15	0.91
NVNT	ac80	5610	Ant1	30.56	5.15	0.91
NVNT	ac80	5610	Ant2	30.56	5.15	0.91
NVNT	ac80	5775	Ant1	31.51	5.02	0.87
NVNT	ac80	5775	Ant2	31.51	5.02	0.87

NVNT	ax20	5180	Ant1	32.43	4.89	0.83
NVNT	ax20	5180	Ant2	31.51	5.02	0.87
NVNT	ax20	5200	Ant1	32.43	4.89	0.83
NVNT	ax20	5200	Ant2	32.43	4.89	0.83
NVNT	ax20	5240	Ant1	31.51	5.02	0.87
NVNT	ax20	5240	Ant2	31.51	5.02	0.87
NVNT	ax20	5260	Ant1	31.51	5.02	0.87
NVNT	ax20	5260	Ant2	31.51	5.02	0.87
NVNT	ax20	5280	Ant1	31.51	5.02	0.87
NVNT	ax20	5280	Ant2	32.43	4.89	0.83
NVNT	ax20	5320	Ant1	31.51	5.02	0.87
NVNT	ax20	5320	Ant2	32.43	4.89	0.83
NVNT	ax20	5500	Ant1	31.51	5.02	0.87
NVNT	ax20	5500	Ant2	32.43	4.89	0.83
NVNT	ax20	5600	Ant1	31.51	5.02	0.87
NVNT	ax20	5600	Ant2	31.51	5.02	0.87
NVNT	ax20	5700	Ant1	32.43	4.89	0.83
NVNT	ax20	5700	Ant2	31.51	5.02	0.87
NVNT	ax20	5745	Ant1	32.43	4.89	0.83
NVNT	ax20	5745	Ant2	32.43	4.89	0.83
NVNT	ax20	5785	Ant1	32.43	4.89	0.83
NVNT	ax20	5785	Ant2	32.43	4.89	0.83
NVNT	ax20	5825	Ant1	31.08	5.08	0.87
NVNT	ax20	5825	Ant2	31.51	5.02	0.87
NVNT	ax40	5190	Ant1	47.37	3.25	0.44
NVNT	ax40	5190	Ant2	47.37	3.25	0.44
NVNT	ax40	5230	Ant1	47.37	3.25	0.44
NVNT	ax40	5230	Ant2	47.37	3.25	0.44
NVNT	ax40	5270	Ant1	47.92	3.2	0.43
NVNT	ax40	5270	Ant2	47.92	3.2	0.43
NVNT	ax40	5310	Ant1	47.37	3.25	0.44
NVNT	ax40	5310	Ant2	47.37	3.25	0.44
NVNT	ax40	5510	Ant1	47.92	3.2	0.43
NVNT	ax40	5510	Ant2	47.37	3.25	0.44
NVNT	ax40	5590	Ant1	47.37	3.25	0.44
NVNT	ax40	5590	Ant2	47.37	3.25	0.44
NVNT	ax40	5670	Ant1	47.92	3.2	0.43
NVNT	ax40	5670	Ant2	47.37	3.25	0.44
NVNT	ax40	5755	Ant1	47.37	3.25	0.44
NVNT	ax40	5755	Ant2	47.37	3.25	0.44
NVNT	ax40	5795	Ant1	47.37	3.25	0.44
NVNT	ax40	5795	Ant2	47.37	3.25	0.44
NVNT	ax80	5210	Ant1	30.56	5.15	0.91
NVNT	ax80	5210	Ant2	30.56	5.15	0.91


NVNT	ax80	5290	Ant1	30.56	5.15	0.91
NVNT	ax80	5290	Ant2	31.51	5.02	0.87
NVNT	ax80	5530	Ant1	25	6.02	1.11
NVNT	ax80	5530	Ant2	30.56	5.15	0.91
NVNT	ax80	5610	Ant1	30.56	5.15	0.91
NVNT	ax80	5610	Ant2	31.51	5.02	0.87
NVNT	ax80	5775	Ant1	30.56	5.15	0.91
NVNT	ax80	5775	Ant2	30.56	5.15	0.91




Duty Cycle NVNT a 5180MHz Ant1




Duty Cycle NVNT a 5180MHz Ant2




Duty Cycle NVNT a 5200MHz Ant1




Duty Cycle NVNT a 5200MHz Ant2




Duty Cycle NVNT a 5240MHz Ant1




Duty Cycle NVNT a 5240MHz Ant2




Duty Cycle NVNT a 5260MHz Ant1




Duty Cycle NVNT a 5260MHz Ant2




Duty Cycle NVNT a 5280MHz Ant1




Duty Cycle NVNT a 5280MHz Ant2




Duty Cycle NVNT a 5320MHz Ant1




Duty Cycle NVNT a 5320MHz Ant2




Duty Cycle NVNT a 5500MHz Ant1




Duty Cycle NVNT a 5500MHz Ant2




Duty Cycle NVNT a 5600MHz Ant1




Duty Cycle NVNT a 5600MHz Ant2




Duty Cycle NVNT a 5700MHz Ant1




Duty Cycle NVNT a 5700MHz Ant2




Duty Cycle NVNT a 5745MHz Ant1




Duty Cycle NVNT a 5745MHz Ant2




Duty Cycle NVNT a 5785MHz Ant1




Duty Cycle NVNT a 5785MHz Ant2




Duty Cycle NVNT a 5825MHz Ant1




Duty Cycle NVNT a 5825MHz Ant2




Duty Cycle NVNT n20 5180MHz Ant1




Duty Cycle NVNT n20 5180MHz Ant2




Duty Cycle NVNT n20 5200MHz Ant1




Duty Cycle NVNT n20 5200MHz Ant2




Duty Cycle NVNT n20 5240MHz Ant1




Duty Cycle NVNT n20 5240MHz Ant2




Duty Cycle NVNT n20 5260MHz Ant1




Duty Cycle NVNT n20 5260MHz Ant2




Duty Cycle NVNT n20 5280MHz Ant1




Duty Cycle NVNT n20 5280MHz Ant2




Duty Cycle NVNT n20 5320MHz Ant1




Duty Cycle NVNT n20 5320MHz Ant2




Duty Cycle NVNT n20 5500MHz Ant1




Duty Cycle NVNT n20 5500MHz Ant2




Duty Cycle NVNT n20 5600MHz Ant1




Duty Cycle NVNT n20 5600MHz Ant2




Duty Cycle NVNT n20 5700MHz Ant1




Duty Cycle NVNT n20 5700MHz Ant2




Duty Cycle NVNT n20 5745MHz Ant1




Duty Cycle NVNT n20 5745MHz Ant2




Duty Cycle NVNT n20 5785MHz Ant1




Duty Cycle NVNT n20 5785MHz Ant2




Duty Cycle NVNT n20 5825MHz Ant1




Duty Cycle NVNT n20 5825MHz Ant2




Duty Cycle NVNT n40 5190MHz Ant1




Duty Cycle NVNT n40 5190MHz Ant2




Duty Cycle NVNT n40 5230MHz Ant1




Duty Cycle NVNT n40 5230MHz Ant2




Duty Cycle NVNT n40 5270MHz Ant1




Duty Cycle NVNT n40 5270MHz Ant2




Duty Cycle NVNT n40 5310MHz Ant1




Duty Cycle NVNT n40 5310MHz Ant2




Duty Cycle NVNT n40 5510MHz Ant1




Duty Cycle NVNT n40 5510MHz Ant2




Duty Cycle NVNT n40 5590MHz Ant1




Duty Cycle NVNT n40 5590MHz Ant2




Duty Cycle NVNT n40 5670MHz Ant1




Duty Cycle NVNT n40 5670MHz Ant2




Duty Cycle NVNT n40 5755MHz Ant1




Duty Cycle NVNT n40 5755MHz Ant2




Duty Cycle NVNT n40 5795MHz Ant1




Duty Cycle NVNT n40 5795MHz Ant2




Duty Cycle NVNT ac20 5180MHz Ant1




Duty Cycle NVNT ac20 5180MHz Ant2




Duty Cycle NVNT ac20 5200MHz Ant1




Duty Cycle NVNT ac20 5200MHz Ant2




Duty Cycle NVNT ac20 5240MHz Ant1




Duty Cycle NVNT ac20 5240MHz Ant2




Duty Cycle NVNT ac20 5260MHz Ant1




Duty Cycle NVNT ac20 5260MHz Ant2




Duty Cycle NVNT ac20 5280MHz Ant1




Duty Cycle NVNT ac20 5280MHz Ant2




Duty Cycle NVNT ac20 5320MHz Ant1




Duty Cycle NVNT ac20 5320MHz Ant2




Duty Cycle NVNT ac20 5500MHz Ant1




Duty Cycle NVNT ac20 5500MHz Ant2




Duty Cycle NVNT ac20 5600MHz Ant1




Duty Cycle NVNT ac20 5600MHz Ant2




Duty Cycle NVNT ac20 5700MHz Ant1




Duty Cycle NVNT ac20 5700MHz Ant2




Duty Cycle NVNT ac20 5745MHz Ant1




Duty Cycle NVNT ac20 5745MHz Ant2




Duty Cycle NVNT ac20 5785MHz Ant1




Duty Cycle NVNT ac20 5785MHz Ant2




Duty Cycle NVNT ac20 5825MHz Ant1




Duty Cycle NVNT ac20 5825MHz Ant2




Duty Cycle NVNT ac40 5190MHz Ant1




Duty Cycle NVNT ac40 5190MHz Ant2




Duty Cycle NVNT ac40 5230MHz Ant1




Duty Cycle NVNT ac40 5230MHz Ant2




Duty Cycle NVNT ac40 5270MHz Ant1




Duty Cycle NVNT ac40 5270MHz Ant2




Duty Cycle NVNT ac40 5310MHz Ant1




Duty Cycle NVNT ac40 5310MHz Ant2




Duty Cycle NVNT ac40 5510MHz Ant1




Duty Cycle NVNT ac40 5510MHz Ant2




Duty Cycle NVNT ac40 5590MHz Ant1




Duty Cycle NVNT ac40 5590MHz Ant2




Duty Cycle NVNT ac40 5670MHz Ant1




Duty Cycle NVNT ac40 5670MHz Ant2




Duty Cycle NVNT ac40 5755MHz Ant1




Duty Cycle NVNT ac40 5755MHz Ant2




Duty Cycle NVNT ac40 5795MHz Ant1




Duty Cycle NVNT ac40 5795MHz Ant2




Duty Cycle NVNT ac80 5210MHz Ant1




Duty Cycle NVNT ac80 5210MHz Ant2




Duty Cycle NVNT ac80 5290MHz Ant1




Duty Cycle NVNT ac80 5290MHz Ant2




Duty Cycle NVNT ac80 5530MHz Ant1




Duty Cycle NVNT ac80 5530MHz Ant2




Duty Cycle NVNT ac80 5610MHz Ant1




Duty Cycle NVNT ac80 5610MHz Ant2




Duty Cycle NVNT ac80 5775MHz Ant1




Duty Cycle NVNT ac80 5775MHz Ant2




Duty Cycle NVNT ax20 5180MHz Ant1




Duty Cycle NVNT ax20 5180MHz Ant2




Duty Cycle NVNT ax20 5200MHz Ant1




Duty Cycle NVNT ax20 5200MHz Ant2




Duty Cycle NVNT ax20 5240MHz Ant1




Duty Cycle NVNT ax20 5240MHz Ant2




Duty Cycle NVNT ax20 5260MHz Ant1




Duty Cycle NVNT ax20 5260MHz Ant2




Duty Cycle NVNT ax20 5280MHz Ant1



Duty Cycle NVNT ax20 5280MHz Ant2



Duty Cycle NVNT ax20 5320MHz Ant1



Duty Cycle NVNT ax20 5320MHz Ant2