



thermaltake

W1 WIRELESS

MECHANICAL GAMING KEYBOARD

MULTI-LANGUAGE
QUICK INSTALLATION GUIDE

Key Features



- A. Bluetooth® Mode Button
- B. 2.4GHz Wireless Mode Button
- C. Gaming Mode Switch
- D. Mute Button
- E. Volume Wheel
- F. Battery Indicator LED

- G. Power Button
- H. Wireless Receiver
- I. Fn + 1 – Bluetooth® Connect 1
- J. Fn + 2 – Bluetooth® Connect 2
- K. Fn + 3 – Bluetooth® Connect 3

System Requirements

- PC with available USB port or Bluetooth® 4.2 enable device
- Windows® Win 7 / Win 8 / Win 10
- Internet connection
- 200 MB of free hard disk space

Package Contents

- W1 Wireless Gaming Keyboard* 1
- Multi-language Quick Installation Guide* 1
- Warranty Card* 1
- Keycap Puller* 1
- Type-C Data Cable* 1
- AA Battery *2

Hardware Installation

2.4GHz Wireless Mode :

1. Turn on your computer and W1 wireless keyboard.
2. Connect the USB wireless receiver to an available USB 2.0 or USB 3.0 port on your PC and press the 2.4GHz wireless mode button on the keyboard.
3. The 2.4GHz wireless LED indicator on the keyboard will turn solid white when automatically connected.



Bluetooth® Mode :

1. Turn on your Bluetooth® 4.2 or higher enabled product and W1 wireless keyboard.
2. Initiate Bluetooth® pairing mode on your device.
3. Press Fn + 1 / Fn + 2 / Fn + 3 and hold Bluetooth® mode button on the keyboard until the Bluetooth® LED indicator rapidly blinks blue.
4. The Bluetooth® LED indicator on the keyboard will turn solid blue when Connected.



Wired Mode :

1. Plug USB connector into your computer. The [Hardware found] notice will appear.



To learn more about the W1 wireless gaming keyboard please visit www.thermaltake.com.

Battery LED Indicator

When you turn on the keyboard or wake it up from sleep, the battery indicator will light up with the current battery level for the first 5 seconds.		INDICATOR LED STATUS
BATTERY STATUS	100 - 21%	GREEN
	20 - 6%	YELLOW
	> 5%	RED BLINKING

Specs.

- Interface : USB / 2.4GHz / Bluetooth®
- Operational system : Windows® Win7 / Win8 / Win10
- Cable length : 1.8m cable with USB connector
- Body dimensions (L*W*H) : 441.95*219.95*40.56 mm

Keyboard Features and Functions

1. Cherry MX switches rated at 50-million keystrokes for the most durable, precise, and responsive tactile feedback.
2. Ultra-durable PBT keycaps provide the best typing and gaming experiences while staying clean and grease-free.
3. Using ultra-fast 1ms 2.4GHz technology, low energy Bluetooth®, or wired USB Type-C connections.
4. Dedicated mute / volume wheel and gaming mode switch.
5. 100% anti-ghosting support across all zones (N-Key Rollover).
6. Disable windows key to prevent accidental activation during gaming.
7. Ergonomic wrist rest design.

繁體中文

品名：W1 無線電競鍵盤

CHERRY MX 青軸型號：GKB-WOW-BLSNTC-01

CHERRY MX 紅軸型號：GKB-WOW-RDSNTC-01

主要特點



- A. 藍芽模式鍵
- B. 2.4GHz 無線模式鍵
- C. 遊戲模式切換開關
- D. 靜音鍵
- E. 音量滾輪
- F. 電量 LED 指示燈

- G. 電源鍵
- H. 無線接收器
- I. Fn + 1 – 藍芽連接 1
- J. Fn + 2 – 藍芽連接 2
- K. Fn + 3 – 藍芽連接 3

系統需求

- 附設 USB 連接埠的電腦或 藍芽 4.2 的裝置
- Windows® Win 7 / Win 8 / Win 10
- 網際網路連線
- 200MB 可用硬碟空間

包裝內容物

- W1 Wireless 無線電競鍵盤* 1
- 多國語言快速安裝指南* 1
- 保固卡* 1
- 拔鍵器* 1
- Type-C 數據線* 1
- AA 電池* 2

硬體與軟體安裝

2.4GHz 無線模式：

1. 開啟電腦 和 W1 無線鍵盤。
2. 將無線接收器連接到電腦上的 USB 2.0 或 USB 3.0 連接埠，然後按下鍵盤上的 2.4GHz 無線模式鍵。
3. 鍵盤上的 2.4GHz 無線模式鍵 LED 指示燈會自動連結時轉為持續亮白燈。



藍芽模式：

1. 開啟已啟用藍芽 4.2 或以上版本的產品和 W1 無線鍵盤。
2. 在裝置上啟動藍芽配對模式。
3. 按下 Fn + 1 / Fn + 2 / Fn + 3 並按住藍芽模式鍵直到 LED 指示燈快速閃爍藍燈。
4. 鍵盤上的藍芽模式鍵 LED 指示燈會在連接時轉為持續亮藍燈。



有線模式：

1. 將 USB 接頭連接到電腦 USB 接口上,即顯示 [Hardware found] (找到新硬體) 通知。



欲知更多 W1 無線電競鍵盤相關資訊及所有功能，請前往 tw.thermaltake.com。