




Dear customer:


Thank you for purchasing A10 Mini Wireless Speaker.
Please read this user guide carefully before operation and
save these instructions for future reference.

Packaging included:

- | | | |
|--------------------------|-------|------|
| 1. Portable Speaker | ----- | 1 pc |
| 2. Usb line (FM Antenna) | ----- | 1 pc |
| 3. User manual | ----- | 1 pc |

Features:

Active Suspension Lighting Effect
Minimal Art Aluminum Anode
Captivating sound, Glowing design
Designed for modern life




Features:



Specifications:

- Output Power: 3W
- Discharge Current: 5V/0.5A
- Battery: 300mah 3.7V
- Product Size: Ø71x42mm
- Speaker Weight: 160g
- Music Play Time: 1-2 hours
- Speaker Output frequency range: 150Hz-20KHz

Function Keys:



1. Mic
2. ON/OFF
3. TF Card Slot
4. Mode Switch/Restore to factory settings
5. Vol-/Previous song
6. Play/Pause/Phone
7. Vol+/Next song

1.ON/OFF

Slide ON/OFF switch to the right to power on. The blue light will come on. Slide ON/OFF switch to the left, the blue light will blink and the unit will power off.

2. Bluetooth Connection

Follow the operating instructions of your Bluetooth device for pairing with the speaker. Typically this is done by going to the "Bluetooth", "Set Up" or "Connect" menu and selecting the option to search for Bluetooth devices.
When pairing, the blue light will blink quickly. Use cell phone or computer or other device search device name "A10", click to connect, blue light turn off when connection successful.
blue light blink quickly when connection out of range.

3. When you play music

1. Short press "Play/Pause/Phone" key to pause music or pause music to answer a call. A second short press second will resume playing music again.
2. Short press "Vol-/Previous song", the speaker will play the previous song.
3. Short press "Vol+/Next song", the speaker will play the next song.

"Play/Pause/Phone" key to redial the last call.
3. When the Speaker is in standby /music mode, double press the hang up.

4. Hands free phone call operation

1. When a phone call is incoming, the blue light remains on. Short press the "Play/Pause/Phone" key to reject the call.
2. When on an active call, short press "Play/Pause/Phone" to long press the "Play/Pause/Phone" key to reject the call.

When speaker is on with TF Card inserted, click "M" key to switch to switch through different modes one by one in this order: Bluetooth - TF Card - FM - AUX - Bluetooth

5. Mode Switch(Bluetooth-TF Card-AUX-FM)

(FM Mode: Connecting the USB cable to be FM Antenna, long press "play / pause" automatic search platform. Some items do not have AUX, FM modes).

Warm Tips

1. In order to avoid damage to your hearing and prolong the speaker's use-life, please don't listen to music for long time in high volume environment.
2. When a fault occurs, please immediately turn off the power switch, unplug the USB plug, prevent speaker and other components damaged.
3. Over use of battery will affect the Bluetooth distance and use-life, please charge in time.

7. Restore to factory settings

In Bluetooth connection mode, long press "M" key for 3 seconds, the blue light will blink rapidly, restoring the speaker to factory settings.

6. Charging

Connect the Micro 5P charging cable to speaker's Micro USB port, insert the other end to the USB port of a 5V charger. A red light is illuminated when charging, and will switch off when full charge is reached.

7. Restore to factory settings

In Bluetooth connection mode, long press "M" key for 3 seconds, the blue light will blink rapidly, restoring the speaker to factory settings.

Free music

FCC Instructions

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the product.

NOTE: This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures :

- Reorient or relocate the receiving antenna.
- Increase the separation between the product and receiver.
- Connect the product into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Shenzhen Minsuo Import & Export Co.Ltd