

B-380 Bluetooth Headphone Users Manual

Packaging Content:

1. B-380 Bluetooth Headphone
2. USB Charging Cable
3. Line-in Cable

Understanding the buttons and ports of your B-380 Wireless Bluetooth Headphone:



1. On/Off Switch – Turn On/Off of the Headphone. (Line-in connection does not require to turn the headphone On)
2. Play/Pause, Volume Control – Push wheel in for Play or Pause of tracks playback. Turn wheel Left or Right for volume increase or decrease.
3. Power Charging Port – Connect supplied charging USB Cable for power charging of headphone
4. Charging Indicator LED – Turns on while charging.



1. LCD Display – Display the current selected mode and FM Radio Stations selected
2. Call Answering/Hang Up Button – For Bluetooth Connected Phone Answering Function
3. Model Selection, Track Skip/Rewind Control – Push in the wheel for mode selection between 3 modes – MP3 (TF Card Slot), FM Radio, or Bluetooth Connection. Turn the Wheel Left or Right for Track Skip or Rewind while playing music track or for Radio Station changing.
4. Line-In Jacks – Connect Line-In cable with any Audio Output devices, Microphone jack is supported for Line-in Microphone. (Line-In function does not require battery usage of the headphone)
5. Indicator LED – Flashes while attempting of Bluetooth pairing.



TF (Micro SD) Card Slot

TF Card (Micro SD) Slot is located on the top of the Right side Ear Pad which has the LCD Screen. Support up to 32GB of capacity.

Charging your Bluetooth Headphone for the first time:

Although all the headphones already came with some pre-charged battery life for production QC, it is always recommended that you first fully charge the headphone for at least 2 to 4 hours prior first use.

Use the USB Charging Cable supplied to connect with the Power Charging Jack input on the Headphone and connect the USB connection to any 5V USB Power Charging Adapter or a Computer USB Port.

Pairing with your Bluetooth enabled devices with the B-380 Headphone:

You will need to Pair the Headphone with your Bluetooth device for the first time of use. Please note that headphone can only pair with one device at a time. If you need to use the headphone on another device, please make sure to delete the pairing setting on the previous connected device before connecting and pairing with a new device.

To Pair the headphone with your device:

- 1) Turn on your device's Bluetooth discovery mode.
- 2) Turn on the B-380 Bluetooth Headphone.

- 3) Your device should find an unpaired device name B-380 on your device's screen.
- 4) Select the B-380 and the headphone will automatically pair with your device. Your device is now ready to stream audio to the B-380 Headphone via Bluetooth connectivity.

Using the TF (Micro SD) Card for MP3 playback:

- 1) Insert a TF (Micro SD) Card into the slot.
- 2) Select the MP3 Mode
- 3) Playback should start Automatically

Using the FM Radio:

- 1) Select the FM Radio Mode
- 2) Turn the track select wheel to tune into the station you wanted to listen to

** Please note that due to reception signal strength, quality of the Radio broadcast may vary depending of your location. When you are in movement, signal strength may get affected. **

SAFETY OF USAGE:

- Due to battery nature contain in the headphone, avoid exposing headphone to extreme temperature and extensive amount of time directly under sun light.
- Do not temper or try to disassemble the headphone. Do not hammer, or throw headphone.

- Extensive amount of time listening to loud audio may cause harmful result to your health. Please use proper volume for audio and music enjoyment.

FCC INFORMATION

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION: Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.