

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Applicant: Shenzhen Microtouch Ergonomic Technologies Inc
Add: Suit#A, 26th Floor, Jinfeng Villa Bldg. QianJin Road,#26 Baoan District,
Shenzhen,Guangdong Province
Eut: Wireless mouse
Model:RS200WM, RS200WL, N100WM, N100WL

RÖCKSTICK MOUSE
Ergonomic Laser Mouse



User's Guide



www.rockstickmouse.com

Trouble Shooting:

The cursor moves too slow or too fast

Adjust the DPI button located on top of the mouse to find the right speed for you.

When you push the DPI button, if the word "DPI" flashes one time means slow speed;
two times means regular speed;
three times means fast speed;
four times means super fast speed.

The cursor doesn't move after some time without usage

The wireless version will sleep after a few minutes without usage to save battery power. Just click any button to wake it up.

There is no red light from the sensor located at the bottom as other optical mice

It is laser sensor instead of optical. There is no red light coming out from the laser sensor. Please don't check the light with your eyes directly. It may cause uncomfortable or even minor or moderate eye injury if you check with your eyes directly.

How to switch from one hand to the other hand?

Just push the switch under the mouse from R to L or from L to R.

QUICK START:

1. Pull out the USB dongle receiver from the bottom of Rockstick 2 mouse.
2. Connect the USB dongle receiver to the USB port of you computer.
3. Turn on the power switch at the bottom of the Rockstick 2 mouse.
4. Driver will be installed automatically.
5. Ready for use.



Ergo-Grip: Anchoring with your elbow or wrist for maximum ergonomic comfort.



Precise Grip: Anchoring with your wrist and fingertip for maximum precision.

