

AR GUN USER MANUAL



Smart device is not included. Rev.1.2
Item # AR-1

AR GUN USER MANUAL

Thank you for purchasing AR Gun from AR Attack.


PACKAGE CONTENTS

- 1 x AR-1 Gun
- 1 x Smartphone holder
- 1 x Instruction Guide
- 1 x AR Poster
- 1 x Quick Installation Guide

- This device is not intended to provide protection to the smart device.
- AR Attack is not responsible for any damage.
- Adult assembly required.
- Be aware of your surroundings and other people when play.
- Hold your AR Gun firmly.

OVERVIEW

AR-1 Gun



DOWNLOAD THE APP

ARLlens is available from the AppStore or Android Marketplace.



You can also visit **www.arattack.com** or  AR Attack Toys 

COMPATIBILITY

AR Gun supported the following devices at the time of printing. More supported devices are coming. Please visit **arattack.com** <SUPPORT> page for the latest supported devices.

Model AR-1: Android & Apple iOS

Android* Tested with Samsung Galaxy S4, S5 and Note 2 & Note 3; HTC One & Butterfly S; Nexus 4 & 5.
*must install OS 4.4 or higher with Bluetooth LE 4.0.
More support devices are coming.

Apple iOS Tested with iPhone 4S, iPhone 5, 5C, 5S and iPod Touch 5th Generation.

BATTERY DETAILS

AR Gun requires 2 x "AA" size batteries (Alkaline Batteries recommended).

Please ensure the batteries are placed in the correct polarity (+) / (-) See bottom of gun.


If AR Gun does not perform correctly, please replace with new batteries.

The AR Gun is equipped with Auto-Off after about 10 minutes of idling without pulling the trigger.

IMPORTANT BATTERY INFORMATION

1. Remove small locking screw and battery cover in bottom.
- 2.
3. Remove used batteries. Insert 2 new batteries ensuring "+" positive pole of batteries are placed as markings shown.
- 4.
5. Replace the battery cover and screw.
6. Do not mix old and new batteries.
Recommended to use

BATTERY INSTRUCTION



Step 1- Attach the holder to AR Gun

Take out holder from packaging. Align bottom of holder and insert on top of gun and gently push in. Make sure both holder and gun are securely attached.

Step 2- Place smart device in the holder

- A) Open the holder mount by pressing the button on right side.
- B) Place your smart device in center of holder and press down the upper mount.
- C) Press down the upper mount until it is tightly clipped and smart device is secured.

NOTE: Check if device's camera is not blocked by anything and the volume buttons are not pressing down.

Step 3- Connect with AR Gun

- A) << **IMPORTANT** >> Switch Bluetooth to 'ON' on your device **BEFORE** loading the app.
- B) AR Gun will detect and pair** automatically with your device once you set the Bluetooth to 'ON' on your device. Start the APP and select "Single Player" to play.

*** Bluetooth connection may take up to 30 seconds to pair with the AR Gun. Once it is paired, AR Gun will be activated automatically.*

NOTE: If you are using smartphone to play, you will need to detach from phone mount to answer any incoming calls

HOW TO PLAY?

Single Play / Multi-Play*

Select “Single Player” button in main menu. After selected weapon(s), pull trigger to continue or touch screen to begin.



Main Menu



In-game Instruction



Medals Collections



Look out for the raging Aliens on radar (red dots)

Actual screen and colour may vary

App Download: Android & Apple iOS

iOS



Android



* For Multi-Play, please refer to web site for the latest setup.

The box set is included with one AR Poster. Additional posters are available on web site. The game app will provide instruction when to use them.

Please keep markers in a safe place. To check with the latest AR Posters, please visit our **< SUPPORT >** page on www.arattack.com.

Trouble Shootings:

- Q: What if I started the App accidentally before switch "ON" Bluetooth?
A: Manually exit the APP. Turn 'ON' Bluetooth from device setting menu. Start App again.
- Q: Bluetooth is just not connecting even after I switched 'ON' before starting the App?
A: Bluetooth may take up to 30 secs to pair with the AR Gun.
- Q: It is just not working!
A: Check your batteries in correct polarity. And/or, replace the batteries in gun with two new Alkaline AA size batteries and start again.
- Q: I paired my AR Gun earlier but now can't play!
A: Make sure there is only one Bluetooth device is set to 'ON' with the AR Gun. Turn off the other devices and start again.

NOTE: If you are using smartphone to play, you will need to detach from phone mount to answer any incoming calls

For optimal AR experience:

Please stick AR Poster on a flat surface (Wall / Back of Door) with adequate lighting.

Point AR Gun at AR Poster at about 2 feet (60cm) distance.

For replacement of AR Poster, you may download from:

<http://download.arattack.com/Marker1.pdf>



WEBSITE
www.arattack.com

FACEBOOK
AR Attack Toys

IMPORTANT BATTERY INFORMATION:

- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the toy before being charged.
- Rechargeable batteries are only to be charged under adult supervision.
- Different types of batteries or new and used batteries are not to be mixed.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.



The equipment that you have purchased has required the extraction and use of natural resources for its manufacturing. It may contain substances that are hazardous to health and the environment. In order to prevent release of these substances into the environment and to reduce the pressure on natural resources, we encourage you to use appropriate return systems. These systems will ensure that most of the materials in your equipment are properly reused or recycled at the end of its operational life. The crossed-bin symbol invites to use these systems. For further information on collection, reuse and recycling systems, please contact your regional waste management administration.

This symbol is only valid in the European Union. If you wish to discard this product, please contact your local authorities or dealer and ask for the correct method of disposal.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: – Reorient or relocate the receiving antenna. – Increase the separation between the equipment and receiver. – Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. – Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

CAUTION:

Know your surroundings and clear the area of any obstructions before each use.
To avoid fatigue and strain, take frequent rest during each use if necessary.

DISCLAIMER:

iPhone and iPod Touch are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc.
Android is a trademark of Google Inc., registered in the U.S. and other countries. Google Play is a service mark of Google Inc.

CONTACT INFORMATION:

For more information about the AR Gun and more products, please go to www.arattack.com

Product and colors may vary from actual. This product is made and manual is printed in China.
Product names, designations, and logo are trademarks or registered trademarks of Maksco Toy Ltd.
AR Attack is a registered trademark of Maksco Toy Ltd. All Rights Reserved.
Patent Pending 201330039682.3.
MAKSCO TOY LTD., 7/F, 6 HUNG TO ROAD, KWUN TONG, KOWLOON, HONG KONG