

Apolosign

Wireless Karaoke Microphone Instruction Manual


Packing list:



Receiver *1



Microphone *2



Type-C charging port



Portable smart screen



1. Insert the receiver into the USB port of the portable smart screen.
2. Press the microphone power  button for 3 seconds to turn it on.
The LED light will stay on, and the corresponding blue signal LED indicator on the receiver will also stay on, indicating that the microphone and receiver communicate normally.
3. When the microphone's red light flashes, it indicates a low battery. Please use a dual-headed Type-C charging cable to connect to the DP-IN port to charge the microphone. During charging, the red LED indicator on the microphone will remain lit and turn off once fully charged.

Professional sound | Plug and play | Set Bundle | Energy saving

Title: Wireless microphone

Model: MM-15

Manufacturer: Shenzhen Electron Technology Co., Ltd.

Address: Bld.2, Yingfeng Industrial Zone Tantou Community,
Songgang Street, Bao'an, Shenzhen, China.

E-mail: packgo@elclcd.com

Made in China



FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device

can be used in portable exposure condition without restriction.