


CE TEST SETUP(adapter: 12V)




RE TEST SETUP(adapter: 12V)



Model No.: WR-393

RE TEST SETUP(adapter: 12V)




Model No.: WR-393

CE TEST SETUP(adapter: 18V)



RE TEST SETUP(adapter: 18V)



Model No.: WR-393

RE TEST SETUP(adapter: 18V)

