




single finger touch movement	single finger touch	single finger double tap and drag	slide finger slide to
cursor movement	left key	mouse document	right key
double finger touch and move up and down	three fingers moves up	three fingers moves down	three fingers moves left/right
wheel mouse up and down	Win 10 best switching	Win 10 desktop display	four finger backspace
four fingers tap	three fingers tap	double fingers pointing right/left	
Win 10 transfer operation center	Win 10 transfer contacts	edge/teaching	

A detailed diagram of the Microsoft IntelliMouse Explorer 3.0. The mouse is shown from a top-down perspective, highlighting its ergonomic design. Key features labeled include:

- Buttons:** Left button, Right button, and a central 'Ok' button with four directional arrows (Up, Down, Left, Right).
- Scroll Wheel:** A circular scroll wheel with a central 'Enter' button and a 'Back' button.
- Function Keys:** F6, F7, F8, F9, F10, and DEL.
- Other Keys:** 'Back', 'Enter', 'Exit', 'End', 'Home', 'Left', 'Right', 'Up', 'Down', 'F6', 'F7', 'F8', 'F9', 'F10', 'DEL', 'Back', 'Enter', 'Exit', 'End', 'Home', 'Left', 'Right', 'Up', 'Down'.



Fn+F1	the signal between the keyboard and USB receiver /recover the signal between the keyboard and receiver
Fn+Space	adjusting the mice sensitivity of touch-pad
Ctrl+Alt+Del	open the task manager
Fn+F7	full desktop screenshot function
Fn+F8	lock the touchpad
Fn+F9	F11
Fn+F10	F12
Fn+PgUp	jumping to the beginning of the letter/text
Fn+PgDn	jumping to the end of the letter/text
Fn+F6	open/close the backlit of the keyboard

In line with the policy of continued development, The manufacturer reserves the right to amend the specifications without prior notification. The pictures and date in the stylebook are consult only if there is fluctuation. According to the real object please.


Since devices using 2.4G technology communicate using radio waves your device and the other devices do not need to be in direct line-of-sight. The connection can be subject to interference from obstructions, such as walls, or other electronic devices.

This is a wonderful combo.2.4GHz Mini Wireless QWERTY keyboard,TouchPad combo,with USB interface Adapter.

For the lecturer, sales manager, presenter, from within a 30' radius make a presentation and operate PC wirelessly. Change slides and screen options, write on the screen, emphasize words and objects just by using this wireless Mini Keyboard and Mouse with Touch Pad.

For people who want to watch internet TV play on their standard TV via broadband and a PC, like NBC, ABC, FOX and IPTV, Android TV Box / I use this wireless mini combo, who can sit in comfortable chair and select viewing pleasures without walking to computer to change channels or scroll through options.

Shenzhen Sungi Technology Co., Ltd
Phone: 86-755-61587655
Website: www.szsungi.cn
Add: 4F, 20th BLD, Xiawei Yuan, Gushu, Bao'an district, Shenzhen, China



Support PC, Computer, Smart TV, Internet TV Box, Android TV Box,
Projector, video teaching equipment, ect.

Connecting the receiver
Slide the receiver out from the side of keyboard, and insert to the devices with a standard USB interface. Once connected, slide the power switch to the "ON" position located on the left side of the unit to establish the connection.

Note: play to switch ON, will flash lights, and then the lights out ON the keyboard, receiver connected to the keyboard, success can be normal use of the keyboard. If you find lights flash or no flash, please check:

- A. the distance between the receiver and the keyboard is in the range of 10 m.
- B. the receiver is plugged into,

The keyboard also features an auto sleep and auto wake mode. If there is a long period of inactivity, the keyboard will automatically go into a sleep mode. During the sleep mode, the user can wake the unit up by pressing any key. The 2.4 GHz receiver and keyboard's RF indicator will continue to flash and will not power down.

After finishing using the keyboard, push the switch to the off position. This turns off the power of the keyboard. The USB receiver should be plugged out from the PC and then inserted back in the keyboard so it is being kept safely.

Charging the battery(Only for Configure A)
The device with built-in lithium-ion battery, please use only approved data lines and chargers.

Fully charge the unit before operating for the first time. This device can be used when charging but will extend the charging time; When the battery is low, the low-voltage light will flash to warn the user. The unit will automatically turn off if the battery has been depleted.

Notes: this product has A B C three configurations can choose.
Configure A: lithium battery version, this version built in rechargeable lithium battery, additional charge USB line.
Configure B: install AAA 2 battery, this version does not support the charging function

Configure C: Backlit version, this version is only suitable for lithium battery configuration. The receiver must be insectile to fit back light
press the FN+F6: turn on backlight
press the FN+F6: turn off backlight

Backlight dormancy: 1 minute not operation, automatically shut down;
Backlight reset: press any key or touch start automatically.
Backlit open working current: 12 mA
Backlight color: cold blue highlight
Backlit normal use time: about 30 days
Backlit continuous working time: about 120 hours
Backlit battery capacity: 600 mA
Charging time: 4-5 hours

Low voltage alarm
Lithium electricity: below 3.3V low voltage alarm, orange light.
Dry electric: below 2.0V low voltage alarm, orange light.
Alarm way: on the left side of the first light, press keys or open, flashing 3 times.

- Measurements (L x W x H): 152X126,5X18,5mm
19mm
- Weight (grams): 148g
- Operational Range: up to 25 meters
- Transmit power : +4db Max.
- Operation voltage: 3.3V
- Operation current: < 5mA
- Charging current: < 300mA
- Sleep current: < 1mA

Below are some basic troubleshooting scenarios for the device. Please contact support from the place of purchase if you are unable to resolve any issues with the device.

Problem	Possible Issue	Solution
Unit does not respond	1. Low battery power 2. Unit is not turned on	1. Configure A: Charge the device for at least 15 minutes - Configure B: Replacement of the AAA "2" battery 2. Check if the switch selected to the "ON" position
Keyboard cannot establish a connection to the receiver.	1. The receiver may not be inserted correctly	1. Disconnect and reconnect the receiver to this USB port.
The mouse pointer moves erratically and/or unresponsive.	1. Device may not be within optimal range of the receiver 2. Low voltage 3. Dust or oil on the touchpad.	1. Bring the unit closer to the receiver. 2. Please recharge/replace Configure A) or replace the battery(Configure B) 3. Clean the touchpad with a damp cloth.
The unit does not charge only for Configure A	1. Defective battery 2. Check cord/padlock	1. Contact your local dealer for replacements. 2. Verify if the device is securely connected to the charger
Unit does not respond (light flash)	1. The receiver may not be inserted correctly 2. Keyboard cannot connect to the receiver(s)	

- Windows 2000
- Windows XP
- Windows Vista, Windows CE, Windows 7
- Linux (Debian-3.1, Redhat-9.0, Ubuntu-8.10, Fedora-7.0 tested)

- Do not attempt to disassemble the device or replace rechargeable battery. Doing so will void the warranty.
- The battery will discharge if stored for a long period of time without usage.
- Use the specified charger. Disconnect the device after the battery has been fully charged. Overcharging the battery will shorten the life span of the battery.
- Do not expose the device in extreme heat or cold. Extreme temperatures will cause the life span of the battery to shorten.
- Use only a damp cloth with mild soap to clean the device. Solvents and other cleaning agents may cause damage to the device.

This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID:2ABDB-T8K