


1. Install the iSwimband App

Download and open the iSwimband app from your device




Agree to allow notifications and to the disclaimer

WARNING: If you do not allow notifications and are not actively using the iSwimband app, you will not receive alerts.




2. Checking Notification Settings in iOS

- ▶ Open Settings and choose “Notification Center”
- ▶ Scroll down and choose “iSwimband”
- ▶ Make sure “Alerts” is selected and all options are set to ON (green)
Note: Do not use Banners because they disappear automatically and could cause you to miss an alert.




3. Connecting an iSwimband

- ▶ Power on the iSwimband by lightly tapping it on a firm surface 5 times and waiting for the red blinking light




NOTE: The device will automatically shut off after 10 minutes of inactivity or when disconnected from the app. To disconnect the device, close the iSwimband app on all of your devices by double-tapping the home button and swiping up on the iSwimband screen.

- ▶ From the Monitor tab, choose “Add an iSwimband”



- ▶ Tap an available iSwimband to connect
- ▶ Enter the last 6 digits of the serial number located on the device or on the box and tap “Continue”
- ▶ Customize the name to identify the wearer
- ▶ Choose a wearer type and tap “Continue”



4. Configure for a Non-Swimmer

- ▶ Non-Swimmers do not need any further setup.
The alert will sound 3 seconds after a non-swimmer’s wristband is submerged
- ▶ Confirm your settings and return to the iSwimband Monitor screen
NOTE: On this screen you can disconnect the iSwimband when not in use to prevent battery drain




5. Configure for a Swimmer

- ▶ Select the iSwimband to configure
- ▶ Press the Edit button
NOTE: On this screen you can disconnect the iSwimband when not in use to prevent battery drain
- ▶ Select a period of delay before an Alert
NOTE: Increasing the delay above 20 seconds on the headband is contrary to the advice of aquatic safety professionals
- ▶ Select the amount of time before an alert to show a Warning
NOTE: Leaving the setting on “Immediate” will let you know whenever a swimmer is underwater
- ▶ Tap “Save”
- ▶ Confirm your settings and return to the Monitor tab




6. In-App Warnings and Alerts

- ▶ The “Current Status Monitor” bar shows the total number of swimmers in all alert states
 - ▶ Warnings will show as a yellow highlight behind the wearer’s id/name
 - ▶ Alerts display the wearer’s id/name on a red screen
- NOTE: Dismissing the alert will show a red highlight




7. Inserting the Sensor

Headband
(for swimmers)




Wristband
(for non-swimmers
and toddlers)

NOTE: The sensor cannot be removed once inserted into the wristband



8. Adjusting and Fitting the Strap



Regulations

FCC COMPLIANCE STATEMENT:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

INFORMATION TO USER:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy. If not installed and used in accordance with the instructions, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the distance between the equipment and the receiver

- Connect the equipment to outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help.

Canada – Industry Canada (IC)

This device complies with Industry Canada license-exempt RSS Standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. Cet appareil est conforme avec Industrie Canada exempts de licence standard RSS (s). Son fonctionnement est soumis aux deux conditions suivantes: (1) cet appareil ne doit pas provoquer d'interférences et (2) cet appareil doit accepter toute interférence, y compris celles pouvant causer un mauvais fonctionnement de l'appareil.

© Aquatic Safety Concepts, LLC. All rights reserved. Apple, the Apple logo, Airplay, iPad, iPhone, and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc. The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG Inc. For illustrative purposes only. Your results may vary. Product specifications subject to change without notice. www.iSwimband.com

NEVER let anyone swim alone.
Not intended as a replacement
for diligent supervision.

