


Skype 專用機3G版

PChomeTalk Phone
for Skype 3G




Getting Started Guide

(GSM850/900/1800/1900/WCDMA/WIFI/Bluetooth)

Model:PT2

For the complete user guide and other helpful resources,
go to www.pchometalk.com.

| Device Overview




- | | |
|-------------------------------|------------------------|
| 1. Earpiece | 11. 3.5mm headset jack |
| 2. Front camera lens | 12. USB port |
| 3. Proximity and light sensor | 13. Camera lens |
| 4. POWER | 14. LED flash light |
| 5. VOLUME | 15. Back microphone |
| 6. Touch screen | 16. Battery cover |
| 7. Back Key | 17. Speaker |
| 8. Home Key | |
| 9. Menu Key | |
| 10. Front microphone | |

| Charging The Battery

It is recommended that you charge the battery for at least three hours before using the device for the first time.

The device prompts a warning tone and message stating insufficient battery when the battery power is low. Please follow the instructions below to charge your device:

1. Insert the small end of the USB cable into the USB port.
2. Insert the other end of the USB cable into the power adapter.
3. Plug in the power adapter to an electrical outlet to start charging the battery.



| Power on/off the device

After charging the battery, you are now ready to turn on your device.

Turning On the Device

Press and hold the Power button until the PChomeTalk animation appears on screen.


Turning Off the Device

1. If the screen is turned off, activate it by using the Power button.
2. Press and hold the Power button for 3 seconds.
3. Select Power Off from the pop-up window when prompted.

| Inserting SIM Card(s)

The PChomeTalk phone features dual-SIM and supports SIM cards of different varieties.

1. Switch off your device before installing a SIM card .
2. Remove the back cover by lifting up from the left bottom corner with the back of the handset facing you.
3. Insert the SIM card(s) into the device.
4. Attach the battery.
5. To close the battery cover, push it until it clicks into place.



| Getting Started

1. Language Setting

PChometalk

繁體中文


简体中文

English

2.Wi-Fi Setting


Select the "Wi-Fi Setting" option to display a list of available networks.

Enter a wireless network's password to connect and press the  button to login to Skype.



3.Entering PCHomeTalk UI's mainscreen

Tap "Sign in" to sync contacts from your Skype account, or tap "Skip" to access your phone contacts directly.




Skype Calls

Send instant messages and make voice/video calls to anyone on Skype for free; use Skype credits to call mobile/landlines and send SMS messages.

1. Retriving Skype Contact List

After logging in to your Skype account, your contacts and their online statuses will be shown on screen.

Your list will be prioritized to show your Skype contacts first. Your phone contacts will be shown in the "Others" section.



▶ Skype contacts and status

▶ Phone contacts and status

▶ Your Skype status

2. Sync Skype Contact List

To refresh your contact list and see their latest statuses, simply swipe down on the PChomeTalk UI contact list screen.

