


178mm

44.5mm

FCC ID:2ABHA0095

Ifidelity Auto Pair True Wireless Earbuds with ANC Instruction Manual 7197-37



| 01


Hello! This is your instruction manual, to help create the best possible experience with this cool product.

Safety Precautions:

1. Please follow the rules described in this manual closely to ensure your safety.
2. Before using the earbuds, we would strongly encourage you read this manual.
3. Do not modify, repair or dismantle the earbuds or power bank.
4. Do not use any liquids to clean the products.
5. Do not use the earbuds near water, or intense temperatures.


| 02

Included Contents:



**Also includes: Extra Ear tips (Small and Large)

Product Overview:



1. Touch Multifunction Button
2. Earbud LED Indicator
3. Charging Case LED Indicator
4. Charging Case
5. Type-C Input Port

| 03

Charging:

** The battery isolator on both earbuds need to be removed in order to be charged. Besure to charge the devices completely before initial use. **

1. Charging the earbuds
 - Magnetic contact recharging, once placed into the charging case and close the lid earbuds will begin to charge automatically.
 - The case LED (3) will turn WHITE for 1 second when place the earbuds into the charging case. Make sure the case lid is closed to confirm the charging has begun.
2. Charging the power case
 - Use the Type-C cable to connect to an adapter or computer to charge the power case.
 - When charging the power case LED light will turn RED.

| 04

- Once fully charged, the power case LED will turn off.
- Open the case, the charging case LED will glow GREEN, ORANGE, or RED to indicate the battery life.
 - Green LED – case has 80%-100% power
 - Orange LED - case has 40-79% power
 - Red LED - case has 15%-39% power
 - Red LED (flashing) – low battery

Stereo Earbud Usage:

1. Pairing: First time
 - Open the charging case lid, the earbuds will auto power on and auto-pair to each other after a few seconds.
 - Now activate Bluetooth on your mobile device. If the pairing is successful, only one "Ifidelity ANC TWS" pairing name will appear.

| 05

2. Search and Pairing
 - Select "Ifidelity ANC TWS" from your Bluetooth function.
 - When you hear "Connected", you will be successfully connected to your Bluetooth.
 - The earbuds are now ready to be used.
 - Previously paired earbuds connected automatically when power is switched ON.
 - If the earbuds didn't pair to your phone successfully, place them back into the charging case and closed the lid, then open the lid to pair again.

3. Power ON:
 - Open the charging case lid.
4. Power OFF:
 - Place your earbuds back into the charging case and close the lid.

| 06

5. Calling
 - Answer/End Call: Touch the multifunction button once to answer an incoming call, and again to end the call.
 - Reject a call: Press and hold the multifunction button for 2 seconds to reject an incoming call.
6. Playing Audio
 - Touch the multifunction button on the right or left earbud to play/pause your audio.
 - Double touch the right ear multifunction button to go to the next track and double press the left button to go to the previous track.
 - If you want to adjust the volume, you must use the connected device.
7. Activate Voice Assistant: Triple touch the multifunction button, you will hear a beeping sound to indicate that your voice Assistant/Siri is "activated" and awaiting your commands.

| 07

8. ANC ON/OFF & Transparency Mode: Long touch any earbud to switch between ANC ON /ANC OFF/ Transparency modes, earbuds will voice prompt each mode.


9. In-Ear Detection:
 - When playing music, if one or both earbuds are removed from the ear the music will stop.
 - Once the earbuds is placed back into the ears, music will auto resume
 - If earbuds are removed for a extented amount of time, music will not automatically resume and will need manually resumed.

Resetting your earbuds:

- If you have trouble pairing your earbuds, turn off your bluetooth.
- Place both earbuds back into the charged power case.
- Now remove the earbuds and follow the instructions under "Pairing Both Earbuds".

| 08

front side



Single Earbud Usage:

- Pairing for the first time
 - Open the charging case lid, the earbuds will auto power on.
 - Open your Bluetooth options, switch on Bluetooth and select the pairing name "ifidelity ANC TWS".
 - If pairing is successful, you will hear the voice prompt "Connected".
 - If you would like to sync the earbuds, simply remove the other earbud from the case. The earbuds will pair automatically.
- Power ON/OFF
 - Power ON: Open the charging case lid.
 - Power OFF: Place your earbud back into The charging case and close the lid.
- Once the earbud is successfully connected with your device, you can listen to audio.

- Answer/End calls: Touch the multifunction button once to answer an incoming call, and again to end.
- Reject a call: Touch and hold the multifunction button for 2 seconds to reject an incoming call.
- Music: Touch the multifunction button once to pause the music or play the music.
- Activate Voice Assistant: Triple press the multifunction button, you will hear a beeping sound to indicate that your voice Assistant/Siri is "activated" and awaiting your commands.

Earbud Tech Specifications

Items	Specifications
Charging time	1.5 hrs (from 0-100)
Play time(ANC OFF)	5 hrs
Play time(ANC ON)	4 hrs
Bluetooth Range	10m
Mic Sensitivity	-42+3db

Power Case Tech Specifications

Items	Specifications
Charging time	2.5 hrs (from 0-100)

Mobile devices cannot connect with the earbuds if the earbuds are not in pairing mode.

If the earbuds are unable to connect to a mobile device via Bluetooth for 5+ minutes, the earbuds will power off automatically.

Troubleshooting

Issue	Reason	Solution
Start-up failure	low battery	charge earbuds and power case
Shut down automatically	low battery	charge earbuds and power case
Noise during calls	mobile device is too far away	bring mobile device closer

Signal interrupted	environment disturbance, distance too far from mobile device	bring the mobile device closer to the earbuds
--------------------	--	---

Safety Precautions

WARNING--When using this product, basic precautions should always be followed, including the following:

- Fully read the instructions before using the product.
- The unit will only achieve full performance after 2 or 3 completed charge and discharge cycles.
- Do not overcharge your case. The unit may become hot under excessive use. Remove your case once it is fully charged. Never charge your case for more than 7 hours at a time.
- To reduce the risk of injury, close supervision is required when the product is used near children.
- Do not expose the device to moisture.
- Do not use the device in excess of its output rating. Overload outputs above the rating may result in a risk of fire or injury.
- Do not use the device if damaged or modified.
- Damaged or modified batteries may exhibit unpredictable behaviour resulting in fire, explosion or risk of injury.
- Do not disassemble the device. Take the device to a qualified technician if service or repair is

- required. Incorrect reassembly may result in a risk of fire or injury.
- Do not expose the device to fire or excessive temperatures. Exposure to fire or temperatures above 212°F/100°C may cause explosion.
 - Have servicing performed by a qualified repair person using only identical replacement parts.
 - This will ensure that the safety of the product is maintained.
- #### FCC Statement
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
 - This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates

- uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- This device complies with part 15 of the FCC

rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:
The device has been evaluated to meet general RF exposure requirement.
The device can ben used inthe portable exposure condition with restriction

back side