






Press the
Menu Button




Using UP and Down to select the menu item and Press OK to enter the menu.

1. Press "Menu" Button
2. Using Up and Down to Select "Today's Activity"
3. Press "OK"



Select Analog Watch Faces

1. Press “Menu” Button
2. Using Up and Down to Select “Analog Watch”
3. Press “UP” and “Down” to Select your favorite Watch Face
4. Press “OK” to confirm




Select Digital Watch Faces

1. Press “Menu” Button
2. Using Up and Down to Select “Digital Watch”
3. Press “UP” and “Down” to Select your favorite Watch Face
4. Press “OK” to confirm



1. Press “Menu” Button
2. Using Up and Down to Select “World Clock”
3. Press “UP” and “Down” to turn pages. We support total 6 world cities in 2 pages.
4. Press “OK” to confirm




1. Press “Menu” Button
2. Using Up and Down to Select “Calendar”
3. Press “OK” to confirm
4. Then you will see the bottom hint. You can check previous month or next month
5. Press “Menu” to exit

Button Hint:
Previous Month



Button Hint:
Next Month


1. Press "Menu" Button
2. Using Up and Down to Select "Stop Watch"
3. Press "OK" to confirm
4. Then you will see the bottom hint.
5. Follow the Button Hint to Operate




When you jump into stop watch, it will show button hint in this particular function.


Hit will change

1. Press “Menu” Button
2. Using Up and Down to Select “Countdown Timer”
3. Press “OK” to confirm
4. Then you will see the bottom hint.
5. You need to select “SS”, “MM” and “HH”
6. Then it will start count down.







When you jump into count down timer, it will ask you to set HH:MM:SS to count down, start from SS.



Press Up and Down to select the value and Press ok to move to the next




When you finish the HH, you press OK, the bottom hint will change




When you press Start, the timer will start to count down

1. Press “Menu” Button
2. Using Up and Down to Select “Music Control”
3. Press “OK” to confirm
4. You will see some button hint and follow the hit to control the music player




When you come into music control function, the button hit will change again.


1. Press "Menu" Button
2. Using Up and Down to Select "Sports Watch"
3. Press "OK" to confirm
4. You will see some button hint and follow the hit to control the Sports Watch.




1. Press “Menu” Button
2. Using Up and Down to Select “Setup”
3. Press “OK” to confirm and enter to the second menu



1. Press “Menu” Button
2. Using Up and Down to Select “Setup”
3. Press “OK” to confirm and enter to the second menu
4. Using Up and Down to Select “Time”, you will select MM:HH
5. Using Up and Down to Select “Date”, DD:MM:YY





1. Press "Menu" Button
2. Using Up and Down to Select "Setup"
3. Press "OK" to confirm and enter to the second menu
4. Using Up and Down to Select "Bluetooth"
5. You will see the button hint to operate



1.9.4 ANT/ANT+

1. Press "Menu" Button
2. Using Up and Down to Select "Setup"
3. Press "OK" to confirm and enter to the second menu
4. Using Up and Down to Select "ANT+"
5. You will see the button hint to operate







List Of Notification

1. Incoming Caller ID
2. SMS
3. Email
4. Calendar Alerts
5. Facebook
6. Twitter
7. Weather Alerts

These notification can pop onto your screen any time in any apps by your setting. We need the design how these 7 types of notification to be displayed/overlay on the watch face.




1. Incoming Call Icon
2. Notification Type
3. Name
4. Phone Number




If the message is too long,
use up and down to
scroll and there is bar
indicator.

1. Incoming SMS Icon
2. Notification Type
3. Name or Phone Number
4. SMS Content




If the message is too long,
use up and down to
scroll and there is bar
indicator.

1. Incoming Email Icon
2. Notification Type
3. Sender Name
4. Email Title
5. Mail Content




If the message is too long,
use up and down to
scroll and there is bar
indicator.

1. Calendar alert Icon
2. Notification Type
3. Due Time
4. To do content




If the message is too long,
use up and down to
scroll and there is bar
indicator.

1. Facebook alert Icon
2. Notification Type
3. Name
4. Message Content





If the message is too long,
use up and down to
scroll and there is bar
indicator.

1. Twitter Alert Icon
2. Notification Type
3. Name
4. Message Content



1. Weather Type Icon
2. Degree
3. Location
4. Weather Message





FCC statement

- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.
- These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

- If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Certification information (SAR)

This device is also designed to meet the requirements for exposure to radio waves established by the Federal Communications Commission (USA).

NOTE: THE GRANTEE IS NOT RESPONSIBLE FOR ANY CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

IC Radiation Exposure Statement for Canada

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.