

1. Photographs of Dynamic Frequency Selection Test Configuration

Test Mode: Mode 1

FRONT VIEW




CLOSE-UP VIEW




Test Mode: Mode 2

FRONT VIEW



CLOSE-UP VIEW



————THE END————