



Call Answer a call Press the Multifunction button once. Reject a call Press and hold the Multifunction button for about 2 seconds. End a call Press the Multifunction button once. End current call and answer new call When a new call rings during a call, press the Multifunction button once to answer new call and end current call simultaneously. On hold current call and answer new call When a new call rings during a call, Press and hold the Multifunction button for about 2 seconds to hold current call and answer new call.	Mute on/off Press the Volume "+/-" for about 2 seconds to mute on/off. Switch between the earphone and phone Press the Volume "+" for about 2 seconds during a call, the call will be switched to the mobile phone, redo this operation again, the call will be switched to the earphone. Redial the last call Double-press the Multifunction button in standby mode. The mobile phone will redial the last call number. Voice dial (need phone support) Press the Volume button "+" and "-" in standby mode, wait for phone prompt and then tell the phone to dial the name of a stored contact.	Music (Need media player support). Music play / pause Press Multifunction button once to play / pause music. (Some phones may require you to start a media player first). Track back/forward Press the Volume "+/-" for 2 seconds once to skip track backward, press Volume "+" for 2 seconds once to skip track forward.	Basic operation Status indicator <table><tr><th>Instruction</th><th>LED status</th><th>Voice prompts</th></tr><tr><td>Power on</td><td>Stay blue about two second</td><td>Power on</td></tr><tr><td>Power off</td><td>Stay red about two second</td><td>Power off</td></tr><tr><td>Standby</td><td>Blink blue twice every 5 seconds</td><td>/</td></tr><tr><td>Pairing</td><td>Flashes red and blue alternately</td><td>Pairing</td></tr><tr><td>Battery low</td><td>Flashes red twice every 8 seconds</td><td>Battery low</td></tr><tr><td>Charging</td><td>Stays on red while charging Stays on blue after fully charged</td><td>/</td></tr></table> Volume up/down Press the volume "+" to turn volume up Press the volume "-" to turn volume down Power on Press and hold Multifunction button for about 2 seconds, the LED flashes blue twice. Power off Press and hold Multifunction button for about 5 seconds, the LED flashes red twice. Tip: When the distance between the earphone and phone is beyond effective range, earphone disconnects with phone. Earphone will power off automatically once no active for 20 minutes.	Instruction	LED status	Voice prompts	Power on	Stay blue about two second	Power on	Power off	Stay red about two second	Power off	Standby	Blink blue twice every 5 seconds	/	Pairing	Flashes red and blue alternately	Pairing	Battery low	Flashes red twice every 8 seconds	Battery low	Charging	Stays on red while charging Stays on blue after fully charged	/	Safety and care Turn on voice prompts: enter pairing mode: Press the volume "+" button for 3 seconds, the blue LED lights flash 3 times; Turn off voice prompts: enter pairing mode: Press the volume "-" button for 3 seconds, the red LED lights flash 3 times. Clear paired list Press and hold the volume "+" button, the multifunction button and press volume "-" button for about 5 seconds in standby mode. (Note: The earphone will enter pairing mode after power on next time.) Hard reset If the earphone cannot be turned on even when fully charged or does not respond during use, follow the instructions below to reset it. 1.While pressing and holding the multifunction button, connect the earphone to your PC's USB port or a USB power adapter with the charging cable. 2.Keep pressing and holding the Multifunction button until the earphone turns on. The earphone is now reset. Using earphone at high to moderate volumes for extended periods of time will result in permanent hearing damage. It is advised you keep volume levels moderate to low at all times for your safety. Do not use while driving a car, cycling, operating machinery, or performing other activities that require hearing surrounding sounds. Do not use earphone in thunderstorm weather, the earphone may not work properly in the condition, and increase the risk of being hit by lightning. Earphone may not work properly under high temperature or high humidity conditions. Do not use any corrosive cleaner/oil to clean the earphone. If the earphone comes in contact with liquids, quickly wipe away. If submersed in water, do not turn the earphone on until completely dried. Tips:liquid submersion voids the warranty. Keep the earphone and packaging out of reach of children.	Bluetooth Sports Headset for calls and music MEE audio X8 INSTRUCTION
Instruction	LED status	Voice prompts																								
Power on	Stay blue about two second	Power on																								
Power off	Stay red about two second	Power off																								
Standby	Blink blue twice every 5 seconds	/																								
Pairing	Flashes red and blue alternately	Pairing																								
Battery low	Flashes red twice every 8 seconds	Battery low																								
Charging	Stays on red while charging Stays on blue after fully charged	/																								

Start here This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.	Product overview 1. Volume + / Track forward 2. Multifunction button 3. LED indicator 4.Talking mic 5. Volume - / Track back 6. Charge jack 	Charging Your new earphone has enough power to pair and make a few calls.It takes 2 hours to fully charge the earphone, while charging, the battery indicator light is red, the indicator light flashes blue once charging is complete. Note: The lifetime of the battery will be significantly reduced if your earphone is left uncharged for a long period. We recommend that you recharge your earphone at least once a month. 	Pairing Pair one phone Note: When the earphone and phone have been paired once, they will automatically connect when the earphone is on and Bluetooth is activated on the phone. 1.Make sure the earphone is turned off and within 1 meter of your phone, press and hold the Multifunction button until the LED indicator flashes red and blue alternately (About 5 seconds), then release Multifunction button. 2.Activate Bluetooth on your phone (See below for more details). iPhone a. On your phone, open the Settings menu. b. Select Bluetooth. If Bluetooth is off, turn it on. The iPhone will search for new devices automatically. Android phone a. On your phone, open the Settings menu. b. Select Bluetooth (For old Android phone: Bluetooth is found in the Wireless & Networks. If Bluetooth is off, turn it on. Select Search for Devices if your phone does not automatically search for new devices. Windows Phone 8 a. On your phone, open the Settings menu. b. Select Bluetooth. If Bluetooth is off, turn it on. The Phone will search for new devices automatically. 	Pair another phone Multipoint technology enables you to pair another phone and take a call from either. To pair with another mobile phone, follow the steps for "Pair one phone". After pairing successfully, restart the earphone to connect to 2 paired mobile phone automatically. 
---	--	---	---	--