



Test Mode: LTE Band 5 / 10MHz / 1RB / QPSK




Lowest channel




Highest channel

Test Mode: LTE Band 5 / 10MHz / 50RB / QPSK




Lowest channel




Highest channel

Test Mode: LTE Band 5 / 1.4MHz / 1RB / 16-QAM




Lowest channel




Highest channel

Test Mode: LTE Band 5 / 1.4MHz / 6RB / 16-QAM




Lowest channel




Highest channel

Test Mode: LTE Band 5 / 3MHz / 1RB / 16-QAM




Lowest channel



Highest channel

Test Mode: LTE Band 5 / 3MHz / 15RB / 16-QAM




Lowest channel




Highest channel

Test Mode: LTE Band 5 / 5MHz / 1RB / 16-QAM




Lowest channel



Highest channel

Test Mode: LTE Band 5 / 5MHz / 25RB / 16-QAM




Lowest channel




Highest channel

ALPHA's reports are using a digital certificate that is trusted on Adobe's official server. If there is no digital certificate or the digital certificate shows damaged in your report. Please do not accept the report.
E-mail: service@alab.cn Tel: 400-8300-895 Website: <http://www.a-lab.cn>

Test Mode: LTE Band 5 / 10MHz / 1RB / 16-QAM




Lowest channel




Highest channel

Test Mode: LTE Band 5 / 10MHz / 50RB / 16-QAM




Lowest channel




Highest channel

Test Mode: LTE Band 7 / 5MHz / 1RB / QPSK




Lowest channel




Highest channel

Test Mode: LTE Band 7 / 5MHz / 25RB / QPSK




Lowest channel




Highest channel

Test Mode: LTE Band 7 / 10MHz / 1RB / QPSK




Lowest channel




Highest channel

Test Mode: LTE Band 7 / 10MHz / 50RB / QPSK




Lowest channel




Highest channel

Test Mode: LTE Band 7 / 15MHz / 1RB / QPSK




Lowest channel



Highest channel

Test Mode: LTE Band 7 / 15MHz / 75RB / QPSK




Lowest channel




Highest channel

Test Mode: LTE Band 7 / 20MHz / 1RB / QPSK



Lowest channel




Highest channel

Test Mode: LTE Band 7 / 20MHz / 100RB / QPSK




Lowest channel




Highest channel

Test Mode: LTE Band 7 / 5MHz / 1RB / 16-QAM




Lowest channel




Highest channel

Test Mode: LTE Band 7 / 5MHz / 25RB / 16-QAM




Lowest channel




Highest channel

Test Mode: LTE Band 7 / 10MHz / 1RB / 16-QAM




Lowest channel




Highest channel

Test Mode: LTE Band 7 / 10MHz / 50RB / 16-QAM




Lowest channel




Highest channel

Test Mode: LTE Band 7 / 15MHz / 1RB / 16-QAM




Lowest channel



Highest channel

Test Mode: LTE Band 7 / 15MHz / 75RB / 16-QAM




Lowest channel




Highest channel

Test Mode: LTE Band 7 / 20MHz / 1RB / 16-QAM




Lowest channel




Highest channel

Test Mode: LTE Band 7 / 20MHz / 100RB / 16-QAM




Lowest channel




Highest channel

Test Mode: LTE Band 12 / 1.4MHz / 1RB / QPSK




Lowest channel




Highest channel

Test Mode: LTE Band 12 / 1.4MHz / 6RB / QPSK




Lowest channel




Highest channel

Test Mode: LTE Band 12 / 3MHz / 1RB / QPSK




Lowest channel




Highest channel

Test Mode: LTE Band 12 / 3MHz / 15RB / QPSK




Lowest channel




Highest channel

Test Mode: LTE Band 12 / 5MHz / 1RB / QPSK




Lowest channel




Highest channel

Test Mode: LTE Band 12 / 5MHz / 25RB / QPSK



Lowest channel



Highest channel

Test Mode: LTE Band 12 / 10MHz / 1 RB / QPSK

ALPHA's reports are using a digital certificate that is trusted on Adobe's official server. If there is no digital certificate or the digital certificate shows damaged in your report. Please do not accept the report.
E-mail: service@alpha-lab.cn Tel: 400-8300-895 Website: <http://www.alpha-lab.cn>