





Test Mode: LTE Band 41 / 5MHz /1RB





Test Mode: LTE Band 41/ 5MHz /25RB



Lowest channel




Middle channel




Highest channel


Test Mode: LTE Band 41 / 10MHz /50RB



Lowest channel




Middle channel




Highest channel

ALPHA's reports is using a digital certificate that is trusted on Adobe's official server. If there is no digital certificate or the digital certificate shows damaged in your report. Please do not accept the report.
E-mail: service@a-lab.cn Tel: 400-8300-895 Website: <http://www.a-lab.cn>



Test Mode: LTE Band 41/ 15MHz /1RB





Test Mode: LTE Band 41 / 15MHz /75RB



Lowest channel




Middle channel




Highest channel



Test Mode: LTE Band 41/ 20MHz /1RB





Test Mode: LTE Band 41 / 20MHz /100RB



Lowest channel





Middle channel





Highest channel

Test Mode: LTE Band 66 / 1.4MHz / 1RB



Test Mode: LTE Band 66 / 1.4MHz / 6RB



Lowest channel




Middle channel




Highest channel

ALPHA's reports is using a digital certificate that is trusted on Adobe's official server. If there is no digital certificate or the digital certificate shows damaged in your report. Please do not accept the report.
E-mail: service@alpha-lab.cn Tel: 400-8300-895 Website: <http://www.alpha-lab.cn>



Test Mode: LTE Band 66 / 3MHz / 1RB





Test Mode: LTE Band 66 / 3MHz / 15RB



Lowest channel




Middle channel




Highest channel



Test Mode: LTE Band 66 / 5MHz / 1RB





Test Mode: LTE Band 66 / 5MHz / 25RB



Lowest channel




Middle channel




Highest channel



Test Mode: LTE Band 66 / 10MHz / 1RB





Test Mode: LTE Band 66 / 10MHz / 50RB



Lowest channel



Middle channel





Highest channel



ALPHA's reports is using a digital certificate that is trusted on Adobe's official server. If there is no digital certificate or the digital certificate shows damaged in your report. Please do not accept the report.
E-mail: service@alpha-lab.cn Tel: 400-8300-895 Website: <http://www.alpha-lab.cn>

Test Mode: LTE Band 66 / 15MHz / 1RB



Test Mode: LTE Band 66 / 15MHz / 75RB



Lowest channel





Middle channel





Highest channel

Test Mode: LTE Band 66 / 20MHz / 1RB



Test Mode: LTE Band 66 / 20MHz / 100RB



Lowest channel



Middle channel



Highest channel