



BV120
Bluetooth Speaker

不見不散®
SEE ME HERE

Preface

Dear user:

Thank you for choosing our Bluetooth speaker. Please view the manual for better operation.

Our bluetooth speaker gets fashionable appearance, excellent voice effect, integrated multifunction, own patent in whole s eries.

The leading audio technology makes you feel wonderful music when you at home, on trip or at business work, providing the excellent voice effect for computer and any other music players.

不見不散®
SEE ME HERE

Catalog

Part1:Start

- Matters need attention
- Product configuration
- Appearance and structure
- Function
- Specification

Part2:Use

- Power
- Bluetooth play
- Charge other devices
- SD card play
- Hands free calling
- USB media play
- Store music
- Charge the speaker
- Selfie snapshot function

9.Part3:FAQ

10.Part4:Warranty Card

Manufactory:
Shenzhen See Me Here Electronic Co.,Ltd.
Address:D Block, TongFuYu Industrial Park, XiXiang Town,
Bao'an District, Shenzhen.
Tel:0755-61181399 Fax:0755-29101982
Website:www.see-me-here.com


All rights reserved by Shenzhen See Me Here Electronic Co.,Ltd.
It's not allowed to copy comment from the manual.
The product specification bases on newest update.

Start

Matters need attention

- Please read this instruction before using.
- Do not disassemble product.
- Do not expose product to high temperature or wet area.
- Please keep product away from fire or water to avoid explosion.
- Do not cover product with papers or other articles to avoid cooling fault.
- Please disconnect the power charging cable when product is in off.
- Do not shock, hit product.
- Please stop using if there is liquid flooding from product.
- Please use the original charge cable and adapter.

Product configuration




1 BV120 Bluetooth speaker

2 USB cable

3 Manual instruction/Warranty card

Appearance



Volume-/Previous:Short press for volume down, long press for previous music.

Reset: Press it with sharp for reset when the speaker crash.

Volume+/Next: Short press for volume up(15 levels), default on 12 level when power on; Long press for next music.

Snapshot: Short press for photo snapshot when bluetooth connected.

Power: Long press 2 seconds for power on or off.

Pause: Short press for pause or play when run in SD card mode; for sound off mode when run in line in mode.


Mode: Double-click for changing mode, the sequence is : Bluetooth > SD card > Line in mode.

Charge: Short press for power bank mode, charge for other devices, display the power capacity for 5 seconds and output power is 5V 1A.Exit power bank mode if no charging 30 seconds

Microphone: Built-in microphone for hands free calling.

Bluetooth: Long press for disconnection, short press to reconnect.

Call: Hands free calling, short press to answer or hang up the call, long press to refuse the call.



LED power capacity/Charging power capacity

Mode LED Light

Plastic Material, Metal mesh, Bass intensifier.

Functions

- Support bluetooth play and bidirectional conversation.
- One key to reconnect bluetooth
- Support SD card play in APE/FLAC format.
- Support exchange data via SD card.
- USB media play mode.
- Shut down automatically if pause or no working 10 minutes.
- Bluetooth snapshot.
- Run in Ultra Power Saving Mode after sound off 15 seconds.
- Play above 15 hours with super battery.
- Always keep Bluetooth connection
- Built-in 4400mAh battery for power bank function

Specification

Appearance specification	
Name	Bluetooth speaker
Model	BV120
Net weight	245g
Dimension	63*36*126mm
Basic	
Vocal tract	Single
Bluetooth version	Bluetooth 4.0
Wireless distance	10m Max
Power capacity	4400mAh
Store type	SD Card
Technical	
Frequency response	100Hz~18KHz
Rated power	3W THD≤10%
USB	USB2.0
Input	5V>1A
Output	5V≈1A
Max store capacity	32GB Max
Charge time	1000mA≈4hr~5hr
Play time	12hr~24hr
Playing Function	
Format	APE, MP3, WMA, WAV, FLAC

FCC Notice

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

USE

Long press 2s for power on/off

Connect with other bluetooth devices

1 After power on, turn on bluetooth function on mobile, tablet or computer, search device "BV120", click to connect.

2 You will hear voice "Ding-dong" when connected, play music now. Type in "0000" if it needs password. The speaker will automatic reconnect the last pairing device before shut down.

3 Long press to disconnect bluetooth, the LED light is flashing, other device can search BV120 again.

4 Short press the bluetooth key to reconnect the last device.

Charge other devices

1 Connect the speaker with your mobile or tablet via USB cable.

2 Press , LED light will show the power capacity for 5s, then start charging.

3 Disconnect the speaker with your device, BV120 will shut down automatically after 30s.

Power display

	100%Power	
White light		White light
	75%Power	
White light		White light Flashing light
	50%Power	
White light		White light Flashing light
	Low power needs charging, volume will get lower automatically.	
White light		White light Flashing light
	The speaker can not work in 10% low power	
Flashing white light		Flash in order base on the power status

Power on: white LED light quick flash, waiting Bluetooth connection, the white light stays means the Bluetooth connected.
Pause under BT mode: the white LED light slow flash
Micro SD card play: the white LED light stays
Micro SD card pause: the white LED light flash
Line in play: the white LED light stays
Line in pause: the white LED light flash
Max volume: the white LED light quick flash

! Note: when the power is very low, power on and the white LED will be quick flash. The speaker will be turned off automatically in 15S.

Micro SD card (TF card) mode

1 Insert SD card when power on
In powered status, insert the SD card, the speaker will switch to SD card mode automatically and play music.

2 Switch to SD card mode
In powered off status, insert SD card, then power on the speaker, after "dingdong", it enters Bluetooth mode firstly, double click the mode key , with prompt "SD card mode" then it can play the stored music.

Warm Tip: We set Bluetooth mode as the first mode, it needs to switch (double click) to SD card mode.

Hands free

1 When speaker connected with mobile
The music play will be paused when a call comes in, short press to answer or end the call, long press to reject the call

USB media play

1 USB media play
Connect the speaker with laptop, PC via USB cable, then double click to enter the USB media play, then play music on your computer. Double click to shift to other mode.

2 Copy music
When power off, connect the speaker with laptop, PC via USB cable; short press with the prompt of "card reader mode", then you can copy the music to the SD card.

3 Charging
Either power on or off, it can be charged as blow ways
1: Use the adapter on or above DC5V=1A
2: Use the USB ports on laptop, PC

PS: Please charge before using if unused for a long time.

Selfie snapshot function

1 In IOS system, connect with BV120, turn on the camera then press to snapshot.
2 In Android system, please download and install app "Camera360" from Google Play. Connect BV120 with your device, turn on "Camera360", press to snapshot.

FAQ

Problem	Solution
Fail to connect	1. Turn off then restart the speaker 2. Type in "0000" if it needs password.
Staccato (not play fluently)	Check the connected distance or if there is barrier in the connected range.
SD card error	1. Check the SD card format (should be FAT32) 2. The stored file format should be WAV/MP3
No voice	1. Check the volume 2. Check the speaker if it is in silent mode or pause status.
No voice when in USB media play mode	Check the USB cable if it connects correctly or not.
Can not power on	Click the reset key to try power on.
No reaction	Click the reset key

Warranty Card

Please fill up the "Warranty card" and keep it well after purchasing the product

Model: _____

Purchase date: _____

Name: _____

Address: _____

Telephone: _____ Zip code: _____

Dealer: _____

Address: _____

Principal: _____

Telephone: _____ Zip code: _____

Authorized stamp: _____

5

6

7

8

9