

SKY[®]

DEVICES



SKY *F3P+*

User Manual
Manual del Usuario

User Manual

1. **Messaging**

You can receive and send message, and can also use broadcast message.

Message make it possible for you to exchange message With other wireless phone users. Select Message to perform operation.

1.1 **Writing Message**

You can write a new text message send to others, and also can insert template in the message.

Select the Option after editing a text message:

Send:	send the message only
Save and Send:	send the message while sending
Save:	save the message
Send to Many:	send the message to many
Send By Group:	send the message to all the link of the selected group

1.2 Message Setting

You can setup your MMS through the menu by your need as following:

- Server Profile:** Start or edit the service, when you fail to send the MMS, please change online-pattern of the server to WAP.
- Send:** Include life, send return, read return, priority etc.
- Retrieve:** Include main network, roaming network, Send return, allow to sending reports etc.
- Memory Status:** View the storage of the MMS.
- Note:** If you fail to send MMS, please change the online-pattern to WAP in the server setting.

1.3 SMS Setting

You can setup the message from the menu, as following:

- SIM Setting:** Offer you four profiles and you can edit their names, set SC Address and Valid Period etc.
- Common Setting:** Set delivery report on or off
- Memory Status:** Check the capacity of message storage
- Preferred Storage:** Set the default message storage location, including phone storage and SIM card.
- Note:** you need support from the service provider to receiver delivery reports.

2. Call history

Enter the main menu Log, select SIM1 or SIM2 to view the dialed calls and answered calls, can also examine the call time, cost and the use of the message.

2.1 SIM 1/2Call history

You phone keeps lists of incoming and outgoing calls, even for calls that didn't connect .The most recent calls are listed first.

Tip: the phone keeps the only latest call of the same number .To view detail information or performs other operation:

Find the lists of Dialed Calls, Received Calls, Missed Calls .Press ok key to view the detail information: times etc.

Press Option key to perform following operation:

Delete: Delete this record.

Save: Save the number of this record to phone book.

Call: Call the number of this record.

Send SMS: Send message to the number of the item.

Edit : Enter the number edit screen, you can modify, save or dial the number.

3. Phonebook

Select contacts to open phone book.

The phone book is consisting of phone storage and SIM card storage and you can use both of them.

Phone Storage: With a name, default number, family number, company name, email address, company number, fax number, birthday date and group/individual ting in each item

SIM card Storage: The capacity depends your SIM card type and there is only a name and one business number in each item .For details, please contact your service provider.

Note: Delete the selected names one by one

3.1 Setting

You can perform bellowing operations on the phonebook:

Memory Status: Check the capacity of the phonebook, Including SIM card memory and phone memory.

Preferred Storage: Select SIM card memory or phone Memory as the default storage location when adding a new name.

Tip: You can also choose another storage location when you add a new name.

4. Setting

You can set your favorite wallpaper, ring or some other function.

4.1 SIM Setting

Enter this menu; you can set the mode to be Dual SIM, only SIM1, only SIM2, flight mode.

4.2 Network Setup

When dual SIM mode is activated, you can perform network setup for SIM1 and SIM2 separately. Enter Network Settings, select Network Setup and then you can perform following operations:

- | | |
|------------------------|---|
| Network: | New search, Select Network |
| Selection: | Selection Mode. |
| Preferences: | Set the preferred network during searching. |
| Band selection: | Set the way how GPRS is connected. |

4.3 Security Setup

Enter Security Settings, select Security Setup and then you can perform following operation:

- | | |
|-------------------------|---|
| SIM Lock: | Set a password for your SIM card-open/close. |
| Phone Lock: | Set a password for phone lock. |
| Keypad Lock: | auto keypad lock on or off and a time after which the keypad is Locked. |
| Change Password: | Change the Pin Password, Pin2 Password and Phone Lock Password. |

Note: For Pin Password, please contact your service provider; Fixed Dial and Barred Dial must be supported by your SIM card .For details, please contact your service provider.

4.4 Call Setting

Enter call Setting form main menu, select Call Setup and then you can perform some operations as following:

Call Waiting: Setup the call waiting function.

Call Divert: Setup the call diverts function.

Call Limit: Setup the call limit function.

Line Switch: Switch your current line and there are 2lines Available.

Call time

Reminder: Set the call time reminder on or off and its type and period.

Call time

Display: Set if call time shows during calls or not.

Auto Redial: Set Auto Dial on or off. While it is on, the phone automatically redials 10 times in occasion that the line is busy or cannot be answered and you can press Abort to cancel redialing.

Backlist: Set 5 numbers, while it is on, the phone automatically shields the incoming calls from the members in blacklist.

IP Dial: Set IP dial on or off, edit IP number.

5. Multimedia

Your phone offers multimedia applications and you can select Media from main menu to open it.

5.1 Camera

Your phone has a hi-Mega pixel camera that you can take photos whenever and wherever you like. After taking photos, store them in the phone memory or memory card (if any).

Camera Setting: Press left soft key to open Option in viewfinder display and make detail setting.

5.2 Audio player

You can enjoy the music with this function. You can use the following keys during the play. Use “#” key for volume up and “*” key for volume down.

Key	Function
Left Soft key	List menu
Right Soft key	Press to Back
Play / Pause key	Play or Pause music
Previous key	Previous music
Next key	Next music
Stop key	Stop music

All the songs files must be copied on the folder "My Music" and then need to update Play List else the cellphone won't recognize any file and will show the music player always empty.

5.3 Video Player

You can play the video with this function. Select a video and begin to play. You can use the following keys during the play. Use "# "key for volume up and "*" key for volume down.

Key	Function
Left Soft key	Press to go to Options
Right soft key	Press to stop the video and go back

5.4 Image viewer

You can perform the following operations

- View:** View photos
- Forward:** Send the current photo to wallpaper list, screen saver list and power on/off display list
- Rename:** Change name of the photo
- Delete:** Delete the photo
- Delete All:** Delete all photos
- Files Sort:** Arrange the photos by name, type, time,. size or random
- Storage:** Choose photos in the phone memory or

memory card.

5.5 FM radio

Choose Radio menu to turn the radio function..Use “#” key for volume up and “*” key for volume down.

Note: While tuning the radio in, you can dial or hear the call normally. When on the phone, the volume of the radio will become silence automatically

6. File manager

Tap from the main menu to open it and you can find the storage devices and the capacity of total space and free space. On different objects, there are different operations.

7. Organizer

7.1 Calendar

7.2 Alarm

7.3 Flashlight

7.4 Tasks

7.5 Bluetooth®

7.6 Calculator

Manual del Usuario

1. Mensajería

Puede recibir y enviar mensajes e inclusive utilizar mensajes de difusión.

La función mensajería le permite intercambiar mensajes con otros usuarios de teléfonos inalámbricos. Seleccione Mensajería para realizar la operación.

1.1 Redactar un mensaje

Puede redactar un mensaje nuevo y enviarlo, como también se pueden insertar plantillas a los mensajes.

Seleccione una de las siguientes opciones después de editar un mensaje de texto:

Enviar:	solo enviar el mensaje
Guardar y enviar:	guardar el mensaje al enviar
Guardar:	guardar el mensaje
Enviar a varios:	enviar el mensaje a varios destinatarios
Enviar por grupo:	enviar el mensaje a todo el grupo seleccionado

1.2 Configuración del mensaje

A través del menú puede configurar los MMS de acuerdo a sus necesidades, como sigue:

Perfil del servidor:	Iniciar o editar el servicio, cuando no se puede enviar un MMS, cambie el servidor WAP a la modalidad en línea.
Enviar:	Incluye enviar, reenviar, volver a leer, prioridad, etc.

Recuperar: Incluir red principal, red roaming, reenviar, permitir enviar informes, etc.

Estado de la memoria: Ver el almacenamiento de los MMS.

Nota: Si no puede enviar un MMS, cambie el modo de configuración del servidor WAP en línea.

1.3 Configuración de SMS

Puede configurar el mensaje desde el menú, como sigue:

Configuración de SIM: Le ofrece cuatro perfiles y puede editar sus nombres, establecer la dirección SC, periodo válido, etc.

Configuraciones comunes: Configure envío de informe, activar o desactivar.

Estado de la memoria: Verificar la capacidad de almacenamiento de mensajes.

Almacenamiento preferido: Establecer la ubicación de almacenamiento de los mensajes por defecto, incluyendo el almacenamiento del teléfono y de la tarjeta SIM.

Nota: Se requiere el soporte del proveedor de servicio para recibir informes de entregas.

2. Historial de llamadas

Ingresa al menú principal del registro de llamadas, seleccione SIM1 o SIM2 para visualizar los números marcados y las llamadas recibidas, también puede revisar la hora de la llamada, el costo y el uso

del mensaje.

2.1 Historial de llamadas de tarjeta SIM1 y SIM2

El teléfono mantiene una lista de llamadas entrantes y salientes, inclusive de aquellas que no lograron conectarse. Primero aparecen las llamadas más recientes.

Consejo: El teléfono solo guarda la última llamada del mismo número. Para visualizar información detallada o realizar otra operación:

Busque las listas de llamadas realizadas, llamadas recibidas, llamadas perdidas. Pulse la tecla OK para visualizar la información detallada como horas, etc. Pulse la tecla Opción para realizar las siguientes operaciones:

Eliminar: Eliminar el registro.

Guardar: Guardar el número de este registro en el directorio telefónico.

Llamar: Llamar a un número del registro.

Enviar SMS: Enviar un mensaje al número de la lista.

Editar: Ingresar a la pantalla editar número, donde puede modificar, guardar o marcar el número.

3. Directorio telefónico

Seleccione los contactos para abrir el directorio telefónico.

El directorio telefónico consiste en la memoria del teléfono y de la tarjeta SIM y se pueden usar ambas memorias.

Memoria del teléfono: El uso de un nombre, número predeterminado,

número de familia, nombre de empresa, dirección de correo electrónico, número de fax, fecha de cumpleaños y tono para cada ítem individual o grupal.

Memoria tarjeta SIM: La capacidad de memoria depende del tipo de tarjeta SIM y solo hay un nombre y número de empresa para cada ítem. Para mayor información, contacte a su proveedor de servicio.

Nota: Eliminar los nombres seleccionados uno por uno.

3.1 Configuración

Puede realizar las siguientes operaciones en el directorio telefónico:

Estado de la memoria: Compruebe la capacidad del directorio telefónico, incluyendo la memoria de la tarjeta SIM y del teléfono.

Almacenamiento preferido: Cuando se añade un nuevo nombre seleccione la memoria de la tarjeta SIM o la memoria del teléfono como ubicación de almacenamiento predeterminado.

Consejo: También puede seleccionar otra ubicación de almacenamiento cuando añade un nuevo nombre.

4. Configuración

Puede configurar su fondo de pantalla, tono preferido o alguna

otra función.

4.1 Configuración de la tarjeta SIM

Ingrese a este menú, donde puede configurar el modo SIM Dual, solo SIM1, solo SIM2, modo avión.

4.2 Configuración de red

Cuando se activa el modo SIM dual, puede realizar la configuración de red para la tarjeta SIM1 y tarjeta SIM2 por separado. Ingrese a la Configuración de Red, seleccione Configuración de Red y luego se pueden realizar las siguientes operaciones:

- Red:** Nueva búsqueda, seleccionar red
- Selección:** Modo selección.
- Preferencias:** Configure la red de su preferencia durante la búsqueda.
- Selección de banda:** Configure la manera como se conecta GPRS.

4.3 Configuración de seguridad

Ingrese a Configuración de Seguridad, seleccione Configuración de Seguridad y luego se pueden realizar las siguientes operaciones:

- Bloqueo de SIM:** Establecer una contraseña para abrir/cerrar la tarjeta SIM.
- Bloqueo del teléfono:** Establecer una contraseña para bloquear el teléfono.
- Bloqueo del teclado:** Auto bloqueo del teclado activado o desactivado después de un periodo de tiempo.
- Cambio de contraseña:** Cambio de contraseña Pin, contraseña Pin2 y contraseña de Bloqueo del teléfono.

Nota: Para la contraseña Pin, contacte a su proveedor de servicio. La marcación fija y la marcación restringida debe ser compatible con su tarjeta SIM. Para mayores detalles contáctese con su proveedor de servicios.

4.4 Configuración de llamada

Ingrese a la configuración de llamada desde el menú principal, seleccione Configuración de Llamada y luego se puede realizar las siguientes operaciones:

Llamada en espera: Configurar la función llamada en espera.

Desvío de llamadas: Configurar la función desvío de llamadas.

Límite de llamada: Configurar la función límite de llamadas.

Cambio de línea: Cambiar la línea actual, si tiene dos líneas disponibles.

Recordatorio tiempo de llamada: Configurar el recordatorio de tiempo de llamada on/off, tipo, y lapso de tiempo.

Pantalla tiempo de llamada: Configurar si se muestra el tiempo de llamada durante las llamadas o no.

Auto Marcado: Configurar el Auto marcado on/off. Mientras esté activado el teléfono automáticamente remarcará el número hasta 10 veces si la línea está ocupada o si la persona no responde. Si desea interrumpir el remarcado puede presionar Cancelar.

Lista negra: Configure 5 números en la lista negra, mientras la función esté activada, el teléfono automáticamente bloqueará las llamadas

entrantes de las personas de la lista negra.

Marcación IP: Configurar marcación IP on/off, editar número IP.

5. Multimedia

El teléfono le ofrece aplicaciones multimedia y para abrirlas puede seleccionar Media desde el menú principal.

5.1 Cámara

El teléfono cuenta con una cámara megapíxeles superior que le permite captar imágenes cuándo y dónde lo desee. Después de tomar las fotos guárdelas en la memoria del teléfono o en la tarjeta memoria (si la hubiera).

Configurar la Cámara: Pulse la tecla izquierda para abrir Opción en la pantalla del visor y hacer los ajustes de detalles.

5.2 Reproductor de Audio

Puedes disfrutar de la música con esta función. Puede usar las siguientes teclas durante la reproducción. Usar la Tecla “#” para subir el volumen y la tecla “*” para bajar el volumen.

Tecla	Función
Tecla de función izquierda	Menú de lista
Tecla de función derecha	Presione para retroceder
Tecla de reproducción / pausa	Reproducir o pausar música
Tecla anterior	Canción anterior
Tecla siguiente	Canción siguiente
Tecla detener	Detiene la canción

Los archivos de canciones (música) deben de copiarse en la carpeta "My Music" y luego en la opción del reproductor, seleccionar la opción para actualizar la lista de reproducción, de lo contrario si los archivos no se copian en esa carpeta especificada, no se encontrará ningún archivo de música y el reproductor se mostrará vacío.

5.3 Reproductor de Vídeo

Puedes reproducir el video con esta función. Selecciona un video y comienza a reproducir. Puede usar las siguientes teclas durante la reproducción. Usar la Tecla "#" para subir el volumen y la tecla "*" para bajar el volumen.

Tecla	Función
Tecla de función izquierda	Presione para ir a Opciones.
Tecla de función derecha	Presione para detener el video y regresar

5.4 Visor de imágenes

Puede realizar las siguientes operaciones:

- Vista:** Visualizar las imágenes
- Reenviar:** Enviar la imagen actual a la lista de fondos de pantalla, de protector de pantalla y a la lista de pantalla on/off
- Renombrar:** Cambiar el nombre de la imagen
- Borrar:** Borrar la imagen
- Borrar todos:** Borrar todas las imágenes
- Ordenar archivos:** Organizar las imágenes por nombre, tipo, hora, tamaño o al azar.

Memoria: Seleccione imágenes en la tarjeta memoria del teléfono o de la tarjeta memoria.

5.5 Radio FM

Seleccione el menú Radio para encender la función radio. Usar la Tecla “#” para subir el volumen y la tecla “*” para bajar el volumen.

Nota: Mientras sintoniza la radio, puede marcar o recibir llamadas de manera normal y el volumen del teléfono se pondrá en silencio automáticamente.

6. Administrador de archivos

Pulse en el menú principal para abrir y encontrar los dispositivos de almacenamiento, la capacidad de espacio total y el espacio disponible. En diferentes objetos hay operaciones distintas.

7. Organizador

7.1 Calendario

7.2 Alarma

7.3 Linterna

7.4 Tareas

7.5 Bluetooth®

7.6 Calculadora



Designed in the USA

Manufactured in China to SKY Devices Specifications

FCC Statement

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

SAR Information Statement

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radiofrequency (RF) energy set by the Federal Communications Commission of the U.S. Government. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health. The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg. * Tests for SAR are conducted with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output. Before a phone model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government adopted requirement for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) as required by the FCC for each model. The highest SAR value for this model phone when tested for use at the ear is **0.706W/Kg** and when worn on the body, as described in this user guide, is **1.292W/Kg**(Body-worn measurements differ among phone models, depending upon available accessories and FCC requirements). While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirement for safe exposure. The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RFexposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of <http://www.fcc.gov/oet/fccid> after searching on FCC ID: **2ABOSSKYF3PPBI** Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications Industry Association (CTIA) web-site at <http://www.wow-com.com>. * In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.

Body-worn Operation

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of **10mm** must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.