


Slope ON / OFF




How to Set-up Time

- Automatic setting (only available outdoors)
- Touch the Set-up menu on the menu screen.



How to Use Smart Green View

- Automatically set the direction of approach based on the location of the player



How to Set-up Time

- Manual Setting (available both indoor/outdoor)
- Touch the Set-up menu on the menu screen.




How to Reset



How to Set-up Time

- Manual Setting (available both indoor/outdoor)
- Touch the Set-up menu on the menu screen.



Notes

- The time required to capture GPS satellite signals while in golf mode may vary depending on the environment (weather, topography).
- The battery's usage time may be reduced during rounds in cold weather and in areas where satellite reception is poor. It is recommended to turn power on once outside and ready to begin your round to increase product usage time.
- Do not leave the product in vehicles in hot temperatures or humid places as damage may occur.

How to Use Pin Reload

- Touch the screen at the desired pin position to change pin position.



Warranty Conditions

One Year Limited Warranty

Voice Caddie warrants this hardware product against defects in materials and workmanship for a period of one year from the date of original purchase. If a defect exists, at its option Voice Caddie will (1) repair the product at no charge, (2) exchange the product with a product that is new or like-new and is at least functionally equivalent to the original product, or (3) refund the purchase price of the product. Voice Caddie shall have no obligation to repair, replace or refund until the customer returns the defective product to Voice Caddie. This warranty does not apply: (1) to damage caused by accident, abuse, misuse, misapplication, or non-Voice Caddie products; (2) to damage caused by service performed by anyone who is not a Voice Caddie Authorized Service Provider; or (3) to a product or part that has been modified without the written permission of Voice Caddie. For more information on Voice Caddie's warranty and return policy, please visit www.Voicecaddie.com

Key Button Functions

- Power On/Off : Press and hold the power button for more than three seconds.



Caution

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

How to Use the Golf Mode

- Swipe left on the screen to enter the menu screen, then touch the 'Golf Mode' icon



Caution

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.
- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: 1) This device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.
- Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.
- The device has been evaluated to meet general RF exposure requirement.
- The device can be used in portable exposure condition without restriction

Golf Course and Hole Recognition

- Automatic Hole Recognition once GPS signal is captured when touching the 'Golf Mode' icon



Warranty Conditions

Product	Hybrid Golf Watch G1		
Model	G1		
Serial Number			
Date of Purchase		Full Name	
Purchase's Address		Telephone	
Warranty Period	One year after the date of purchase (other components is 6 months)		
Battery life	Regular Watch Mode : 9-10 days Golf Mode: 10 hours		

Responsible Party - U.S. Contact Information
Street Address : 13951 Valley View Ave.
City, State : La Mirada, CA
Postal Code : 90638
United States : United States
Telephone number : 562-926-3978
Internet contact information : swoo@voicecaddie.com

voice caddie

How to use Green Undulation

- Swipe left while in Distance Guide View to enter the Green Undulation view



G1

Golf Mode Quick Start Guide

The Quick Start Guide can be found on the Voice Caddie's website : www.voicecaddie.com

How to connect G1 App and Bluetooth

- With the Voice Caddie G1 app, you can download course information and view messages or missed calls.

