



QUICK START GUIDE

Congratulations,

You are the happy owner of the VEA Buddy smartwatch.

Buddy is the faithful companion to your smartphone (Android, iPhone and Windows).

It vibrates and displays notifications that you have set up. It can control remotely your smartphone without taking it out of your pocket. It will also give some fitness information through its sensors.

You are now free and always connected.


This quick start guide contains basic information to familiarise yourself with your Buddy.

The detailed manual is available on our website:

<http://www.veabuddy.fr/manuel>



LET'S GET ACQUAINTED



CHARGING THE BATTERY

Your Buddy features a USB connector at the end of the band. The battery charger is always with you.

Plug in your Buddy to the supplied USB-to-mains cable or to any USB connector on your laptop or PC. A cable extension is also provided to allow you to charge your Buddy while wearing it.

If you charge the battery while your smartwatch is switched off, an animated icon will be displayed. The animation stops when the battery is full.

If your Buddy is already switched on, you can control that the battery is charging by pulling down the Settings page from the main (favorites) page.

SWITCHING ON YOUR BUDDY

Press the button for 2 seconds. The VEA logo is displayed and your buddy is ready to be connected.

SMARTPHONE APP

Please download the Buddy app from the required store, depending on your smartphone operating system.

PAIRING YOUR BUDDY



SMARTPHONE MODE

Bluetooth pairing is initiated by the Buddy app in your smartphone.

1. Switch on the buddy.
2. Tap on Connect in the Buddy app.
3. Follow the instructions

To check that your smartwatch is properly paired, pull down the Settings page. The Bluetooth signal strength is indicated at the top, in green if the signal strength is good, in red if it is weak.

If the pairing failed the following icon will be displayed instead





SOLO MODE

In this mode your buddy will directly manage the Bluetooth connection.

1. Switch on the Bluetooth device you want to pair to your Buddy
2. Pull down the Settings page
3. Tap on Settings



4. Tap on Bluetooth
5. Tap on the magnifying glass icon

6. Your Buddy starts looking for your device
7. Tap on the required device in the list
8. Follow the instructions
9. Once paired, the Buddy will automatically connect to the device

THE VARIOUS PAGES OF YOUR BUDDY

SMARTPHONE MODE

Your Buddy main page displays four favorites icons and the current time.

To access more pages, slide your finger to the right or to the left.

You can also use the button to access the next pages. Pressing twice on the button displays the Favourite page again.

To access the Settings page, slide down your finger.



CONFIGURING THE FAVORITES ON THE MAIN PAGE

From the main (Favorite) page, pull down the Settings page. Select from the list the four functions you will use the most.

The corresponding icons are now displayed in the main page of your Buddy. You can of course change these functions as often as you wish.

TEXT MESSAGES AND CALLS

Display the Phone & Text page by sliding your finger to the left or to the right. The number of unread calls and messages is indicated in the bottom left corner.



Tap the page to display a list of text messages and calls. Tap on any call or message for more information.

You can when you receive a call :

- Accept the call
- Reject the call
- Call back when you wish

AGENDA

Your Buddy reads the events in your smartphone agenda.

GPS

Buddy reads the itinerary requested from your smartphone and guides you.

MUSIC

Your buddy controls remotely the music in your smartphone. Music settings are available by pulling down the Music settings page.

Your music is played in the background until you stop it.

PEDOMETER

The pedometer settings are displayed by pulling up the page. There you can indicate your weight, height and age.

You can set up your goals by pulling down the page:

- Duration
- Number of steps
- Calories to burn
- Distance

The pedometer will say active in the background until you reach your goal. A notification will be displayed when you do and will let you chose to add a new goal or to stop the pedometer.

SOCIAL NETWORKS

Your buddy will request the authorisation to read your Facebook or Twitter messages. The number of unread

messages is displayed. To read a message, tap on it.

GALLERY

Your buddy can read the pictures from your smartphone.

CAMERA REMOTE CONTROL

Buddy can remotely control your smart-watch camera.

SOLO MODE

When the Buddy is not paired with your smartphone it operates in Solo mode.

You can also activate the Solo mode by pulling down the Settings page from

the Main page and tapping the Buddy logo.

In solo mode, the following features are available in your main page:

- Pedometer
- Music
- Pictures
- Alarm

The pedometer and alarm features work in exactly the same way as when in smartphone mode.

To use the music feature, you need to first transfer your tunes into the Buddy 8 GB integrated memory. Your smart-watch acts like a USB key.

Pictures need also to be transferred to your smartwatch in the same way as your music.

Thank you for reading this quick start guide.

The full manual can be downloaded from our website:

www.veabuddy.fr

FCC Information and Copyright

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates,

uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference

to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does

cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is

encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC RF warning statement: the device has been evaluated to meet general RF exposure requirement , The device can be used in portable exposure condition without restriction.