



Project : i.Tech MusicBand 3300 / User manual
Drawing : Artwork drawing / Scale 1:1
From : Design Team / Jessie / To : All / Date : 20180119v1
Copyright by i.Tech Dynamic Limited. All Rights Reserved.

MusicBand 3300, B3300

Front

MusicBand 3300

i.Tech Bluetooth Headphones

www.itechdynamic.com

Quick Start Guide

1

2

3

4

EN

1. About your MusicBand 3300

2. Charging Your Headset

3. Pairing Your Headset with a Bluetooth Device

4. Basic Operation

5. Safety Information

Care and Maintenance

Version 1.0

All features, functionality and other product specifications, as well as the information contained in this guide, are based upon the latest available information and believed to be accurate at the time of printing. i.Tech reserves the right to change or modify any information or specifications without notice or obligation. The latest version of this guide can be obtained from www.itechdynamic.com. The images in this guide are for reference only.

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by i.Tech Dynamic Global Distribution Ltd. is under license. Other trademarks and trade names are those of their respective owners.

The i.Tech® word mark and logos are registered trademarks owned by the i.Tech Dynamic Global Distribution Ltd. is under license. Other trademarks and trade names are those of their respective owners.

Type : B3300

「經型式認證合格之低功率射頻電機，非經許可，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。」

「低功率射頻電機之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。前項合法通信，指依電信法規定作業之無線電通信。低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。」

EN

3. Pairing Your Headset with a Bluetooth Device

1) Ensure the headset is off.

2) To activate the pairing mode, press and hold the headset's MFB for 8 seconds without releasing your finger until its status indicator flashes blue and red alternately.

3) Activate your mobile phone's Bluetooth, search Bluetooth devices, select "MusicBand 3300" and enter the pass code "0000". When the pairing is completed, the headset's status indicator will show blue light for 2 seconds with "Your phone is connected" voice prompt if the voice prompt language has been configured with English.

4. Basic Operation

Function	Button	Alert Tone / Voice Prompt	Status Indicator
Power on	Press & hold the MFB for 2.5 seconds	"Power on"	Flashing blue light for 3 times
When you turn on your headset for the first time, the headset proceeds into pairing mode, i.e. the status indicator flashes blue and red alternately, you can immediately pair it with your mobile phone.			
Power off	Press & hold the MFB for 2.5 seconds	"Power off"	Red light for 2 seconds
Answer / End a call	Press the MFB once	Short beep	--
Last number redial	Double press the MFB	Short beep	--
Volume up	Short press Volume up button	--	--

Function	Button	Alert Tone / Voice Prompt	Status Indicator
Volume down	Short press Volume down button	--	--
Music track forward	Long press Volume up button	--	--
Music track backward	Long press Volume down button	--	--
Configure voice prompt language	Press & hold 1 second MFB, Volume up & down buttons together standby mode	Short beep	Flashing red & blue 3 times

Multi-point allows simultaneous pairing of the headset with 2 mobile phones, to pair 2 mobile phones:

1. pair your headset with the 1st mobile phone as normal and then switch off.

2. repeat the pairing procedures for the 2nd mobile phone

3. re-connect the 1st mobile phone with the headset via the phone menu

Safety Information

• Check and observe local laws regarding the use of a mobile phone and a headset while driving. If you use the headset while driving, ensure your full attention and focus. It is your responsibility to drive safely. Consider to pull off the road before making or answering a call.

• Never leave your headset above any air bag deployment area inside your car as serious injury may result when an air bag deploys.

• Never allow children to play with the headset - Small parts may be of choking hazard.

• Observe all signs and displays that require an electrical device or RF radio product to be switched off in designated areas. These could include hospitals, blasting areas, and potentially explosive atmospheres.

• Turn off your headset prior to boarding an aircraft. Do not use your headset inside an aircraft.

• To prevent damage to your hearing, please do not set the listening volume too high.

Care and Maintenance

Headset

• Turn off your headset before placing it in your pocket or bag. If the MFB is accidentally depressed, your mobile phone may place an unintended call.

• Do not keep to subject your headset in liquid or try to wash in any circumstance more than 5 minutes.

• Do not use abrasive cleaners to clean the headset.

• Do not expose the headset to extremely high or low temperatures.

• Avoid charging the headset in extremely high or low temperatures.

• Dispose of the battery and the headset according to local regulations. Do not dispose of them as household waste.

Built-in Battery

• Do not stick anything inside the headset, as this may damage internal components.

• Do not attempt to disassemble the headset as it does not contain serviceable components.

• If you do not plan to use the headset for a long period, please store it in a dry place that is free from extreme temperatures and dust.

• Dispose of the battery and the headset according to local regulations. Do not dispose of them as household waste.

EN Charger • Use only the USB cable supplied by the headset's original manufacturer to charge the headset. Other USB cables may look similar but using them could be dangerous and could damage the headset. • Do not attempt to disassemble the charger as it may expose you to dangerous voltages or other risks. Incorrect reassembly can cause electric shock when the headset is subsequently used. • Do not use the charger outdoors or in damp areas. Excessive sound pressure from earphones and headphones can cause hearing loss.	Notes on Environmental Protection After the implementation of the European Directive 2012/19/EU in the national legal system, the following applies: Electrical and electronic devices must not be disposed of with domestic waste. Consumers are obliged by law to return electrical and electronic devices at one of their service points or at the public collection points that are set up for this purpose or designated points of sale. However, such details are defined by the national law of the respective country. This symbol on the product, the instruction manual or the packaging indicates that the product is subject to these regulations. By recycling, reusing the materials, or other forms of utilizing old devices, you are making an important contribution in protecting our environment.	Troubleshooting Q: I can't hear anything in my headset. A: • Ensure the headset is turned on and is properly charged. • Ensure the headset is properly paired with the mobile phone. • Make sure that the mobile phone is connected with the headset - if it does not connect, either refer to the mobile phone's Bluetooth menu or by pressing the MFB once (see "Basic Operation" and "Pairing Your Headset with a Bluetooth Mobile Device"). Q: I can't connect my headset with my mobile phone. A: • Ensure your headset is turned off and is properly charged. • Ensure the headset is properly paired with your mobile phone. • Ensure the headset is within ten meters range of your mobile phone and there are no obstructions, such as walls or other electronic devices in between.	If the above steps do not solve your problem, please recharge the headset and remove your mobile phone's battery for a while. i.Tech Dynamic Global Distribution Limited All rights in this publication are reserved and no part may be reproduced without the prior written permission of the publisher. The contents of this publication are believed to be correct at the time of going to press, but any information, specifications, products or services mentioned, and product I.D. shown may be modified, supplemented or withdrawn without further notice. The Stylized i.Tech logos are trademarks owned by i.Tech Dynamic Global Distribution Limited or its affiliates. All other trademarks or registered trademarks belong to their respective owners. Bluetooth® and the Bluetooth logos are trademarks owned by Bluetooth SIG, Inc. USA and licensed to i.Tech Dynamic Global Distribution Limited. i.Tech declares under our sole responsibility that the headset is in conformity with the provisions of the following Council Directives: 2014/53/EU	FCC RF Radiation Exposure Statement This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must be co-located or operating in conjunction with any other antenna or transmitter. Federal Communications Commission (FCC) Statement This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. 15.21 You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.	Exposure Statement 15.105(b) This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Recent or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the headset is connected. - Consult the dealer or an experienced radio / TV technician for help.	繁中 1. 關於您的 MusicBand 3300 2. 耳機充電 a. 多功能按鈕 (MFB) • 開機 / 關機 • 與行動電話配對 • 接聽 / 結束來電 b. 音量增加按鈕 c. 音量減少按鈕 d. 狀態指示燈 e. USB 充電插座 f. 內建式麥克風 耳機內置可再充電電池。在第一次使用耳機前，建議先為耳機完全充電。 將充電器插頭插入耳機的USB充電插座，然後將充電器連接至交流電源插座或個人電腦 / 手提電腦之中。 請僅使用隨附的充電器 / USB 充電線，為耳機充電。
---	---	---	---	--	--	---

Back

繁中 <table><tr><th>耳機狀態</th><th>狀態指示燈光</th></tr><tr><td>低電量</td><td>每3分鐘閃動紅色3次及「電量低」提示音</td></tr><tr><td>充電中</td><td>紅色</td></tr><tr><td>完全充電</td><td>關閉</td></tr></table> 需要大約 1 小時的時間，才能將耳機充滿電量。 * 警告：請勿在耳機連接至充電器時使用耳機。	耳機狀態	狀態指示燈光	低電量	每3分鐘閃動紅色3次及「電量低」提示音	充電中	紅色	完全充電	關閉	3. 將耳機與藍牙行動電話配對 1) 確保耳機已關閉。 2) 如要啟動配接模式，請按住耳機的MFB鍵 8 秒，直至狀態指示燈交替閃爍藍色和紅色。 3) 啟動流動電話的藍牙功能，搜尋藍牙裝置，然後選擇 "MusicBand 3300"，並輸入密碼 "0000"。當配接完成後，耳機的狀態指示燈會顯示藍燈 2 秒鐘，並會聽到「手機已連接」的提示音 (語音提示語言設定須選擇為中文)。	4. 基本操作 <table><tr><th>功能</th><th>按鈕</th><th>嗶聲 / 語音提示</th><th>狀態指示燈</th></tr><tr><td>開機</td><td>按住MFB約2.5秒鐘</td><td>「開機」</td><td>閃爍藍燈 3 次</td></tr><tr><td>當您第一次開啟耳機時，耳機會進入配對模式，即狀態指示燈會交替閃爍藍色、紅色，如此您可以立即將耳機與裝置進行配對。</td><td></td><td></td><td></td></tr><tr><td>開機 / 結束來電</td><td>按一次MFB</td><td>短嗶聲</td><td>--</td></tr><tr><td>重播最後號碼</td><td>連接MFB兩次</td><td>短嗶聲</td><td>--</td></tr><tr><td>音量增加</td><td>按音量增加鍵 + 一次</td><td>--</td><td>--</td></tr></table>	功能	按鈕	嗶聲 / 語音提示	狀態指示燈	開機	按住MFB約2.5秒鐘	「開機」	閃爍藍燈 3 次	當您第一次開啟耳機時，耳機會進入配對模式，即狀態指示燈會交替閃爍藍色、紅色，如此您可以立即將耳機與裝置進行配對。				開機 / 結束來電	按一次MFB	短嗶聲	--	重播最後號碼	連接MFB兩次	短嗶聲	--	音量增加	按音量增加鍵 + 一次	--	--	<table><tr><th>功能</th><th>按鈕</th><th>嗶聲 / 語音提示</th><th>狀態指示燈</th></tr><tr><td>音量減少</td><td>按音量減少鍵 - 一次</td><td>--</td><td>--</td></tr><tr><td>下一首音樂</td><td>長按音量增加鍵 + 一次</td><td>--</td><td>--</td></tr><tr><td>上一首音樂</td><td>長按音量減少鍵 - 一次</td><td>--</td><td>--</td></tr><tr><td>設定語音提示語言</td><td>持續按住下列按鈕約1秒鐘：MFB、音量增加鍵 + 及音量減少鍵 -</td><td>短嗶聲</td><td>閃爍藍及紅燈 3 次</td></tr></table>	功能	按鈕	嗶聲 / 語音提示	狀態指示燈	音量減少	按音量減少鍵 - 一次	--	--	下一首音樂	長按音量增加鍵 + 一次	--	--	上一首音樂	長按音量減少鍵 - 一次	--	--	設定語音提示語言	持續按住下列按鈕約1秒鐘：MFB、音量增加鍵 + 及音量減少鍵 -	短嗶聲	閃爍藍及紅燈 3 次	雙待機多方配接技術讓您可同時將兩部流動電話配接。配接程序： 1. 將耳機與第一部電話配接，然後關閉。 2. 為第二部電話重複配接程序。 3. 使用電話功能表，把第一部電話與耳機重新配接。 i.Tech藍牙耳機是專門設計與藍牙裝置搭配使用。由於不同製造商提供種類繁多的藍牙裝置，因此無法完全保證耳機可與啟用藍牙的產品之間能互通。 FCC RF 輻射暴露聲明 本器材符合在不受控制環境下的FCC輻射暴露限制，最終用戶必須從特定的操作指引以符合FCC的要求。此設備不能與任何天線或發射器共同設置。 聯邦通訊委員會(FCC) 聲明 本器材符合FCC第15部分的要求。操作要遵守以下兩個條件：(1) 本器材不能產生有害的干擾，以及(2) 本器材必須接受任何收到的干擾，包括可能引起超額的上干擾。 任何未經負責遵守條例一方明示批准的修改或更改，將會取消用戶操作本器材的權利。 15.21 我們在此對你作出聲，任何未經遵守條例一方明示批准的修改或更改，將會取消用戶去操作本器材的權利。	安全指引 • 駕駛時請先關閉當地有使用手提電話及耳機的法则。使用本耳機時，必須保持集中，注意路面情況。為閣下安全著想，請小心駕駛。可考慮先將車輛停泊於路旁，再撥打或接听電話。 • 切勿把本耳機放在車內安全氣袋的位置上，因為當安全氣袋弹出時，可能會引致嚴重的傷害。 • 切勿讓兒童玩耍本耳機，細小的零件可能令兒童有窒息的危险。 • 醫院、爆破地点或潛在爆炸環境的地方，可能會要求用戶关掉電子器材及無線電裝置。當進入特定範圍內時請留意有關指示。 • 登機前請先將耳機關掉，在飛機內不可使用本耳機。 • 為閣下聽覺著想，請勿把音量調得太大。 護理及保養 • 切勿試圖對本耳機作出任何修改。 • 切勿把本耳機放置在洗手盆或其他潮濕的地方。 • 切勿在雨中或使用本耳機。 • 切勿在風雨時使用本耳機。 • 當處於充電狀態時，請勿清潔本耳機。應先把耳機及充電器分開，再進行清潔。 • 切勿讓耳機暴露在溫度过高或过低的地方。 • 切勿讓耳機靠近明火，以免煮焦。 • 切勿讓耳機長時間受陽光直射照射。 • 切勿讓耳機接觸到任何尖銳的物體，因為這會造成割痕和損壞。 • 切勿在耳機內敷設任何物品，因為這可能會損害內部零件。 • 切勿嘗試拆開耳機，因為它並不包含任何維修組件。如果長時間內不打算使用耳機，請將它儲存在乾燥的地方，避免極端的溫度和灰塵。	簡中 <table><tr><th>耳机状态</th><th>状态指示灯光</th></tr><tr><td>低电量</td><td>每3分钟闪烁红色3次及“电量低”提示音</td></tr><tr><td>充电中</td><td>红色</td></tr><tr><td>已充饱电</td><td>关闭</td></tr></table> 需要大约 1 小时的时间，才能将耳机充满电量。 * 警告：请勿在耳机连接至充电器时使用耳机。	耳机状态	状态指示灯光	低电量	每3分钟闪烁红色3次及“电量低”提示音	充电中	红色	已充饱电	关闭	1. 关于您的 MusicBand 3300 a. 多功能按钮 (MFB) • 开机 / 关机 • 与行动电话配对 • 接听 / 结束来电 b. 音量增加按钮 c. 音量减少按钮 d. 状态指示灯 e. USB 充电孔 f. 内置麦克风	2. 耳机充电 耳机随附内置式充电电池。第一次使用耳机之前，建议您将电池充满电。 将您的耳机插入 USB 充电插，并将主充电器插入 AC 墙壁插座或插入个人计算机 / 笔记本计算机。 请仅使用随附的充电器 / USB充电线，为耳机充电。
耳機狀態	狀態指示燈光																																																																			
低電量	每3分鐘閃動紅色3次及「電量低」提示音																																																																			
充電中	紅色																																																																			
完全充電	關閉																																																																			
功能	按鈕	嗶聲 / 語音提示	狀態指示燈																																																																	
開機	按住MFB約2.5秒鐘	「開機」	閃爍藍燈 3 次																																																																	
當您第一次開啟耳機時，耳機會進入配對模式，即狀態指示燈會交替閃爍藍色、紅色，如此您可以立即將耳機與裝置進行配對。																																																																				
開機 / 結束來電	按一次MFB	短嗶聲	--																																																																	
重播最後號碼	連接MFB兩次	短嗶聲	--																																																																	
音量增加	按音量增加鍵 + 一次	--	--																																																																	
功能	按鈕	嗶聲 / 語音提示	狀態指示燈																																																																	
音量減少	按音量減少鍵 - 一次	--	--																																																																	
下一首音樂	長按音量增加鍵 + 一次	--	--																																																																	
上一首音樂	長按音量減少鍵 - 一次	--	--																																																																	
設定語音提示語言	持續按住下列按鈕約1秒鐘：MFB、音量增加鍵 + 及音量減少鍵 -	短嗶聲	閃爍藍及紅燈 3 次																																																																	
耳机状态	状态指示灯光																																																																			
低电量	每3分钟闪烁红色3次及“电量低”提示音																																																																			
充电中	红色																																																																			
已充饱电	关闭																																																																			

繁中 • 避免在溫度過高或過低的地方為耳機充電。 • 請根據地方法規棄置電池和耳機。不要將它當作家庭廢物般棄置。 內置電池 • 切勿嘗試更換耳機的電池，因為它是內置的，且不能更換。 • 請根據地方法規棄置電池。不要將它當作家庭廢物般棄置。 • 請按照本用戶指南附有的指示替電池充電。 充電器 • 請使用耳機製造商提供的原裝充電器，使用其他品牌的充電器可能會損壞耳機，甚至構成危險。 • 由於在拆解充電器時可能會接觸到高压電流或構成其他危險，請勿嘗試拆解充電器。使用不正確組裝的充電器會引致觸電危險。 • 請勿在戶外或潮濕地方使用充電器。	有關環保注意事項 自從在國家法律體系中實施歐盟指令2012/19/EU後，以下措施開始應用：電器及電子產品不能作一般家庭廢物處理。如在電器產品壽命終結時，消費者將根據法例規定，將產品棄置於特定的公共收集點或銷售點作回收用途，但細節須由相關國家的國家法律所定。產品、說明書或包裝上的標誌，說明這類產品是受到這法律的規定，循環使用或再用這些物料或使用其他形式的器材，將對環境保護有重大貢獻。	疑難排解 問：我的耳機沒有聲音。 答：• 請確保耳機已啟動並完全充電。 • 請確保耳機與流動電話妥善配接。 • 如未能連接，請參閱流動電話的藍牙功能表，或按MFB一次。(請參閱「基本操作」及「將耳機與藍牙行動電話配接」一節)。 問：我不能把耳機與流動電話連接。 答：• 請確保耳機已啟動並適當充電。 • 請確保耳機與流動電話妥善配接。 • 請參閱流動電話的藍牙裝置已被啟用。詳細操作說明請參考流動電話用戶使用說明。 • 請確保耳機位於流動電話的10米範圍之內，而當中並沒有任何障礙物，例如牆壁或其他電子器材等。	如以上步驟未能解決問題，請重新把耳機充電並把電池從手機取出一會。 愛達克球有限公司 所有在本刊的資料均為其版權，沒有印刷錯誤的書面問題，不得作出任何翻印。在印刷時，所有在本刊的內容均屬真實正確，但任何材料、規格、產品或服務的，以及相關的產品ID可能會修改、補充或撤銷或未來失效。 時期的i.Tech標誌是愛達克球有限公司或其附屬公司擁有的商標，所有其他商標或標誌均屬於相應的擁有者。 Bluetooth® 和藍牙商標是屬於Bluetooth SIG, Inc. USA擁有的商標並經授予i.Tech Dynamic Global Distribution Limited。 i.Tech聲明其耳機唯一責任下，本耳機是符合下列委員會指令的條款：2014/53/EU	FCC RF 輻射暴露聲明 本器材符合在不受控制環境下的FCC輻射暴露限制，最終用戶必須從特定的操作指引以符合FCC的要求。此設備不能與任何天線或發射器共同設置。 聯邦通訊委員會(FCC) 聲明 本器材符合FCC第15部分的要求。操作要遵守以下兩個條件：(1) 本器材不能產生有害的干擾，以及(2) 本器材必須接受任何收到的干擾，包括可能引起超額的上干擾。 任何未經負責遵守條例一方明示批准的修改或更改，將會取消用戶操作本器材的權利。 15.21 我們在此對你作出聲，任何未經遵守條例一方明示批准的修改或更改，將會取消用戶去操作本器材的權利。	安全指引 • 駕駛時請先關閉當地有使用手提電話及耳機的法则。使用本耳機時，必須保持集中，注意路面情況。為閣下安全著想，請小心駕駛。可考慮先將車輛停泊於路旁，再撥打或接听電話。 • 切勿把本耳機放在車內安全氣袋的位置上，因為當安全氣袋弹出時，可能會引致嚴重的傷害。 • 切勿讓兒童玩耍本耳機，細小的零件可能令兒童有窒息的危险。 • 醫院、爆破地点或潛在爆炸環境的地方，可能會要求用戶关掉電子器材及無線電裝置。當進入特定範圍內時請留意有關指示。 • 登機前請先將耳機關掉，在飛機內不可使用本耳機。 • 為閣下聽覺著想，請勿把音量調得太大。 護理及保養 • 切勿試圖對本耳機作出任何修改。 • 切勿把本耳機放置在洗手盆或其他潮濕的地方。 • 切勿在雨中或使用本耳機。 • 切勿在風雨時使用本耳機。 • 當處於充電狀態時，請勿清潔本耳機。應先把耳機及充電器分開，再進行清潔。 • 切勿讓耳機暴露在溫度过高或过低的地方。 • 切勿讓耳機靠近明火，以免煮焦。 • 切勿讓耳機長時間受陽光直射照射。 • 切勿讓耳機接觸到任何尖銳的物體，因為這會造成割痕和損壞。 • 切勿在耳機內敷設任何物品，因為這可能會損害內部零件。 • 切勿嘗試拆開耳機，因為它並不包含任何維修組件。如果長時間內不打算使用耳機，請將它儲存在乾燥的地方，避免極端的溫度和灰塵。	簡中 <table><tr><th>耳机状态</th><th>状态指示灯光</th></tr><tr><td>低电量</td><td>每3分钟闪烁红色3次及“电量低”提示音</td></tr><tr><td>充电中</td><td>红色</td></tr><tr><td>已充饱电</td><td>关闭</td></tr></table> 需要大约 1 小时的时间，才能将耳机充满电量。 * 警告：请勿在耳机连接至充电器时使用耳机。	耳机状态	状态指示灯光	低电量	每3分钟闪烁红色3次及“电量低”提示音	充电中	红色	已充饱电	关闭	1. 关于您的 MusicBand 3300 a. 多功能按钮 (MFB) • 开机 / 关机 • 与行动电话配对 • 接听 / 结束来电 b. 音量增加按钮 c. 音量减少按钮 d. 状态指示灯 e. USB 充电孔 f. 内置麦克风	2. 耳机充电 耳机随附内置式充电电池。第一次使用耳机之前，建议您将电池充满电。 将您的耳机插入 USB 充电插，并将主充电器插入 AC 墙壁插座或插入个人计算机 / 笔记本计算机。 请仅使用随附的充电器 / USB充电线，为耳机充电。
耳机状态	状态指示灯光															
低电量	每3分钟闪烁红色3次及“电量低”提示音															
充电中	红色															
已充饱电	关闭															

簡中 • 避免在温度过高或过低的地方为耳机充电。 • 请根据地方法规弃置电池和耳机。不要将它当作家庭废物般弃置。 内置电池 • 切勿尝试更换耳机的电池，因为它是内置的，且不能更换。 • 请根据地方法规弃置电池。不要将它当作家庭废物般弃置。 • 请按照本用户指南附有的指示替电池充电。 充电器 • 请使用耳机制造商提供的原装充电器，使用其他品牌的充电器可能会损坏耳机，甚至构成危险。 • 由于在拆解充电器时可能会接触到高压电流或构成其它危险，请勿尝试拆解充电器。使用不正确组装的充电器会引致触电危险。	有关环保注意事项 自从在国家法律体系中央实施欧盟指令2012/19/EU后，以下措施开始应用：电器及电子产品不能作一般家庭废物处理。如在电器产品寿命终结时，消费者将根据法例规定，将产品弃置于特定的公共收集点或销售点作回收用途，但细节须由相关国家的国家法律所定。产品、说明书或包装上的标志，说明这类产品是受到这法律的规定的，循环使用或再用这些物料或使用其它形式的器材，将对环境保护有重大贡献。	疑难排解 問：我的耳机没有声音。 答：• 請確保耳机已启动并完全充电。 • 請確保耳机与流动电话妥善配接。 • 如未能连接，請參閱流动电话的蓝牙菜单，或按MFB一次。(請參閱「基本操作」及「將耳机与蓝牙行动电话配接」一節)。 問：我不能把耳机与流动电话连接。 答：• 請確保耳机已启动并适当充电。 • 請確保耳机与流动电话妥善配接。 • 請參閱流动电话的蓝牙装置已被启用。詳細操作說明請參考流动电话用户使用說明。 • 請確保耳机位于流动电话的10米範圍之內，而當中並沒有任何障礙物，例如牆壁或其他電子器材等。	如以上步驟未能解決問題，請重新把耳机充电并把电池从手机取出一会。 爱达克球有限公司 所有在本刊的資料均為其版權，沒有印刷錯誤的書面問題，不得作出任何翻印。在印刷時，所有在本刊的內容均屬真實正確，但任何材料、規格、產品或服務的，以及相關的產品ID可能會修改、補充或撤銷或未來失效。 時期的i.Tech標誌是愛達克球有限公司或其附屬公司擁有的商標，所有其他商標或標誌均屬於相應的擁有者。 Bluetooth® 和藍牙商標是屬於Bluetooth SIG, Inc. USA擁有的商標並經授予i.Tech Dynamic Global Distribution Limited。 i.Tech聲明其耳機唯一責任下，本耳機是符合下列委員會指令的條款：2014/53/EU	FCC RF 辐射暴露声明 本器材符合在不受控制环境下的FCC辐射暴露限制，最终用户必须从特定的操作指引以符合FCC的要求。此设备不能与任何天线或发器共同设置。 联邦通讯委员会(FCC) 声明 本器材符合FCC第15部分的要求。操作要遵守以下两个条件：(1) 本器材不能产生有害的干扰，以及(2) 本器材必须接受任何收到的干扰，包括可能引起超额的上下干扰。 任何未经负责遵守条例一方明示批准的修改或更改，将会取消用户操作本器材的权利。 15.21 我们在此对你作出声，任何未经遵守条例一方明示批准的修改或更改，将会取消用户去操作本器材的权利。	安全指引 • 驾驶时请先关闭当地有使用手提电话及耳机法则的法则。使用本耳机时，必须保持集中，注意路面情况。为阁下安全着想，请小心驾驶。可考虑先将要车辆停泊于路旁，再拨打或接听电话。 • 切勿把本耳机放在车内安全气囊的位置上，因为当安全气囊弹出时，可能会导致严重的伤害。 • 切勿让儿童玩耍本耳机，细小的零件可能令儿童有窒息的危险。 • 医院、爆破地点或潜在在爆炸环境的地方，可能会要求用户关掉电子器材及无线电装置。当进入特定范围内时请留意有关指示。 • 登机前请先将耳机关掉，在飞机内不可使用本耳机。 • 为阁下听觉着想，请勿把音量调得太大。 护理及保养 • 切勿试图对本耳机作出任何修改。 • 切勿把本耳机放置在洗手盆或其它潮湿的地方。 • 切勿在雨中不使用本耳机。 • 切勿在风雨时使用本耳机。 • 当处于充电状态时，请勿清洁本耳机。应先把手机及充电器分开，再进行清洁。 • 请勿让耳机暴露在温度过高或过低的地方。 • 请勿让耳机靠近明火，以免煮焦。 • 请勿让耳机长时间受阳光直射照射。 • 请勿让耳机接触到任何尖锐的物体，因为这会造成划痕和损坏。 • 切勿在耳机内敷设任何物品，因为这可能会损害内部零件。 • 切勿尝试拆开耳机，因为它并不包含任何维修组件。如果长时间不打算使用耳机，请将它存放在干燥的地方，避免极端的温度和灰尘。	EU Declaration of Conformity (DoC) Henley we, Name of manufacturer : i.Tech Dynamic Global Distribution Limited Address: 406-407, 4/F, Shui Hing Centre, 13 Sheung Yuet Road, Kowloon Bay, K'n, Hong Kong Country: China Telephone number: (852) 3908 1000 declares that this DoC is issued under our sole responsibility and that this product complies with the relevant Union harmonization legislation applicable to this product: Product description: Bluetooth Stereo Headphones Type designation(s): MusicBand 3300 Trademarks: i.Tech Batch / Serial number: AC7Pxxxxxxxxxxxx Object of the declaration (for identification of the radio equipment allowing traceability, it may include a color image for the identification of the radio equipment): MusicBand 3300 is in conformity with the relevant Union harmonization legislation: Radio equipment directive: 2014/53/EU and other Union harmonization legislation where applicable with reference to the following standards applied: EN 60950-1: 2006+A11: 2008+A1: 2010+A2: 2011+A2: 2013; Draft EN 301 489-1 V22.0 (2017-03); EN 62479: 2010; Draft EN 301 489-1 V3.2.0 (2017-03); EN 300 328 V2.1.1 (2016-11)	The Notified Body Telefication B.V., with Notified Body number 0560 provided (Modules B+C) Where applicable: Description of accessories and components, including software, which allow the radio equipment to operate as intended and covered by the DoC: Bluetooth: 2400-2483.5MHz Operation Temperature: -10°C, +45°C MAX output power: BT classic: 10 dBm Signed for and on behalf of: Patrick Tsang, Chief Operations Officer
---	--	---	--	--	--	---	--