

JJ-CRC-I11 UserGuide

- Frequency: 433.92MHz
- Indicator light: Blue LED
- Working Voltage: DC 12V

Noted: Please take battery out when no use.

- Working current: 9ma±0.5ma
- Picture



- **Main Function:**
Remote control duplicator which can copy 90% fixed code remote control in market.
- **How to work(3 functions):**
 - 1. To remove the existing code:**
Press buttons A and B simultaneously until the LED flashes (approximately 10 seconds), release both buttons and all codes will be eliminated .
 - 2. To duplicate code**
Hold the The original and duplicator as close as possible to each other. Press button A on both duplicator and original transmitter at the same time, after 5 seconds, the LED will flash steadily, release both buttons and the code will have been accepted. Repeat the above operation to duplicate the code of the other buttons.
 - 3. Code retrieval**
If the code is inadvertently removed previous code can be retrieved by pressing buttons C and D simultaneously until the LED flashes (approximately 10 seconds).

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.