





OBW NVNT ax20 6995MHz Ant13 SISO




OBW NVNT ax20 7115MHz Ant13 SISO






OBW NVNT ax40 5965MHz Ant12 SISO




OBW NVNT ax40 6205MHz Ant12 SISO






OBW NVNT ax40 6405MHz Ant12 SISO




OBW NVNT ax40 6565MHz Ant12 SISO






OBW NVNT ax40 6685MHz Ant12 SISO




OBW NVNT ax40 6845MHz Ant12 SISO






OBW NVNT ax40 5965MHz Ant13 SISO




OBW NVNT ax40 6205MHz Ant13 SISO






OBW NVNT ax40 6405MHz Ant13 SISO




OBW NVNT ax40 6565MHz Ant13 SISO






OBW NVNT ax40 6685MHz Ant13 SISO




OBW NVNT ax40 6845MHz Ant13 SISO






OBW NVNT ax40 6445MHz Ant12 SISO




OBW NVNT ax40 6485MHz Ant12 SISO






OBW NVNT ax40 6885MHz Ant12 SISO




OBW NVNT ax40 6965MHz Ant12 SISO






OBW NVNT ax40 7085MHz Ant12 SISO




OBW NVNT ax40 6445MHz Ant13 SISO






OBW NVNT ax40 6485MHz Ant13 SISO




OBW NVNT ax40 6885MHz Ant13 SISO






OBW NVNT ax40 6965MHz Ant13 SISO




OBW NVNT ax40 7085MHz Ant13 SISO






OBW NVNT ax80 5985MHz Ant12 SISO




OBW NVNT ax80 6225MHz Ant12 SISO






OBW NVNT ax80 6385MHz Ant12 SISO




OBW NVNT ax80 6625MHz Ant12 SISO






OBW NVNT ax80 6705MHz Ant12 SISO




OBW NVNT ax80 6785MHz Ant12 SISO






OBW NVNT ax80 5985MHz Ant13 SISO




OBW NVNT ax80 6225MHz Ant13 SISO






OBW NVNT ax80 6385MHz Ant13 SISO




OBW NVNT ax80 6625MHz Ant13 SISO






OBW NVNT ax80 6705MHz Ant13 SISO




OBW NVNT ax80 6785MHz Ant13 SISO






OBW NVNT ax80 6465MHz Ant12 SISO




OBW NVNT ax80 6945MHz Ant12 SISO






OBW NVNT ax80 7025MHz Ant12 SISO




OBW NVNT ax80 6465MHz Ant13 SISO






OBW NVNT ax80 6945MHz Ant13 SISO




OBW NVNT ax80 7025MHz Ant13 SISO






OBW NVNT ax160 6025MHz Ant12 SISO




OBW NVNT ax160 6185MHz Ant12 SISO






OBW NVNT ax160 6345MHz Ant12 SISO




OBW NVNT ax160 6665MHz Ant12 SISO






OBW NVNT ax160 6025MHz Ant13 SISO




OBW NVNT ax160 6185MHz Ant13 SISO






OBW NVNT ax160 6345MHz Ant13 SISO




OBW NVNT ax160 6665MHz Ant13 SISO






OBW NVNT ax160 6985MHz Ant12 SISO




OBW NVNT ax160 6985MHz Ant13 SISO






OBW NVNT be20 5955MHz Ant12 SISO




OBW NVNT be20 6175MHz Ant12 SISO






OBW NVNT be20 6415MHz Ant12 SISO




OBW NVNT be20 6535MHz Ant12 SISO






OBW NVNT be20 6695MHz Ant12 SISO




OBW NVNT be20 6855MHz Ant12 SISO






OBW NVNT be20 5955MHz Ant13 SISO




OBW NVNT be20 6175MHz Ant13 SISO






OBW NVNT be20 6415MHz Ant13 SISO




OBW NVNT be20 6535MHz Ant13 SISO






OBW NVNT be20 6695MHz Ant13 SISO




OBW NVNT be20 6855MHz Ant13 SISO






OBW NVNT be20 6435MHz Ant12 SISO




OBW NVNT be20 6475MHz Ant12 SISO






OBW NVNT be20 6515MHz Ant12 SISO




OBW NVNT be20 6875MHz Ant12 SISO






OBW NVNT be20 6995MHz Ant12 SISO




OBW NVNT be20 7115MHz Ant12 SISO






OBW NVNT be20 6435MHz Ant13 SISO




OBW NVNT be20 6475MHz Ant13 SISO






OBW NVNT be20 6515MHz Ant13 SISO




OBW NVNT be20 6875MHz Ant13 SISO






OBW NVNT be20 6995MHz Ant13 SISO




OBW NVNT be20 7115MHz Ant13 SISO






OBW NVNT be40 5965MHz Ant12 SISO




OBW NVNT be40 6205MHz Ant12 SISO






OBW NVNT be40 6405MHz Ant12 SISO




OBW NVNT be40 6565MHz Ant12 SISO






OBW NVNT be40 6685MHz Ant12 SISO




OBW NVNT be40 6845MHz Ant12 SISO






OBW NVNT be40 5965MHz Ant13 SISO




OBW NVNT be40 6205MHz Ant13 SISO






OBW NVNT be40 6405MHz Ant13 SISO




OBW NVNT be40 6565MHz Ant13 SISO






OBW NVNT be40 6685MHz Ant13 SISO




OBW NVNT be40 6845MHz Ant13 SISO






OBW NVNT be40 6445MHz Ant12 SISO




OBW NVNT be40 6485MHz Ant12 SISO






OBW NVNT be40 6885MHz Ant12 SISO




OBW NVNT be40 6965MHz Ant12 SISO






OBW NVNT be40 7085MHz Ant12 SISO




OBW NVNT be40 6445MHz Ant13 SISO






OBW NVNT be40 6485MHz Ant13 SISO




OBW NVNT be40 6885MHz Ant13 SISO






OBW NVNT be40 6965MHz Ant13 SISO




OBW NVNT be40 7085MHz Ant13 SISO






OBW NVNT be80 5985MHz Ant12 SISO




OBW NVNT be80 6225MHz Ant12 SISO






OBW NVNT be80 6385MHz Ant12 SISO




OBW NVNT be80 6625MHz Ant12 SISO






OBW NVNT be80 6705MHz Ant12 SISO




OBW NVNT be80 6785MHz Ant12 SISO






OBW NVNT be80 5985MHz Ant13 SISO




OBW NVNT be80 6225MHz Ant13 SISO






OBW NVNT be80 6385MHz Ant13 SISO




OBW NVNT be80 6625MHz Ant13 SISO






OBW NVNT be80 6705MHz Ant13 SISO




OBW NVNT be80 6785MHz Ant13 SISO






OBW NVNT be80 6465MHz Ant12 SISO




OBW NVNT be80 6945MHz Ant12 SISO






OBW NVNT be80 7025MHz Ant12 SISO




OBW NVNT be80 6465MHz Ant13 SISO






OBW NVNT be80 6945MHz Ant13 SISO




OBW NVNT be80 7025MHz Ant13 SISO






OBW NVNT be160 6025MHz Ant12 SISO




OBW NVNT be160 6185MHz Ant12 SISO






OBW NVNT be160 6345MHz Ant12 SISO




OBW NVNT be160 6665MHz Ant12 SISO






OBW NVNT be160 6025MHz Ant13 SISO




OBW NVNT be160 6185MHz Ant13 SISO






OBW NVNT be160 6345MHz Ant13 SISO




OBW NVNT be160 6665MHz Ant13 SISO






OBW NVNT be160 6985MHz Ant12 SISO




OBW NVNT be160 6985MHz Ant13 SISO






OBW NVNT be320 6105MHz Ant12 SISO




OBW NVNT be320 6745MHz Ant12 SISO






OBW NVNT be320 6105MHz Ant13 SISO




OBW NVNT be320 6745MHz Ant13 SISO






OBW NVNT be320 6425MHz Ant12 SISO




OBW NVNT be320 6905MHz Ant12 SISO






OBW NVNT be320 6425MHz Ant13 SISO




OBW NVNT be320 6905MHz Ant13 SISO






OBW NVNT ax20 26@0 5955MHz Ant12 SISO




OBW NVNT ax20 26@0 6175MHz Ant12 SISO






OBW NVNT ax20 26@0 6415MHz Ant12 SISO




OBW NVNT ax20 26@0 6535MHz Ant12 SISO






OBW NVNT ax20 26@0 6695MHz Ant12 SISO




OBW NVNT ax20 26@0 6855MHz Ant12 SISO






OBW NVNT ax20 26@0 5955MHz Ant13 SISO




OBW NVNT ax20 26@0 6175MHz Ant13 SISO






OBW NVNT ax20 26@0 6415MHz Ant13 SISO




OBW NVNT ax20 26@0 6535MHz Ant13 SISO






OBW NVNT ax20 26@0 6695MHz Ant13 SISO



OBW NVNT ax20 26@0 6855MHz Ant13 SISO






OBW NVNT ax20 26@0 6435MHz Ant12 SISO




OBW NVNT ax20 26@0 6475MHz Ant12 SISO






OBW NVNT ax20 26@0 6515MHz Ant12 SISO




OBW NVNT ax20 26@0 6875MHz Ant12 SISO






OBW NVNT ax20 26@0 6995MHz Ant12 SISO




OBW NVNT ax20 26@0 7115MHz Ant12 SISO






OBW NVNT ax20 52@37 5955MHz Ant12 SISO




OBW NVNT ax20 52@37 6175MHz Ant12 SISO






OBW NVNT ax20 52@37 6415MHz Ant12 SISO




OBW NVNT ax20 52@37 6535MHz Ant12 SISO





OBW NVNT ax20 52@37 6695MHz Ant12 SISO



OBW NVNT ax20 52@37 6855MHz Ant12 SISO

