


SPEAKER



SPEAKER

IQ-1508DJWK

1.USB IN
2.Micro SD
3.Audio output
4.Micro USB Input
5.Previous
6.Next
7.Left
8.Right

9. Enter
10. Return
11. Multi-media
12. MIC priority
13. Track
14. Power on/off
15. Master volume
16. Treble

17. BASS
18. DC 12V IN
19. Power led light
20. MIC input
21. Steps how to REC
22. Echo
23. MIC volume
24. DC-12V

1. POWER ON/OFF.

2. MUTE.

3. LIVE.

4. VOD.

5. APP.

6. SET.

7. PREVIOUS.

8. NEXT.

9. VOLUME -.

10. VOLUME +.

11. MENU.

12. VEDIO/AUDIO.

13. UP/DOWN/LEFT/RIGHT.

14. OK.


15. RETURN.

16. HOME.

17. 0~9 play video and input password have effect.

18. MIC PRIORITY.

19. SOUND TRACK: audio tracks are used in video playback.



Carefully read the operating manual to operate this unit correctly,
and keep these manuals handy for future reference.

PRODUCT MANUAL

Thanks for choosing our company DIGITAL MULTI-MEDIA product.
Please read this manual carefully in order to use it in safety.

Function

1. Audio support format: MP3.WMA.APE.AAC.LFAC.OGG.
2. Video support format: RMVB AVI Mp4 FLV VOB MKV WMV MAX IN 720P.
3. MIC record: support record from microphone.
Use remote control to enter the menu MyApp option.
press OK to start the record or record playing.
4. Audio output: with audio output jack.
5. wired mic: when playing karaoke then press mic priority, original singer sound will be disappear. Insert wired mic, then you can enjoy the karaoke.
6. Wireless mic: put battery into wireless microphone before using.
7. Insert USB drive or TF card. this machine will read it and play automatically.
8. Return: press return. then it back to HOME from any media.
9. Track: support LEFT and RIGHT sound channel.
10. Power: power knob is on the top of the panel.
11. Software: factory service jack for system software only.
12. Connect wifi for internet searching with soft Touch display

OPERATION

1. Main interface icon: use remote control panel to select.
2. WIFI: press SET to select wifi connectoin, input wifi password.
click by hand on screen to connect wifi ,insert wifi password .
3. Bluetooth: select Bluetooth logo, open it and find the bluetooth pairing name then pair it with mobile.
4. AUDIO: select Video Musci to switch into audio mode.
5. Google play: it is an App store. you can download any App from Google play after WIFI been connected.

SPECIFICATION

Speaker Features:

- 8" Full Range Speakers
- Built-in Bluetooth® Compatible Allows Your Speaker to Wirelessly Connect to Bluetooth® Enabled Devices
- FM Radio
- 15" Wireless Screen Display
- USB/SD/AUX Inputs Allow You to Connect Your Non-Bluetooth® External Audio Devices
- One Microphone Jack (1 Mic Included)
- AV Input and Output
- Remote Control Included
- Built-in Handle & Wheels for Easy Transport
- Frequency Response: 40Hz-20KHz
- S/N Ratio: 78dB±3dB
- Impedance: 4 ohm
- Peak Power Capacity: 5000Watts
- RMS Power: 80W
- Maximum SPL: 128dB
- Dispersion (@ 6dB): H90° x V50°
- Crossover: 3KHz
- AC Power Supply: 110/220V, 50Hz-60Hz

REMARK

1. For first time use this product, please charge it for 6 hours
2. Please do not insert the earphone into audio output and update the software from The CONNECTION.
3. When battery is low, please charging in time and power off to protect the product.
4. This manual is current software. If any update for any update for software future please refer to the software interface.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.